



OPERATION & MAINTENANCE INSTRUCTIONS

FOR

Coleman®-Mach®

230/240 VAC, 1ø, 50Hz

47000 SERIES

RV ROOF TOP AIR CONDITIONER/HEAT PUMP

AND

REMOTE CONTROLLER



Service Contact:
Coast to Coast RV Services Pty Ltd.
PO BOX 415
REGENTS PARK DC NSW 2143 Australia
Tel: +61-2-9645 7600
technical@coastrv.com.au

Coleman is a registered trademark of The Coleman Company, Inc. used under license. Mach is a registered trademark.

TABLE OF CONTENTS

I.	Model and Serial Numbers	2
II.	Operating Guidelines	2
III.	Adjusting the Air Flow	3
IV.	Hand Held Controller	3
V.	Initial Configuration of the Hand Held Controller	4
VI.	Selecting the Manual Mode of Operation	6
VII.	Follow Me	6
VIII.	Fahrenheit or Celsius (F/C)	6
IX.	Time and Day Set Up	6
X.	7-Day Programming	6
XI.	LED lights & Buttons on Ceiling Assembly	7
XII.	Routine Maintenance	8
XIII.	Warranty	9

These instructions are a general guide for operating and maintaining the 47000 Series, 230/240 VAC, 50Hz, Coleman®-Mach® roof top heat pumps and remote hand held controller.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance and Cleaning and user maintenance shall not be made by children without supervision.

I. Model & Serial Number

Your air conditioner or heat pump has been designed for years of safe, dependable operation. These instructions contain a general description on the operation of the unit, how to set up and operate the controller, and a list of routine maintenance items.

The first thing you should do is to write down the model number and serial number of the unit. Both numbers can be found on the data label on the unit.

Model No. _____ Serial No. _____


II. Operating Guidelines

The air conditioner is designed to provide cooling and dehumidification. A heat pump reverses the refrigerant cycle to provide heating in cool weather. The performance of both units can be optimized by following the simple guidelines:

- Keep doors and windows closed to prevent the loss of conditioner air.
- Keep the curtains closed to reduce heat gain.
- Set the temperature to a reasonable temperature.
- A low fan speed will reduce sound level and improve dehumidification when the unit is cooling.
- Properly adjust the air flow with the slides on the front and rear of the ceiling assembly.
- Never obstruct the air flow to the ceiling assembly.
- Do not spray water or any cleaning fluid into the ceiling assembly. The ceiling assembly should be cleaned with a damp cloth.
- Do not put any object, including your hands, into the openings of the ceiling assembly.

III. Adjusting the Air Flow


The conditioned air is distributed through the ceiling assembly. Slides on the front and rear of the ceiling assembly can be moved to adjust the air flow to the front and rear.



IV. Hand Held Controller

The remote controller controls the operation of the air conditioner or heat pump with an infrared signal to a sensor on the ceiling assembly. For the best reception, the remote should be pointing at the ceiling assembly when changing set points and configuring the air conditioner or heat pump.

Note: Should the remote be lost, the air conditioner or heat pump can be controlled by buttons on the ceiling assembly.



V. Initial Configuration of the Remote Controller

The controller has been factory configured to operate the heat pump. Should you wish to verify the correct configuration, the controller must be in either the Heat ELE or the Auto-changeover (Auto) mode.

A. Heat ELE mode.

1. Press the Power Button.
2. Using the Mode button, scroll through the various setting by repeatedly pressing the Mode button until Heat ELE is shown.
3. Press the **MODE & FAN** Buttons for 5 seconds. The temperatures on the screen will disappear and **HP** should appear at the bottom of the screen. If **nHP** is shown, press the **UP & DOWN** buttons to select **HP**.
4. After 5 seconds, the remote will revert to normal operation.

B. Auto-changeover Mode


1. Press the Power Button.
2. Using the Mode button, scroll through the various setting by repeatedly pressing the Mode button until Auto is shown.
3. Press the **MODE & FAN** Buttons for 5 seconds. The temperatures on the screen will disappear and **HP**, **nHP** or **Gas** should appear at the bottom of the screen. If **nHP** or **Gas** is shown, press the **UP & DOWN** buttons to select **HP**.
4. After 5 seconds, the remote will revert to normal operation.

VI. Selecting the Manual Mode of Operation

The air conditioner (if equipped with heat) or heat pump has five modes of operation- Cooling, Heating, Auto (Auto-changeover), Dry and Fan. To select the desired operation, press the **MODE** button. Then use the **UP** or **DOWN** button to select the set point temperature. Select the desired fan speed by pressing the **FAN** button. To advance to the next mode, press the **MODE** button.

Cooling: The unit will operate in cooling mode to maintain the set point temperature.

In the Cooling Mode, four fan selections are available: High speed continuous, Low speed continuous, Auto High or Auto Low. In Auto, the Fan cycles on & off with the compressor. Use the Fan button to select the desired setting. To advance to the Heating mode, press the **MODE** button.



Typical Cooling Screen

Heating: The unit will operate in heating mode to maintain the set point temperature. There are two selections in the Heating Mode – Heat Pump (ELE) and GAS (gas furnace).

(Heating only functions on air conditioners with electric heat, heat pumps or vehicles with an auxiliary source of heat, e.g. a gas furnace.)

A. Vehicles *without* a gas furnace

1. Using the Mode button, scroll through the various setting by repeatedly pressing the Mode button until HEAT ELE is shown.
2. Using the **UP** & **DOWN** buttons, select the desired set point temperature.
3. Press the **FAN** button to select either High or Low Fan speed.
4. Press the mode button twice to go to Auto Mode, bypassing the HEAT GAS set up.

B. Vehicles *with* a gas furnace

1. Repeat steps 1-3 above.
2. Press the **MODE** button once and Heat GAS is shown.
3. Using the **UP** & **DOWN** buttons, select the desired set point temperature.
4. In HEAT GAS, the fan speed is selected automatically; the user can not select the fan speed.
5. Press the **MODE** button to go to AUTO mode.

NOTE: HEAT GAS should only be used if a gas furnace is to be operated with the controller. In Gas heat mode, Follow Me is automatically turned on. See description of Follow Me below.

Auto: The unit will automatically heat and cool, depending on the set point temperature. (Heating only functions on air conditioners with electric heat, heat pumps or vehicles with an auxiliary source of heat, e.g. a gas furnace). Use the **UP & DOWN** buttons to select the desired set point temperature. In the Auto mode, the fan speed is selected automatically. To advance to the Dry mode, press the **MODE** button.

Dry: This mode is for dehumidification when the vehicle is not in use. The unit will operate in the cooling mode to provide dehumidification. Use the **UP & DOWN** buttons to select the desired set point temperature. If the room temperature is above the set point, the unit will operate for 15 minutes and then turn off for 3 minutes. If the room temperature is below the set point, the unit will operate for 6 minutes and then turn off for 15 minutes. In the Dry mode, the fan speed is selected automatically. To advance to the Fan mode, press the **MODE** button.

FAN: The indoor fan is run to circulate air, but the compressor does not operate. In the Fan Mode, two fan selections are available: High speed continuous or Low speed continuous. Use the **FAN** button to select.

VII. Follow Me

In normal operation a temperature sensor in the ceiling assembly senses the temperature and controls the operation of the Air Conditioner or Heat Pump. Follow Me switches this control to a temperature sensor on the hand held controller. To activate Follow Me, press the **Follow Me** button for 3 seconds and release. On or Off will flash on the screen. Press the **Follow Me** button again to change the setting. In Gas heat mode, Follow Me is automatically turned on.

VIII. F/C

Selects whether the temperature is displayed in Fahrenheit or Celsius. Press and hold the **F/C** button for 3 seconds and release. CEL or FAH will be displayed. Press the **F/C** button again to change the selection.

IX. Time and Day Set Up

Press the **CLOCK** button and hold for 3 seconds.

The hour and AM or PM will flash. To change the hour, press the **UP** or **DOWN** button.

To change the minute, press and release the **PROGRAM** button. To change the minute, press the **UP** or **DOWN** button.

To change the day, press and release the **PROGRAM** button. To change the day, press the **UP** or **DOWN** button.

Press the **CLOCK** button to return to the normal screen.

X. 7-Day Programming

The 7-day program schedule allows different set point temperatures for different times of each day of the week. The schedule includes four periods— Morning, Day, Evening and Night- for each day of the week. Each period has a start time, a set point temperature for Heat, Cool and Auto modes. For 7-day programming:

Press the **CLOCK** and **PROGRAM** buttons simultaneously and hold for three seconds.

The first selection is for the day of the week. Press the **UP** or **DOWN** button to select Monday (MON).

Press the **PROGRAM** button to select the settings for the Morning period. Press the **UP** or **DOWN** button to select Morning.

Press the **PROGRAM** button to select the hour for the period to begin. Use the **UP** and **DOWN** button to select the hour.

Press the **PROGRAM** button to select the minute for the period to begin. Use the **UP** and **DOWN** button to select the minute.

Press the **PROGRAM** button to select the set point temperature for Cooling. Press the UP or DOWN button to select the desired temperature.

Press the **PROGRAM** button to select the set point temperature for Heating. Press the UP or DOWN button to select the desired temperature.

Press the **PROGRAM** button to select the set point temperature for Auto. Press the UP or DOWN button to select the desired temperature.


Repeat this procedure to select the start times and set point temperatures for Monday Day, Monday Evening and Monday Night.

Repeat this procedure for the remaining days of the week.

If the unit is in the COOL, HEAT, or AUTO mode, it can be run in either the Manual Run mode or the 7-Day Preprogrammed Run mode. Pushing the **PROGRAM** button will toggle between the Manual Run mode and 7- Day Preprogrammed Run mode. While in the 7-Day Preprogrammed Run mode, PROGRAM will appear at the bottom of the screen. The set point temperatures maybe changed by pushing the **UP & DOWN** buttons. The manually set temperature will remain in effect until the start of the next preprogrammed period. The 7-Day preprogrammed mode is not available in the Fan only or Dry mode.

XI. LED lights and buttons on the ceiling assembly.


The ceiling assembly has a two color LED to indicate if the unit is in Cooling or Heating. Two manual override buttons - one for cooling the other for heating – can be used if the remote controller is lost or malfunctions.



XII. Routine Maintenance

The ceiling assembly and the outside shroud can be cleaned with a damp cloth. When required a mild detergent can be used.

There are two washable filters in the ceiling assembly, one behind each return air louvers. To access the filters, pull on the tabs on the return air grilles. The filters should be washed in warm water or vacuumed clean and replaced. The filters should be inspected once a month and cleaned as required. Note: If the unit is operated in a dusty environment, the filters should be inspected and cleaned more frequently.



XIII. WARRANTY



Coast RV Pty Ltd
trading as Coast to Coast RV Services
ABN 49 097 104 492 - ACN 101 461 330
PO Box 415, Regents Park NSW 2143
AUSTRALIA
Ph (02) 9645 7600 - Fax (02) 9645 7699
Email: warranty@coastrv.com.au
Web: www.coastrv.com.au

Coast to Coast RV Services
PO Box 58-054, Botany AUCKLAND 2163
NEW ZEALAND
Ph (09) 274 8700 – Fax (09) 274 8701
Email: enquiry@coastrv.co.nz
Web: www.coastrv.co.nz

Warranty Against Defects

1 WHAT THIS WARRANTY RELATES TO

- 1.1 This warranty covers goods supplied by Coast RV Pty Ltd T/A Coast to Coast RV Services ("Supplier") to the Client ("Goods") and relates to any defects in materials and workmanship under normal use and maintenance ("Defect").

2 WHAT THE SUPPLIER WILL DO TO HONOUR THE WARRANTY

- 2.1 The Supplier will:
- (i) replace or repair the Goods or the defective part of the Goods free of charge;
 - (ii) arrange for the Goods or the defective part of the Goods to be repaired or replaced by a qualified repairer free of charge.
- 2.2 The Supplier reserves the right to replace defective parts of the Goods with parts and components of similar quality, grade or composition where an identical part or component is not available.
- 2.3 Goods presented for repair may be replaced by refurbished goods of the same type rather than being repaired. Refurbished parts may be used to repair the goods.

3 WHAT THE CLIENT MUST DO TO CLAIM THE WARRANTY

- 3.1 To claim the benefit of the warranty, the Client will need to (sequentially):
- (i) first contact the Supplier; and
 - (ii) present the defective Goods to the Supplier for inspection, including inspection for defective workmanship, or otherwise provide evidence of the claimed Defect, accompanied by evidence of proof of purchase and date of delivery, and if applicable, evidence of maintenance performed in accordance with the relevant maintenance schedules.
- 3.2 The claim listed in clause 3.1 may be made in person, or the claim may be sent to the address listed on this form, including the particulars required under clauses 3.1(i) and 3.1(ii).
- 3.3 The appropriate form for making a claim for warranty is as attached.

4 DURATION OF WARRANTY

- 4.1 This warranty will cease:
- (i) where the Goods are purchased already fitted in or as a component of a vehicle or RV: from the date that is twelve (12) months after the Client takes delivery of the vehicle or RV; and
 - (ii) where the Goods are purchased separately or as an after-market item: from the date that is twelve (12) months from the date of purchase..
- 4.2 If a Defect does not materialise in the Goods prior to the date provided in clause 4.1, the Supplier will have no liability to the Client under this warranty.

5 RESPONSIBILITY FOR COSTS OF CLAIM UNDER THIS WARRANTY

- 5.1 The Supplier is responsible for the costs directly associated with repairing or replacing the Goods in accordance with clause 2.1 only.
- 5.2 Any works required to be completed in addition to fixing the Defect are the responsibility of the Client. Additional works includes any costs associated with any testing or repair of the Goods or any goods to which they are fitted, undertaken by a third party in relation to any defect without prior authorisation from the Supplier.
- 5.3 Where it is determined that the Goods do not have a Defect, the Client will be charged a GST exclusive inspection fee of forty-five dollars (\$45.00AUD in Australia or \$45.00NZD in New Zealand) plus freight costs for the return of the Goods, this is subject to change without notice.
- 5.4 The cost of delivery and insurance of the Goods to and from the Supplier, travel costs to and from the Supplier, and the cost of inspecting and testing the Goods are the sole responsibility of the Client.

6 WARRANTY LIMITATIONS

- 6.1 The Supplier makes no warranties or representations other than those set out in this warranty document except as is required by law.
- 6.2 The Supplier will not be liable under this warranty:-
- (i) to the Client or any other person for any consequential, direct or indirect loss, damage or costs incurred or suffered by the Client or any other person, including but not limited to damage to persons, other property, loss of turnover, loss of profits, loss of business or goodwill;
 - (ii) to the Client for transportation or travel costs which are the Client's responsibility;
 - (iii) for damage or defects in any Goods caused by improper transportation, storage or any other misuse, neglect or accident.
 - (iv) for the installation of the Goods. Any fault or defect due to installation should be referred to the installer. The Goods must be installed in accordance with the Manufacturer's instructions and any relevant legislation or code.
- 6.3 This warranty covers the Client only and it is not transferrable if the Goods are sold by the Client during the warranty period.

7 WARRANTY EXCLUSIONS

- 7.1 This warranty will not apply where:
- (i) the Goods have been improperly modified or repaired or the Good's defect has arisen due to the Client's failure to properly install, fit, maintain, service or use the Goods in accordance with the specifications and instructions provided by the Manufacturer, including a failure to comply with the relevant maintenance schedule (where applicable);
 - (ii) the Supplier cannot establish any Defect in the Goods after testing;
 - (iii) the Goods have been used other than for the purpose for which they were designed;
 - (iv) the Goods have been subject to abnormal conditions, including but not limited to temperature, pressure, stress, load or similar;
 - (v) the Client or installer have used or fitted non-genuine or non-approved parts and accessories to the Goods or have failed to use recommended parts and accessories;
 - (vi) the Good's defect has arisen due to abuse, misuse, neglect or accident;
 - (vii) the Goods have not been installed in accordance with the relevant instructions;
 - (viii) the Good's defect is caused by use or fair wear and tear of the Goods (or expendable parts).

8 RIGHTS AT LAW

- 8.1 The benefits given to the Client under this warranty are in addition to other rights and remedies of the Client at law in relation to the Goods.
- 8.2 In Australia our Goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the Goods repaired or replaced if the Goods fail to be of acceptable quality and the failure does not amount to a major failure.

WARRANTY CLAIM FORM

Warranty Providers Name:

Coast RV Pty Ltd trading as Coast to Coast RV Services

ABN 49 097 104 492 - ACN 101 461 330

Warranty Providers Address:

PO Box 415 Regents Park NSW 2143 Australia OR;

PO Box 58-054 Botany AUCKLAND 2163 New Zealand

Client:

Contact No.

Description of Goods provided:

Receipt enclosed: (*tick box*)

☐

Yes

☐

No

Receipt No:

Description of defects (Give as much detail as possible. Use a separate page if required):

Date of purchase/services provided:

I hereby declare that the information provided above is true and correct and to the best of my knowledge and belief and I have complied with all the conditions of the warranty.

Signed:.....

Name:.....
(*please print*)

Dated:.....

[**Please note**, the issue or completion of this form by the Client does not constitute an admission of liability by the Supplier]



Airxcel, Inc.
RV Products Division
P.O. Box 4020
Wichita, KS 67204



This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.