

370W RIGID SOLAR PANEL

MODEL: GS-M120-370-FAB1

USER MANUAL



* Product picture for reference only

Thank you for purchasing this product. Before operating or installing, please read these instructions carefully. This instruction manual contains information for safe use, installation and maintenance of the product.

Please keep this instruction manual in a safe place for future reference. This will ensure safe use and reduce the risk of injury. Be sure to pass on this manual to new owners of this product.

The manufacturer does not accept responsibility for any damages due to not observing these instructions.

CONTENTS

- CONTENTS..... 2
- EXPLANATION OF SYMBOLS..... 3
- PURPOSE OF THIS GUIDE..... 3
- SAFETY PRECAUTIONS 4
 - General Safety Precautions..... 4
 - Safety Precautions When Installing a Solar Photovoltaic System..... 5
- MECHANICAL INSTALLATION 5
 - General Installation Notes..... 5
 - Selecting the Mounting Location..... 5
 - Selecting the Proper Mounting Structure and Hardware..... 6
 - Mounting Methods..... 6
 - Secure the Solar Panel to the RV Roof..... 7
- ELECTRICAL CONNECTION..... 7
- SHUTTING DOWN THE SYSTEM..... 8
- MAINTENANCE..... 9
 - Maintaining Solar Panel 9
 - Long Term RV Storage 9
- SPECIFICATIONS..... 10

EXPLANATION OF SYMBOLS

This manual has safety information and instructions to help eliminate or reduce the risk of accidents and injuries. Always respect the safety warnings identified by the following symbols. The following safety phrases indicate the degree of risk of injury or property damage.

⚠ WARNING: Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

⚠ CAUTION: Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate personal injury, or property damage.

⚠ DANGER: Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.

PURPOSE OF THIS GUIDE

Please carefully read the following installation and safety instructions. Non-compliance with these instructions may void the module warranty.

This guide contains information regarding the installation and safe handling of photovoltaic modules. All instructions must be read and understood before attempting installation. If there are any questions, please contact your dealer for further information.

The installer should conform to all safety precautions in the guide when installing modules. Before installing a solar photovoltaic system, the installer should become familiar with the mechanical and electrical requirements for photovoltaic systems. Keep this guide in a safe place for future reference.

Please carefully read the following installation and safety instructions. Non-compliance with these instructions may void the module warranty.

This guide contains information regarding the installation and safe handling of photovoltaic modules. All instructions must be read and understood before attempting installation. If there are any questions, please contact your dealer for further information.

The installer should conform to all safety precautions in the guide when installing modules. Before installing a solar photovoltaic system, the installer should become familiar with the mechanical and electrical requirements for photovoltaic systems. Keep this guide in a safe place for future reference.

SAFETY PRECAUTIONS

General Safety Precautions

- The installation of solar photovoltaic systems requires specialized skills and knowledge. The installer assumes all risk of injury, including risk of electric shock. Module installation should be performed only by qualified persons.
- All modules come with a permanently attached junction box and 14 AWG PV cable terminated in PV connectors. Your dealer can provide additional extension cables to simplify module wiring.
- Exercise caution when wiring or handling modules exposed to sunlight.
- Do not connect or disconnect wires attached to photovoltaic modules when modules are exposed to sunlight, otherwise an electric arc may occur. Arcs can cause burns, fires or other safety problems. Always exercise caution when connecting and disconnecting wiring on modules.
- Photovoltaic solar modules convert light energy to direct-current electrical energy and are designed for outdoor use. Proper design of support structures is the responsibility of the system designer and installer.
- Modules may be ground mounted, pole mounted, or mounted on rooftops.
- Do not attempt to disassemble the module, and do not remove any attached nameplates or components. Doing so will void the warranty.
- Do not apply paint or adhesive to the module.
- Do not use mirrors or other hardware to artificially concentrate sunlight on the module.
- When installing modules, observe all applicable local, regional and national codes & regulations. Obtain a building and/or electrical permit when required.
- These solar modules are not rated for grid-tied solar systems, they are meant solely for off-grid solar systems.

Work Safely

- Wear protective eye wear and appropriate clothing during installation. Use extreme caution when working with electricity and when working around batteries. Use properly insulated tools only.
- Use care when working on an RV roof, always use rated safety harnesses and ladders during installation and maintenance.

Safety Precautions When Installing a Solar Photovoltaic System

- Solar modules produce electrical energy when exposed to sunlight.
- Keep children well away from the system while transporting and installing mechanical and electrical components.
- Completely cover all modules with an opaque material during installation to prevent electricity from being generated.
- Do not wear metallic rings, watches, or other metallic devices while installing or troubleshooting photovoltaic systems.
- Use appropriate safety equipment (insulated tools, insulating gloves, etc.) approved for use on electrical installations.
- Observe the instructions and safety precautions for all other components used in the system, including wiring and cables, connectors, DC-breakers, mounting hardware, inverters, etc.
- Use only equipment, connectors, wiring and mounting hardware suitable for use in a photovoltaic system.
- Always use the same type of module within a particular photovoltaic system.
- Under normal operating conditions, PV modules will produce currents and voltages that are different than those listed in the data sheet. Data sheet values are applicable at standard test conditions only.
- Short-circuit current and open-circuit voltages should be multiplied by a factor of 1.25 when determining component voltage ratings, conductor ampacity, fuse sizes and size of controls connected to the module or system output.

MECHANICAL INSTALLATION

General Installation Notes

- Drainage holes must not be covered with parts of the mounting system. The junction box has a breather port which must be mounted facing downward and cannot be exposed to the rain. The junction box should be on the higher side of the module when it is mounted in order to orient the breather port correctly.
- Do not lift the module by grasping the module's junction box or electrical leads.
- Do not stand or step on the module.
- Do not drop the module or allow objects to fall on the module.
- Do not place any heavy objects on the module.
- Inappropriate transport and installation may damage the module's glass or frame.

Selecting the Mounting Location

- Select a suitable location for the installation of the module.
- The module should be installed to reduce the amount of shading.
- Modules should be mounted as far away from rooftop obstructions (AC units, plumbing vents, skylights, etc.) as possible.
- If solar panels must be installed near rooftop obstructions, try to orient the modules with broadside facing the obstruction. This orientation will optimize the high by-pass diodes in shaded conditions.
- When possible, mount solar panels so that the majority of surfaces can be oriented south facing if roof is positioned accordingly.

Selecting the Proper Mounting Structure and Hardware

- Observe all instructions and safety precautions included with the mounting system to be used with the module.
- Do not drill holes in the glass surface of the module. Doing so will void the warranty.
- Do not drill additional mounting holes in the module frame. Doing so will void the warranty.
- Modules must be securely attached to the mounting structure using six mounting points for normal installation.
- Load calculations are the responsibility of the system designer or installer. The mounting structure and hardware must be made of durable, corrosion-and UV-resistant materials.
- Select mounting location such that screw holes on the mounting brackets attached to the solar panel frame are aligned with the structural framing of the roof.

Mounting Methods


- The module mounting structure must be made of durable, corrosion-resistant and UV- resistant materials. A Furrion brand Mounting Kit is recommended, Furrion model number C-FSFP37MW-A01.
- In regions with heavy snowfall in winter, select the height of the mounting system so that the lowest edge of the module is not covered by snow for any length of time. In addition, ensure that the lowest portion of the module is placed high enough so that it is not shaded by plants or trees or damaged by flying sand.
- Modules must be securely attached to the mounting structure.
- Provide adequate ventilation under the modules in conformity to your local regulations. A minimum distance of 4" (100mm) between the roof plane and the

frame of the module is generally recommended.

- Always observe the instructions and safety precautions included with the module support frames.
- Before installing modules on a roof, ensure that the roof construction is suitable. In addition, any roof penetration required to mount the module must be properly sealed to prevent leaks.
- Observe the linear thermal expansion of the module frames [the recommended minimum distance between two modules is $\frac{7}{16}$ " (10mm)].
- Always keep the back-sheet of the panel free from foreign objects or structural elements, which could come into contact with the panel, especially when the panel is under mechanical load.
- Ensure panels are not subjected to wind or snow loads exceeding the maximum permissible loads (176lbs/80kg), and are not subject to excessive forces due to the thermal expansion of the support structures.

Secure the Solar Panel to the RV Roof

1. Mount the solar panel through the such that at least 4 of the mounting feet have screws penetrating the metal or wooden framing trusses. For fixed mounting, the points should be installed with M8*25 bolts and nuts in the frame on the long side of the panel, as shown below:




ELECTRICAL CONNECTION

To power the Solar Photovoltaic System properly, the following Furrion components are also required except the solar panel. Please contact Furrion authorized dealer to purchase the product(s) as required and refer to the individual instruction manual that comes with the product to set up the system.

Furrion Model#	Description
C-FSFP37MW-A01	Mounting Bracket
C-FSEB30JWL-BL-004	MC4 to Furrion Connector Adapter
FSCC30PW-BL/FSCC60PW-BL	MPPT Solar Charge Controller

C-FSCC60PW-A01/C-FSCC60PW-A02	Temperature Sensor
FSEB30JWO-BL	Rooftop Solar Electrical Box
FBF12A100E	LiFePo4 Battery Pack



System Connection Diagram

- ⚠ WARNING:** Electrical shock hazard! Do not touch bare conductors or other potentially energized parts.
- Any hardware used must be compatible with the mounting structure material to avoid galvanic corrosion.
 - It is not recommended to use modules with different configurations (grounding, wiring) in the same system.
 - The current, voltage, and power characteristics of the solar panel(s) will vary based on environmental criteria including temperature and solar irradiance.
 - To prevent cables and connectors from overheating, the cross section of the cables and the capacity of the connectors must be selected to suit the maximum system short circuit current (the gauge of system cables is determined by the system designer or installer.).

SHUTTING DOWN THE SYSTEM

- Completely cover system modules with an opaque material to prevent electricity from being generated while disconnecting connectors.
- Disconnect system from all power sources in accordance with instructions for all other components used in the system.

The system should now be out of operation and can be dismantled. In doing so, observe all the safety instructions as applicable to installation.

MAINTENANCE

Maintaining Solar Panel

To ensure optimum module performance, the following maintenance measures are recommended:

- Clean the glass surface of the solar panel when required. Always use clean water and a soft sponge or cloth for cleaning. A mild, non-abrasive cleaning agent may be used to remove stubborn dirt. Do not use cold water to clean panel if the surface is extremity hot as rapid temperature change could lead to cracking.
- Clean solar panel more frequently during drier months, as they may become covered in dust more quickly. A pressure washer is not recommended.
- Check the electrical, grounding and mechanical connections every six months to verify that they are clean, secure, undamaged and free of corrosion.
- Remove snow, ice, or other debris when build up occurs.
- Caution: Observe the maintenance instructions for all components used in the system, such as support frames, PV connectors, charge controller, inverter, batteries, etc.

Long Term RV Storage

If your RV will be stored in extremely cold climates you may need to remove your batteries to prevent them from freezing. Please note if your solar panel(s) are covered by snow they will not produce power and can not be depended upon to keep the batteries charged. For battery storage in mild climates solar system will provide more power provided sufficient sunlight and limited load. Make sure that all passive/phantom loads are removed from the batteries, i.e. DVD players, clock radio, etc. to make sure the solar panel(s) can keep the batteries charged even with reduced sun exposure.

SPECIFICATIONS

This solar modules are made of monocrystalline solar cells in series with high efficiency, high transmission rate, low iron tempered glass, anti-aging EVA, high flame resistant TPT laminate, and anodized aluminum alloy frames. They are designed for easy installation, extended longevity, and resistance to damage incurred by high wind or hail.

Specifications	
Output cable	14 AWG PV Cable
Connectors	Standard MC-4 Connectors
Junction box	IP68 Rated
Bypass diode	Schottky Barrier Rectifiers Diode
Construction	Front: high transmission rate and low iron tempered glass ⅛" (3.2mm) Back: TPT Encapsulation material: EVA
Frame	Black Anodized Aluminum
Dimension (W x H x D)	40⅞x 69⅞ x 1⅞" (1038 x 1755 x 35mm)
Weight	40.2lbs (20.5kg)
Cable Length	47¼" / 1200mm
Solar cell	120 pieces monocrystalline silicon solar cell
Max Power (Pmax)	370W
Operating Voltage (Vmp)	34.2V
Operating Current (Imp)	10.82A
Open-Circuit Voltage (Voc)	41.0V
Short-Circuit Current (Isc)	11.42A
Output Tolerance	±5%
Max Series Fuse Rating	20A
Module Efficiency	20.31%
Temperature Coefficient of Voc	-0.30%/°C
Temperature Coefficient of Isc	+0.05%/°C
Temperature Coefficient of Pmax	-0.39%/°C
Operating Temperature	-40°F to +185°F (-40°C to +85°C)

NOTE: All technical data at standard test condition (E=1000W/m² TC=25°C AM=1.5)



The contents of this manual are proprietary and copyright protected by Lippert. Lippert prohibits the copying or dissemination of portions of this manual unless prior written consent for an authorized Lippert representation has been provided. Any unauthorized use shall void any applicable warranty. The information contained in this manual is subject to change without notice and at the sole discretion of Lippert. Revised editions are available for free download from lippert.com.

Please recycle all obsolete materials.

For all concerns or questions, please contact Lippert
Ph: 432-LIPPERT (432-547-7378) | Web: lippert.com | E-mail:
customerservice@lci1.com



This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.