


Before adjusting, check the standoff brackets with the room extended 6" into the out position.



2

Retract the Room.

The room must be completely in the in position to transfer the slack in the cables and chain.

3

Loosen the interior top cable (Figure 1)

Loosen until you can see the slack in the cable.

4

Tighten the interior bottom cable (Figure 2)

Tighten until the cable can be pulled up and pushed down 1/4" with your thumb and index finger.

5

Tighten the interior top cable (Figure 1).

Tighten until the cable can be pulled up and pushed down 1/2" with your thumb and index finger.

Left (from interior) Cable Routing




Figure 1



Figure 2



Right (from interior) Cable Routing




Figure 3




Coupler
Washer

In the event there is still slack in the cable or chain with the above adjustment, it may be necessary to add a shim with additional washers between the existing washer and coupler. **(Figure 3)**

Left (from interior) Cable Routing Retracted

Retracting the room to the in position, pulls the chain towards the motor. The slack in the chain will be on the same side that the interior bottom cable connects to.





This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.