



MMS-E Series Inverters/Chargers



Owner's Manual

Disclaimer of Liability

The use of this manual and the conditions or methods of installation, operation, use, and maintenance of the MMS-E Series inverter/charger are beyond the control of Magnum Energy, Inc. Therefore, this company assumes no responsibility and expressly disclaims any liability for loss, damage, or expense whether direct, indirect, consequential, or incidental that may arise out of or be in any way connected with such installation, operation, use, or maintenance.

Due to continuous improvements and product updates, the images shown in this manual may not exactly match the unit purchased.

Restrictions on Use

The MMS-E Series inverter/charger may only be used in life-support devices or systems with the express written approval of Magnum Energy. Failure of the MMS-E Series inverter/charger can reasonably be expected to cause the failure of that life-support device or system, or to affect the safety or effectiveness of that device or system. If the MMS-E Series inverter/charger fails, it is reasonable to assume that the health of the user or other persons may be endangered.

Contact Information

Magnum Energy, Inc.
2211 West Casino Rd.
Everett, WA 98204
Phone: +011-425-353-8833
Fax: +011-425-353-8390
Web: www.magnumenergy.com

Record the unit's model and serial number in case you need to provide this information in the future. It is much easier to record this information now, instead of trying to gather it after the unit has been installed.

Model:	Serial Number:
☐ MMS912E	AK

Conventions Used in this Manual

Terminology

Shore power or External AC power - refers to alternating current (AC) provided by the utility electric power grid or from a generator.

Mobile application - refers to inverters used in a caravan, boat, or a truck installation.

Safety Symbols

To reduce the risk of electrical shock, fire or other safety hazard, the following safety symbols have been placed throughout this manual to indicate dangerous and important safety instructions.



WARNING: This symbol indicates that failure to take a specified action could result in physical harm to the user.



CAUTION: This symbol indicates that failure to take a specified action could result in damage to the equipment.



Info: This symbol indicates information that emphasizes or supplements important points of the main text.

IMPORTANT PRODUCT SAFETY INSTRUCTIONS

This manual contains important safety instructions that must be followed during the installation and operation of this product. Read all instructions and safety information contained in this manual before installing or using this product.

- All electrical work must be performed in accordance with local, state, and federal electrical codes.
- This product is designed for indoor/compartment installation. DO NOT expose to rain, snow, moisture, or liquids of any type.
- Use insulated tools to reduce the chance of electrical shock or accidental short circuits.
- Remove all jewelry such as rings, watches, bracelets, etc., when installing or performing maintenance on the inverter.
- Always disconnect the batteries or energy source prior to installing or performing maintenance on the inverter. Live power may be present at more than one point since an inverter utilizes both batteries and AC. Turning off the inverter may not reduce this risk. As long as AC power is connected, it will pass through the inverter regardless of the ON/OFF power switch setting.
- Always verify proper wiring prior to starting the inverter.
- Do not operate the inverter if it has been damaged.
- Do not dismantle the inverter; there are no user-serviceable parts contained in this product. Attempting to service the unit yourself could cause electrical shock. Internal capacitors remain charged after all power is disconnected.
- No AC or DC disconnects are provided as an integral part of this inverter. Both AC and DC disconnects must be provided as part of the system installation.

- Overcurrent protection for the battery supply is not provided as an integral part of this inverter. Overcurrent protection of the battery cables must be provided as part of the installation.
- Overcurrent protection for the AC output wiring is not provided as an integral part of this inverter. Overcurrent protection of the AC output wiring must be provided as part of the installation.

IMPORTANT BATTERY SAFETY INSTRUCTIONS

- Wear eye protection (safety glasses) when working with batteries.
- Remove all jewelry such as rings, watches, bracelets, etc., when installing or performing maintenance on the inverter.
- Never work alone. Always have someone near you when working around batteries.
- Use proper lifting techniques when working with batteries.
- Never use old or untested batteries. Check each battery's label for age, type, and date code to ensure all batteries are identical.
- Batteries are sensitive to changes in temperature. Always install batteries in a stable environment.
- Install batteries in a well ventilated area. Batteries can produce explosive gasses. For compartment or enclosure installations, always vent batteries to the outside.
- Provide at least one inch of air space between batteries to provide optimum cooling.
- Never smoke when in the vicinity of batteries.
- To prevent a spark at the battery and reduce the chance of explosion, always connect the cables to the batteries first. Then connect the cables to the inverter.
- Use insulated tools at all times.
- Always verify proper polarity and voltage before connecting the batteries to the inverter.
- To reduce the chance of fire or explosion, do not short-circuit the batteries.
- In the event of accidental exposure to battery acid, wash thoroughly with soap and water. In the event of exposure to the eyes, flood them for at least 15 minutes with running water and seek immediate medical attention.
- Recycle old batteries.

SAVE ALL INSTRUCTIONS

Table of Contents

1.0 Introduction	1
1.1 MMS-E Series Models	1
1.2 How an Inverter/Charger Works	1
1.3 Inverter Applications for Mobile Installations	2
1.4 Advantages of Pure Sine Wave vs Modified Sine Wave	2
1.5 Appliances and Run Time	2
1.6 Standard Features and Benefits	3
1.6.1 Battery Temperature Sensor	6
2.0 Installation.....	7
2.1 Pre-Installation	7
2.2 Unpacking and Inspection.....	7
2.3 Locating and Mounting the Inverter	9
2.4 Wiring Guidelines	12
2.5 DC Wiring	12
2.5.1 DC Wire Sizing.....	12
2.5.2 DC Overcurrent Protection.....	14
2.5.3 DC Grounding.....	14
2.5.4 DC Cable Connections.....	15
2.6 Battery Bank Wiring	16
2.7 Inverter to Battery Bank Wiring.....	16
2.7.1 DC Ground Wire.....	17
2.7.2 DC Negative Wire.....	17
2.7.3 Battery Temperature Sensor	17
2.7.4 DC Positive Wire	17
2.8 AC Wiring.....	18
2.8.1 Neutral to Safety Ground Bonding	18
2.8.2 AC Wiring Connections.....	18
2.8.3 AC Wire Size and Overcurrent Protection	19
2.8.4 AC Input Wiring	20
2.8.5 AC Output Wiring	21
2.9 Functional Test.....	22

Table of Contents (cont.)

3.0 Operation	24
3.1 Operating Modes	24
3.1.1 Inverter Mode.....	24
3.1.2 Standby Mode	25
3.2 Protection Circuitry Operation	29
3.3 Inverter Start-up.....	30
3.4 Factory Default Settings	31
4.0 Maintenance and Troubleshooting	33
4.1 Recommended Inverter and Battery Care	33
4.2 Caravan/Marine Off-Season Storage.....	33
4.3 Resetting the Inverter.....	34
4.4 Troubleshooting	35
5.0 Specifications	36
Appendix A - Optional Equipment and Accessories	37
Appendix B - Wiring Color Codes for Eur. & US/Canada.....	38
Appendix C - Battery Information.....	39
C1 Battery Bank Sizing	39
C2 Battery Types	39
C3 Battery Configuration.....	39
C3.1 Series Wiring.....	39
C3.2 Parallel Wiring	40
C3.3 Series-Parallel Wiring	40
Appendix D - Warranty/Service Information	42
D1 Limited Warranty	42
D2 How to Receive Repair Service	43

List of Figures

Figure 1-1, MMS-912E Model Inverter/Charger	1
Figure 1-2, Top and Left Side Features	4
Figure 1-3, Front and Back Side Features.....	5
Figure 1-4, Battery Temperature Sensor (BTS)	6
Figure 2-1, MMS-912E Model Basic Installation Diagram	8
Figure 2-2, Approved Mounting Orientations.....	11
Figure 2-3, MMS-912E Model Inverter/Charger Dimensions	11
Figure 2-4, DC Cable to Battery Terminals.....	15
Figure 2-5, DC Cable to Inverter's DC Terminals	15
Figure 2-6, AC Wiring Connections.....	21
Figure 3-1, Automatic 4-Stage Charging Graph.....	27
Figure 3-2, BTS Temperature to Charge Voltage Change	28
Figure 4-1, Resetting the Inverter.....	34
Figure C3-1, Series Battery Wiring	39
Figure C3-2, Parallel Battery Wiring	40
Figure C3-3, Series-Parallel Battery Wiring	40
Figure C3-4, Battery Bank Wiring Examples (12-volt)	41

List of Tables

Table 2-1, Recommended DC Wire/Overcurrent Device	13
Table 2-2, DC Wire Size for Increased Distance.....	14
Table 2-3, Wire Color to AC Wire Connection	19
Table 2-4, Minimum Wire Size to Circuit Breaker Size	20
Table 3-1, Inverter Battery Turn On/Off Levels.....	30
Table 3-2, Inverter/Charger Default Settings	32
Table 4-1, Troubleshooting Guide	35
Table 5-1, MMS-E Series Specifications	36
Table B-1, AC Wiring Color Codes	38
Table B-2, DC Wiring Color Codes	38

1.0 Introduction

Congratulations on your purchase of an MMS-E Series inverter/charger from Magnum Energy, Inc. This product is designed especially for your mobile application. Powerful, yet simple to use, this product will provide you with years of trouble-free use.

1.1 MMS-E Series Model

MMS912E - a 900 watt inverter/charger with 20 amp AC transfer capability and a 40 amp/12 VDC, 4-stage Power Factor Correction (PFC) charger. The AC input and output are provided with pigtail wires to allow hardwiring to a main AC distribution panel and to an inverter sub-panel. Features isolated input/output neutrals for mobile applications. Includes a Battery Temperature Sensor (BTS) with a 15' cable extension.



Figure 1-1, MMS912E Model Inverter/Charger

1.2 How an Inverter/Charger Works

An inverter takes direct current (DC) from your batteries and turns it into alternating current (AC), like you use at home. With the MMS-E Series model, it also takes alternating current (when connected to a generator or to shore power) and transforms it into direct current to recharge your batteries.

The two modes of operation associated with this inverter/charger are referred to in this document as:

Inverter Mode: DC from the batteries is transformed into pure sine wave AC for powering your mobile applications.

Standby Mode: The unit operates as a battery charger to convert incoming AC power into DC power to recharge the batteries while continuing to pass the incoming AC power directly to the inverter's output – to power any AC loads.

1.0 Introduction

1.3 Inverter Applications for Mobile Installations

Inverters can be used to provide power in mobile situations, such as in a caravan, truck, or boat. In these applications the inverter provides power to the AC loads using the energy stored in the batteries, and recharges the batteries when shore power or an onboard generator is available.

1.4 Advantages of a Pure Sine Wave vs Modified Sine Wave Inverter

Today's inverters come in two basic output waveforms: modified sine wave (which is actually a modified square wave) and pure sine wave.

Modified sine wave inverters approximate a pure sine waveform and will run most appliances and electronics without any problems. These inverters are less expensive, and therefore offer a viable alternative to more expensive pure sine wave inverters.

The output of a pure sine wave inverter is equal to or, in many cases, better than the shore power used in your home. Virtually any electronic device will operate from a pure sine wave inverter. Motors run cooler, microwaves usually cook faster, and clocks keep better time just to name a few examples. Without compromising quality or performance, the MagnaSine provides you with all of the advantages of a pure sine wave inverter at a much lower cost than many on the market.

1.5 Appliances and Run Time

The MMS-E Series inverter/charger can power a wide range of household appliances. As with any appliance using batteries for power, there is a certain length of time that it can run – this is called “run time”. Actual run time depends on several variables including: the size and the type of appliance, the type of batteries installed in your application, as well as the battery's capacity and age. Other factors such as the battery's state of charge and temperature can also affect the length of time your appliances can run.

Depending on your inverter capacity, larger electrical appliances such as coffee pots and hair dryers can be used for short durations. However, loads that are used for longer periods such as stoves or water heaters can quickly drain your batteries and are not recommended for inverter applications.

All electrical appliances are rated by the amount of power they consume. The rating is printed on the product's nameplate label, usually located on its chassis near the AC power cord. Even though it is difficult to calculate exactly how long an inverter will run a particular appliance, the best advice is trial and error. Your MMS-E Series inverter/charger has a built-in safeguard that automatically protects your batteries from being over-discharged.

1.6 Standard Features and Benefits

The MMS-E Series inverter/charger converts 12 volts of direct current (VDC) power from your battery to 230 volts alternating current (VAC) power. The multi-stage battery charger optimizes incoming AC power using power factor correction (PFC) technology to keep the inverter's battery bank fully charged. This inverter is designed to allow easy installation and use, and with its die-cast aluminum baseplate it ensures maximum durability and cooler, more efficient operation.

The inverter/charger provides the following:

- 900 watts continuous at 25°C
- numerous protection features to provide a safe and peace-of-mind operation
- AC transfer switch circuitry; allowing incoming AC power to continue to pass-thru to power loads even if the inverter is off
- dead battery charging for batteries that are extremely low
- automatic 4-stage battery charger with power factor correction and temperature compensation – for optimum battery charging (using the temperature sensor)
- modern and aesthetically pleasing design with a large AC wiring compartment (provides easy access to AC wiring for simple and quick connections) and 360° DC connection terminals with color coded insulating covers
- true RMS output voltage regulation to ensure the inverter will deliver the correct amount of power – within the DC input voltage range and the continuous output power level
- quick connection accessory and remote ports – easily accepts several optional remote controls and the Battery Temperature Sensor

The MMS-E Series inverter/chargers are equipped with the following features (see Figures 1-2 & 1-3):

- 1 Inverter Status Indicator** - this green LED illuminates to provide information on the inverter's operation.
- 2 Power Switch** - a momentary pushbutton switch that turns the inverter on or off.
- 3 Negative DC Terminal (black)** - the inverter's connection to the negative terminal on the battery bank.

1.0 Introduction




Figure 1-2, Top and Left Side Features

- 4 Positive DC Terminal (red)** - the inverter's connection to the positive terminal on the battery bank.
- 5 Input Circuit Breaker** - this circuit breaker protects the unit's internal wiring and pass-thru relay.
- 6 Output Circuit Breaker** - this circuit breaker provides another layer of overload protection. This is **not** a branch circuit-rated breaker. Separate AC output breakers may be required on the output.
- 7 Mounting Flanges (x4)** - secures the inverter to shelf/wall.
- 8 AC Wiring Compartment** - provides access for all AC input and output connections on the inverter.
- 9 AC Output Connection** - AC knockout for hardwiring AC output.
- 10 AC Input Connection** - a strain relief clamp for hardwiring AC input.
- 11 DC Ground Terminal** - this connection is used to tie the exposed chassis of the inverter to the DC grounding system. This terminal accepts CU/AL conductors from 2.08 mm² to 13.29 mm² (#14 AWG to #6 AWG).




Figure 1-3, Front and Back Side Features

- 12** **Warning and Information Label** - provides pertinent information for safely using the inverter.
- 13** **REMOTE Port Connection** - a RJ11 connector that allows an optional remote control to be connected.
- 14** **ACCESSORY PORT Connection** - a RJ11 connector to allow the Battery Temperature Sensor (BTS) or MMS-E accessories (e.g., MM-DCLD, MM-ISA) to be connected.
- 15** **Intake Vent** - ventilation openings to pull in air to keep the inverter cool for peak performance.
- 16** **Exhaust Vent** - ventilation openings that allow heated air to be removed by the internal cooling fan.
- 17** **Model/Serial Number Label** - includes the model/serial number and provides specifications and information on the inverter and charger. See the MMS-E Series Specifications on page 36 for more information.

1.0 Introduction

1.6.1 Battery Temperature Sensor

A plug-in external Battery Temperature Sensor (BTS) is provided with the battery charger feature. When installed, the BTS automatically adjusts the battery charger's bulk, absorb, and float voltage set points (based on temperature) for better charging performance and longer battery life. If the temperature sensor is NOT installed and the batteries are subjected to large temperature changes, battery life may be shortened.




Figure 1-4, Battery Temperature Sensor (BTS)

2.0 Installation

2.1 Pre-Installation

Before installing the inverter, read the entire Installation section. The more thorough you plan in the beginning, the better your inverter needs will be met.



WARNING: Installations should be performed by qualified personnel, such as a licensed or certified electrician. It is the installer's responsibility to determine which safety codes apply and to ensure that all applicable installation requirements are followed. Applicable installation codes vary depending on the specific location and the type of installation.



Info: Review the Important Product Safety Instructions on page ii and the Important Battery Safety Instructions on page iii before any installation.

The basic system diagram shown in Figure 2-1 should be reviewed to assist you in planning and designing your installation.

2.2 Unpacking and Inspection

Carefully remove the MMS-E Series inverter/charger from its shipping container and inspect all contents. Verify the following items are included:

- MMS-E Series inverter/charger
- Red and black DC terminal covers
- AC access cover with two screws
- Two 1/2" hex-head Kep nuts (installed on the DC terminals)
- Battery Temperature Sensor (BTS)
- MMS-E Series Owner's Manual

If items appear to be missing or damaged, contact your authorized Magnum Energy dealer or Magnum Energy, Inc.

If at all possible, keep your shipping box. It will help protect your inverter from damage if it ever needs to be returned for service.

Save your proof-of-purchase as a record of your ownership; it will also be needed if the unit should require in-warranty service.

Record the unit's model and serial number in the front of this manual in case you need to provide this information in the future. It is much easier to record this information now, instead of trying to gather it after the unit has been installed.

2.0 Installation




Figure 2-1, MMS912E Model Basic Installation Diagram

2.3 Locating and Mounting the Inverter



WARNINGS:

- Do not mount the inverter near any flammable or combustible fluid or components
- Provide adequate clearance/ventilation to the inverter
- Mount only on a non-combustible surface
- Maximum ambient temperature around the inverter must not exceed 25° C (77° F) to meet power specifications

The inverter should only be installed in a location that meets the following requirements:

Clean and Dry - The inverter should not be installed in an area that allows dust, fumes, insects, or rodents to enter or block the inverter's ventilation openings. The area also must be free from any risk of condensation, water, or any other liquid that can enter or fall on the inverter. The inverter uses stainless steel fasteners, plated copper busbars, and a powder-coated aluminum base. Also, the internal circuit boards are conformal coated. The above measures are undertaken to help fight the harmful effects of corrosive environments. However, the life of the inverter is uncertain if used in any of these types of environments, and inverter failure under these conditions is not covered under warranty.

Cool - The inverter should be protected from direct exposure to the sun or to any equipment that produces extreme heat. The ambient air temperature should be between 0° C (32° F) and 40° C (104° F); keep in mind that the inverter's output specifications are rated at 25° C (77° F), so the cooler the better within this range.

Ventilated - In order for the inverter to provide full output power and avoid over-temperature fault conditions, do not cover or block the inverter's ventilation openings or install this inverter in an area with limited air flow. Allow as much clearance around the inverter's intake and exhaust ventilation openings as possible, see Items 16 and 17 in Figure 1-3. At the minimum, allow an airspace clearance of 15 cm (6") at the front and back, and 7.5 cm (3") everywhere else to provide adequate ventilation.

If installed in an enclosure, a fresh air intake opening must be provided directly to the front side (intake vent) and an exhaust opening on the back side (exhaust vent) of the inverter. This will allow cool air from the outside to flow into the inverter, and heated air to exit away from the inverter and the enclosure. When mounted in an enclosed compartment, air flow must be at least 59 cfm in order to maintain no more than a 20° C (68° F) rise in compartment temperature. Minimum clearances can be reduced if air flow is increased, but in no case should clearance around the inverter be less than 5 cm (2") on all sides.

2.0 Installation

Safe - Keep any flammable/combustible material (e.g., paper, cloth, plastic, etc.,) that may be ignited by heat, sparks, or flames at a minimum distance of 61 cm (2') away from the inverter.



WARNING: The MMS-E Series inverter/charger is not an ignition-protection rated device and should not be installed in any location that requires ignition-protected equipment. To prevent fire or explosion, do not install the MMS-E in any area with extremely flammable liquids like gasoline or propane; or, in an area that contains connections between components of a fuel system.

Close to the battery bank - As with any inverter, it should be located as close to the batteries as possible. Long DC wires tend to lose efficiency and reduce the overall performance of an inverter. However, the unit should not be installed in the same compartment as the batteries or mounted where it will be exposed to gases produced by the batteries. These gases are corrosive and will damage the inverter. Also, if these gases are not ventilated and allowed to collect, they could ignite and cause an explosion.

Accessible - Do not block access to the inverter's remote control and accessory ports. Also, allow enough room to access the AC and DC wiring connections, as they will need to be checked and tightened periodically. See Figure 2-3 for the MMS-E Series' inverter dimensions.

Mounting orientation - The MMS-E Series inverter/charger should only be mounted on a horizontal surface (shelf or table) or a vertical surface (wall or bulkhead) either right-side up or up-side down, as shown in Figure 2-2. This is to prevent the inverter's vents from facing down. The inverter must be mounted on a non-combustible surface*, and this surface and the mounting hardware must be capable of supporting at least twice the weight of the inverter. After determining your mounting position, either use the base of the inverter's chassis as a template to mark your mounting screw locations, or refer to the physical dimensions as shown in Figure 2-3. Drill pilot holes into the mounting surface, and then mount the unit with the appropriate mounting hardware.


If this unit is used in a mobile application, you may want to place flexible washers or bushings between the mounting surface and the inverter's mounting flanges to reduce vibration.

After the inverter has been properly mounted, proceed to the DC Wiring section.


** Noncombustible surface - A surface made of material that will not ignite, burn, support combustion, or release flammable vapors when subjected to fire or heat. For the most part, these materials are largely comprised of inorganic materials such as stone, steel, iron, brick, tile concrete, slate and glass. Common building materials such as gypsum board as well as any paint, wall covering, and certainly wood will not pass.*

2.0 Installation


Wall Mounted (right side up)



Shelf Mounted (right side up)



Wall Mounted (upside down)



Shelf Mounted (upside down)




Figure 2-2, Approved MMS912E Mounting Orientations




Figure 2-3, MMS912E Model Inverter/Charger Dimensions

2.0 Installation

2.4 Wiring Guidelines

- Before connecting any wires, determine all wire routes to and from the inverter throughout the caravan, vehicle, or boat.
- Conductors passing through walls or other structural members must be protected to minimize insulation damage such as chafing, which can be caused by vibration or constant rubbing.
- Always check for existing electrical, plumbing, or other areas of potential damage prior to making cuts in structural surfaces or walls.
- Make sure all wires have a smooth bend radius and do not become kinked.
- Both AC and DC overcurrent protection must be provided as part of the installation.
- Do not attempt to use a vehicle metal frame in place of the negative connection or DC ground. The inverter requires a reliable negative and ground return path directly to the battery.
- DC wires and cables should be tied together with wire ties or electrical tape approximately every 6 inches. This improves the surge capability and reduces the effects of inductance, which improves the inverter waveform and reduces wear on the inverter's filter capacitors.
- Only use copper wires with a minimum temperature rating of 75°C.
- To ensure the maximum performance from the inverter, all connections from the battery bank to the inverter should be minimized. The exceptions are the DC overcurrent disconnect in the positive line.

2.5 DC Wiring

This section describes the MMS-E Series inverter's required DC wire sizes, the recommended disconnect/overcurrent protection, and how to make the DC connections to the inverter and the battery bank.

2.5.1 DC Wire Sizing

It is important to use the correct DC wire to achieve maximum efficiency from the system, and to reduce fire hazards associated with overheating. Refer to Table 2-1 to select the minimum DC wire size needed based on your inverter model. If the distance from the inverter to the battery bank is greater than three feet, use Table 2-2 to help determine the minimum recommended cable sizes for longer distances. Always keep your wire runs as short as practical to help prevent low voltage shutdowns, and to keep the DC breaker from nuisance tripping (or open fuses) because of increased current draw. Undersized cables can also lower the inverter's peak output voltage, as well as reduce its ability to surge heavy loads.



Info: The DC wires must be color coded with colored tape or heat shrink tubing; BROWN for positive (+), BLUE for negative (-), and GREEN w/ YELLOW stripe for DC ground.

The DC wires must have either soldered and crimped lugs, crimped copper compression lugs, or aluminum mechanical lugs. Soldered connections alone are not acceptable for this application.

Table 2-1, Recommended DC Wire/Overcurrent Device

Maximum Continuous Current¹	133 amps
DC Grounding Electrode Wire Size²	13.29 mm ² (#6 AWG)
Minimum DC Wire Size³ (90° C rating in free air)	42.39 mm ² (#1 AWG) [150 amps]
Maximum DC Fuse Size⁴	150 amps w/ time delay



Info: The term “in free air” is defined as not encased in conduit or raceway.

If the inverter is expected to operate at a distance greater than three feet from the battery bank, the DC wire size needs to be increased to overcome the increase in resistance – which affects the performance of the inverter. Continue to use the overcurrent device and the DC ground wire previously determined from Table 2-1, and then refer to Table 2-2 to determine the minimum DC wire size you need for various distances based on your inverter model.

Note 1 - Maximum Continuous Current is based on the inverter's continuous power rating when at the lowest input voltage with an inefficiency factor.

Note 2 - Per standard practice, the DC grounding electrode conductor can be a 13.29 mm² (#6 AWG) conductor if that is the only connection to the grounding electrode and that grounding electrode is either a pipe, rod, or plate electrode.

Note 3 - Wire size is based on the requirements needed to increase efficiency and reduce stress to the inverter.

Note 4 - The next larger standard size overcurrent device may be used if the de-rated cable ampacity falls between the standard overcurrent devices found in the IEC.

2.0 Installation

2.5.2 DC Overcurrent Protection

For safety and to comply with local electrical code regulations, you must install a DC overcurrent protection device in the positive DC cable line to protect your DC cables. This overcurrent device can be a fuse or circuit-breaker, but must be DC rated. It must be correctly sized according to the size of DC cables being used; which means it is required to open before the cable reaches its max. current carrying capability, thereby preventing a fire. See Table 2-1 to select the DC overcurrent device based on the min. wire size for your inverter model.

Table 2-2, DC Wire Size For Increased Distance

Minimum Recommended DC Wire Size (one way)			
≤ 1 m (3 ft or less)	1 m to 1.5 m (3 to 5 ft)	1.5 m to 3 m (5 to 10 ft)	3 m to 4.5 m (10 to 15 ft)
42.39 mm ² (#1 AWG)	53.46 mm ² (#1/0 AWG)	67.40 mm ² (#2/0 AWG)	107.16 mm ² (#4/0 AWG)

Electrical systems in mobile installations typically do not require using a DC disconnect, although an overcurrent protection device is still required. A fuse is usually used as the disconnect device in these installations. These installations also do not normally use conduit, so the fuse must be installed in the ungrounded conductor (usually the positive DC cable line) within 45.72 cm (18") of the battery – to protect the DC wiring system.

If using a fuse, we recommend using a Class-T type or equivalent. This fuse type is rated for DC operation, can handle the high short-circuit currents, and allows for momentary current surges from the inverter without opening.

2.5.3 DC Grounding

The inverter/charger should always be connected to a permanent, grounded wiring system. To reduce the possibility of electric shock, connect the metallic chassis of the various enclosures together to have them at the same voltage potential. For the majority of installations, the inverter chassis and the negative battery conductor are connected to the system's ground bond via a safety-grounding conductor (bare wire or green insulated wire) at only one point in the system. The size for the grounding conductor is usually based on the size of the overcurrent device used in the DC system. Refer to Table 2-1 to select the appropriate DC ground wire based on the overcurrent device used for your inverter model.

If the inverter is in a vehicle, DO NOT connect the battery negative (-) cable to the vehicle's safety ground. Only connect to the inverter's negative battery terminal. If there are any non-factory installed appliances onboard the vehicle, DO NOT ground them at safety ground. Only ground them at the negative bus of the DC load center (as applicable).

2.5.4 DC Cable Connections

When connecting the DC cable to the battery or to the inverter's DC terminals, the hardware should be installed in the correct order to prevent high resistance connections from heating up and possibly melting. Refer to Figures 2-4 and 2-5 to stack the hardware correctly. Tighten the terminal connections from 13.6 to 16.3 N-m.



CAUTION: Do not put anything between the DC cable ring lug and the battery terminal post or the inverter's DC terminal. If antioxidant grease or spray is used, apply after all connections have been made and are properly tightened.



CAUTION: Overtightening or mis-threading nuts on the DC terminals will cause the bolts to strip and snap/break-off.




Figure 2-4, DC Cable to Battery Terminals



CAUTION: The inverter is NOT reverse polarity protected (negative and positive connected backwards). You must verify the correct voltage polarity **BEFORE** connecting the DC wires or damage may occur.

Crimped and sealed copper ring terminal lugs with a 5/16" hole should be used to connect the DC wires to the inverter's DC terminals.




Figure 2-5, DC Cable to Inverter's DC Terminals

2.0 Installation

2.6 Battery Bank Wiring



WARNING: Lethal currents will be present if the positive and negative cables attached to the battery bank touch each other. During the installation and wiring process ensure the cable ends are insulated or covered to prevent touching/shorting the cables.



Info: DO NOT connect the DC wires from the battery bank to the inverter until: 1) all DC/AC wiring is complete, 2) the correct DC and AC overcurrent protection have been installed, and 3) the correct DC voltage and polarity have been verified.



Info: For optimum performance, a minimum battery bank of 200 AHr is recommended.

Depending upon the type of batteries you use in the installation (6 or 12 VDC), the batteries must be wired in series, parallel, or series-parallel (see Appendix B - Battery Information for guidance on wiring batteries together). The interconnecting DC wires must be sized and rated exactly the same as those that are used between the battery bank and the inverter.

Place the batteries as close as practical to the inverter, preferably in an insulated and ventilated enclosure. Allow adequate space above the batteries to access the terminals and vent caps (as applicable). Also, allow at least 2.54 cm (1") of space between the batteries to provide good air flow. DO NOT mount the batteries directly under the inverter.



Info: To ensure the best performance from your inverter system do not use old or untested batteries. Batteries should be of the same size, type, rating, and age.



CAUTION: Install batteries in a well ventilated area. Batteries can produce explosive gasses. For compartment or enclosure installations, always vent batteries to the outside.

2.7 Inverter to Battery Bank Wiring



WARNING: Ensure all sources of DC power (batteries) and AC power (shore power or AC generator) are de-energized (i.e., breakers opened, fuses removed) before proceeding.



CAUTION: The inverter is NOT reverse polarity protected. If this happens, the inverter will be damaged and will not be covered under warranty. Before connecting the DC wires from the batteries to the inverter verify the correct battery voltage and polarity using a voltmeter. If the positive terminal of the battery is connected to the negative terminal of the inverter and vice versa, severe damage will result. If necessary, color code the cables with colored tape or heat shrink tubing; BROWN for positive (+), and BLUE for negative (-) to avoid polarity confusion.



Info: The DC overcurrent device (i.e., fuse or circuit breaker) must be placed in the positive (BROWN) DC cable line between the inverter's positive DC terminal and the battery's positive terminal (BROWN); as close to the battery as possible.

2.7.1 DC Ground Wire

Route an appropriately sized DC grounding wire (GREEN w/ YELLOW stripe) from the inverter's DC Ground Terminal (see Figure 1-2, Item 11) to a dedicated system ground. Recommended tightening torque is 5.2 N-m.

2.7.2 DC Negative Wire

Route an appropriately sized DC negative wire (BLUE) from the negative terminal of the first battery string to the inverter's negative terminal (see C3-4 for reference).

2.7.3 Battery Temperature Sensor

Connect the RJ11 connector end of the BTS to the ACCESSORY PORT (see Figure 1-3, Item 14) on the inverter. Connect the other end of the BTS to the negative terminal of the first battery string (in same place as the negative DC wire above); refer to Figure 2-4 for the correct hardware placement.

2.7.4 DC Positive Wire

Mount the DC fuse block and disconnect (or circuit breaker assembly) as near as practical to the batteries, and then open the disconnect (or circuit breaker).



WARNING: DO NOT close the DC fuse/DC disconnect (or close the DC circuit breaker) to enable battery power to the inverter at this time. This will occur in the Functional Test after the installation is complete.

Route and connect an appropriately sized DC positive wire (BROWN) from the DC fuse block (or circuit breaker assembly) to the inverter's positive DC terminal.

2.0 Installation

Connect a short wire (same rating as the DC wires) to one end of the fuse block and the other end of the short wire to the positive terminal of the last battery string (see Figure C4). This is essential to ensure even charging and discharging across the entire battery bank.

Ensure the DC wire connections (to batteries, inverter, and fuse lugs/DC circuit breaker) are flush on the surface of the DC terminals, and the hardware (lock washer and nut) used to hold these connections are stacked correctly (see Figures 2-4 and 2-5).

Verify all DC connections are torqued from 13.6 to 16.3 N-m.

Once the DC connections are completely wired and tested, coat the terminals with an approved anti-oxidizing spray.

Press the red and black terminal covers on to the inverter's DC connectors to secure them in place.

If batteries are in an enclosure, perform a final check of the hold-down brackets and all connections. Close and secure the battery enclosure.

2.8 AC Wiring

This section describes the required AC wire size and overcurrent protection for the MMS-E. It also provides information on how to make the AC connections.



WARNING: All wiring should be done by a qualified person or a licensed electrician following all local/IEC codes.

2.8.1 Neutral to Safety Ground Bonding

The IEC (International Electrotechnical Commission) provides the standards for safely wiring mobile (caravan, boat, or truck) installations. These wiring standards require the AC source (inverter, shore power, or a generator) to have the neutral conductor tied to ground. These standards also require that the AC neutral be connected to safety ground (often called a "bond") in only one place at any time. If more than one bond is established, currents can circulate between neutral and ground and cause ground-loop currents. These "ground-loops" can trip GFCIs and cause an electric shock hazard.

In mobile installations there may be multiple AC sources (i.e., shore power, generator, or inverter), which means there may be the potential of having multiple neutral to ground connections.

2.8.2 AC Wiring Connections

For the MMS912E model, the AC input and output wiring is performed in the AC wiring compartment. This compartment is accessed via the top panel (see Figure 1-2, Item 8). If the panel cover is installed, remove the two Phillips screws on the cover to access the AC wiring compartment and locate the inverter's AC wiring. There is a label located in the AC access compartment which gives information on

which wires are used for AC input and output. You can also refer to Table 2-3 to match the inverter's AC wires to the appropriate AC wire connection.

Table 2-3, Wire Color to AC Wire Connection

	Wire Color (label)	Wire Connection
AC IN	Brown (HOT IN)	Hot In
	Blue (NEUT IN)	Neutral In
AC OUT	Brown (HOT OUT)	Hot Out
	Blue (NEUT OUT)	Neutral Out
AC Ground	Green w/Yellow stripe (GROUND)	AC IN and AC OUT Ground

The AC wires inside the AC compartment are 1.31 mm² (#16 AWG) with a temperature rating of 105° C. All AC connections should be made using an approved connector for your application (e.g., split bolt, twist-on wire connectors, etc.,). Ensure the wire connectors used are rated for the size and number of wires you are connecting.

After connecting the wires together, gently pull on the wires to ensure they are securely held together. In a proper connection, no bare wire should be exposed.



Info: Per UL certification, non-metallic sheathed cable or an SO flexible cord with listed strain reliefs are allowed to be used to connect to the inverter; conduit connections are not allowed.

After all of the AC wiring in the inverter is complete (and before reattaching the AC access cover), ensure all connections are correct and secure.

2.8.3 AC Wire Size and Overcurrent Protection

The AC input and output wiring must be sized per the IEC and local electrical safety code requirements to ensure the wire's ability to safely handle the inverter's maximum load current. After determining the proper AC wire sizes, the inverter's AC input (unless you are using a flexible cord) and output wires are required to be protected against overcurrent and have a means to disconnect the AC circuits.

All inverter AC input and output wiring is required to be protected by an overcurrent protection device. Overcurrent protection must be provided by fuses or circuit-breakers, and must be properly sized and rated for the wire they are protecting and the appliances being powered.

2.0 Installation

Most inverter's that are hardwired use a service/distribution panel wired to the inverter's input (main panel), and a dedicated panel between the inverter's output wiring and the AC loads (sub-panel). These systems use the circuit breakers provided in the panels as the overcurrent protection and the AC disconnect. If fuses are used, then separate AC disconnect switches will be needed.

Based on information from the IEC, Table 2-4 provides the minimum AC wire size and the suggested breaker size based on the inverter model. However, a larger wire size may be required because of voltage drop. The AC wire sizes provided in this table assume using only copper wire and a temperature rating of 75° C or higher. A minimum of 2.08 mm² (#14 AWG) is required for all AC wiring.

Table 2-4, Minimum Wire Size to Circuit Breaker Size

AC Input			AC Output		
Input Breaker	Minimum Wire Size	Suggested Breaker Size	Output Breaker	Minimum Wire Size	Suggested Breaker Size
8 amps	2.08 mm ² (#14 AWG)	15 amps	7 amps	2.08 mm ² (#14 AWG)	15 amps

2.8.4 AC Input Wiring

Your inverter has an AC transfer feature that passes the AC input power to the inverter's output. Connection to the AC input is made by hardwiring from a distribution panel as described below:

1. Run an appropriately sized 2-conductor plus ground cable (from the AC distribution panel) through the strain relief clamp on the AC IN opening (Figure 1-2, Item 10). Refer to Table 2-4 for minimum wire size and overcurrent protection required for the AC input wiring.
2. Remove about two inches (5.1 cm) of the insulating jacket from the AC cable, and then separate the three wires and strip about 3/4" of insulation from each wire.
3. Using approved AC wire connectors, connect the incoming Hot In (brown), Neutral In (blue), and Ground (green w/ yellow stripe) wires to the MMS-E's AC wires colored black (HOT IN), white (NEU IN), and green (AC GROUND) respectively.
4. After making the AC input connections, secure the AC input cable by tightening the strain relief clamp.

The AC input wiring in the inverter is now complete. Review all AC wiring to ensure all connections are correct and secure.




Figure 2-6, AC Wiring Connections (MMS912E)

2.8.5 AC Output Wiring



CAUTION: The inverter's AC output must never be connected to an AC power source. This will cause severe damage to the inverter and is not covered under warranty.



Info: When using the MMS-E Series inverter in a caravan application (under certain conditions, and provided that the wire is properly sized for the protecting breaker), some standards permit the breaker in the main distribution panel and/or the supplemental breakers on the inverter to provide adequate protection for the AC output wiring. Please check your local codes first.

Follow the steps below to hardwire the AC output of the MMS-E Series inverter:

1. Remove the 12.7 mm knockout on the AC Output Connection (see Figure 1-2, Item 9) – use a utility knife to cut through the round slot.
2. Discard this knockout and install a 12.7 mm (1/2") strain relief in the AC OUT opening. You may need to file the opening edge for proper fit.
3. Run a 2-conductor plus ground cable through the strain relief in the AC OUT opening. Refer to Table 2-4 for the minimum wire size and the overcurrent protection required for the AC output wiring.

2.0 Installation

4. Remove about 50 mm (2") of the insulating jacket from the AC cable, and then separate the three wires and strip about 19 mm (3/4") of insulation from each wire.
5. Using approved AC wire connectors, connect the outgoing Hot Out, Neutral Out, and AC Ground wires to the inverter's AC wires colored red (HOT OUT), white with black stripe (NEU OUT), and green (AC GROUND), respectively. Gently pull on the wires to ensure they are securely held together and check to see that no bare wire is exposed.
6. After making the AC output connections, secure the AC output cable by tightening the strain relief.
7. Connect the outgoing AC wires to either:
 - a. an AC load sub-panel equipped with overcurrent protection (e.g., circuit breakers), or
 - b. directly to the circuit; when following local standards that permit using breakers from the main distribution panel or the breakers on the inverter under certain conditions.

The AC output wiring in the inverter should now be complete. Before reattaching the AC access cover, review all AC wiring to ensure all connections are correct and secure.

2.9 Functional Test

After all electrical connections to the inverter, batteries, AC source, and loads (using a sub-panel) have been completed, follow these steps to test the installation and the inverter's operation.

1. Check the battery voltage and polarity before connecting the batteries to the inverter. Use a multimeter to verify 10 to 14 VDC at the batteries' positive and negative terminals.
2. Apply battery power to the inverter by switching the DC disconnect ON (or close the DC circuit-breaker). The inverter will remain OFF, but the green status indicator on the front of the inverter will quickly blink once to indicate that DC power has been connected and is ready to be turned on.
3. Prior to turning on the inverter make sure all connected loads (e.g., appliances) are switched OFF, or disconnected from the AC outlets.
4.
 - a. If a remote switch is connected, press the ON/OFF switch to turn the inverter on.
 - b. If no remote switch is connected, lightly press and release the inverter's ON/OFF power switch — located on the top of the inverter — to turn the inverter on.

Verify the inverter's status indicator is blinking – indicating the inverter is providing AC power.

5. Check the output voltage of the inverter by connecting a true RMS multimeter to the outlets powered by the inverter. Verify the voltage is 230 VAC +/- 5 VAC. If not using a true RMS meter the output AC voltage could indicate from 170-250 VAC, depending on the battery voltage.
6. Turn on or connect a load to the outlets and verify it comes on. Continue to keep the load connected and turned on.
7. Press the remote ON/OFF switch to turn the inverter off. If the remote is not used, press and release the inverter's ON/OFF power switch to turn the inverter off. The inverter's status indicator and the connected load should go off.
8. Apply AC power to the inverter's AC input. After the AC input power is qualified (approximately 15 seconds), the incoming AC power will transfer through the inverter to the inverter's AC output and power the connected load. Verify that the inverter's status indicator and the connected load come on.
9. Even though the connected load is on, the inverter is currently disabled/off. Press the remote's ON/OFF switch (or press and release the ON/OFF power switch on the inverter) to enable/turn on the inverter.
10. Disconnect the incoming AC power to the inverter. Verify the connected load remains on, but now is powered by the inverter.

If the inverter passes all the previous steps, the inverter is ready for use.

If the inverter fails any of the steps, refer to the Troubleshooting section.

3.0 Operation

3.0 Operation

3.1 Operating Modes

The MMS-E Series inverter/charger has two normal operating routines: Inverter mode, which powers your loads using the batteries, and Standby mode, which transfers the incoming AC power (i.e., shore power or a generator) to power your loads and to recharge the batteries. This inverter also includes an extensive protection circuitry that shuts down the inverter under certain fault conditions.

3.1.1 Inverter Mode

When the inverter is first powered up, it defaults to the OFF mode. The momentary ON/OFF power switch (Figure 1-2, Item 2) must be lightly pressed to turn the inverter ON. Subsequently pressing this switch alternately turns the inverter off and on.

- **Inverter OFF** - When the inverter is off, no power is used from the batteries to power the AC loads, and the Status LED will be off. If AC power from an external source (shore power or generator) is connected and qualified on the inverter's AC input, this AC input power will pass through the inverter to power the AC loads. However, if this AC power is lost, the AC loads will no longer be powered because the inverter is off.

When the inverter is turned on, it operates either by "Searching" or "Inverting", depending on the connected AC loads.

- **Searching** - When the inverter is first turned on, the automatic Search feature is enabled. This feature is provided to conserve battery power when AC power is not required. In this mode, the inverter pulses the AC output looking for an AC load (i.e., electrical appliance). Whenever an AC load (greater than 5 watts) is turned on, the inverter recognizes the need for power and automatically starts inverting. When there is no load (or less than 5 watts) detected, the inverter automatically goes back into Search mode to minimize energy consumption from the battery bank. When the inverter is "Searching", the inverter's green LED flashes (fast).



Info: The factory default value for the Search feature is 5 watts. It can be turned off or adjusted from 5 to 50 watts using the ME-RC50 remote display.

- **Inverting** - When a load greater than 5 watts is connected to the inverter output, the MMS-E Series inverts the DC power from the battery and supplies 230 VAC power to your sub-panel. The inverter's green LED flashes once every 2 seconds (medium flash) to indicate it is inverting. The amount of time the inverter can be inverting and providing power is directly related to the amount of AC loads that are connected and the capacity of the battery bank.

3.1.2 Standby Mode

The MMS-E Series features an automatic transfer relay and an internal battery charger when operating in Standby mode. Standby mode begins whenever AC power (shore power or generator) is connected to the inverter's AC input. Once the AC voltage and frequency of the incoming AC power is within the AC input limits, an automatic AC transfer relay is activated. This transfer relay passes the incoming AC power through the inverter to power the AC loads on the inverter's output. This incoming power is also used to activate a powerful internal battery charger to keep the battery bank charged in case of a power failure.

Battery Charging - The MMS-E Series is equipped with an active Power Factor Corrected (PFC) multi-stage battery charger. The PFC feature controls the amount of power used to charge the batteries in order to obtain a power factor as close as possible to 1 (or unity). This causes the battery charger to look like a resistor to the line (forces the charge current wave shape to mirror the voltage wave shape). This feature maximizes the real power available from the AC power source (shore power or generator), which translates into less power wasted and a greater charging capability than most chargers available today.

When an AC power source is connected to an inverter that has a battery charger, the inverter monitors the AC input for acceptable voltage. Once the inverter has accepted the AC input, the AC transfer relay will close and charging will begin. Once charging, the DC voltage is monitored to determine the charging stage. If the DC voltage is low (≤ 12.9 VDC), the charger begins Bulk Charging. If the DC voltage is high (> 12.9 VDC), the charger skips the initial Bulk/Absorb Charging stages and goes directly to Float Charging.

The multi-stage charger can use up to five different charging stages to help monitor and keep the batteries healthy. The five stages include an automatic 4-stage charging process (Bulk, Absorb, Float, and Full Charge), and a manual Equalization (EQ) charge stage. The automatic 4-stage charge process provides complete recharging and monitoring of the batteries without damage due to overcharging (see Figure 3-2). The Equalization stage (requires the ME-RC50 remote) stirs up stratified electrolyte and reverses any battery plate sulfation that might have occurred.

While charging, the unit may go into "Charger Back-off" protection which automatically reduces the charge current to the batteries.

This is caused by:

1. The internal temperature is too hot – the charger automatically reduces the charge rate to maintain temperature; or,
2. The AC input voltage falls from 150-190 VAC – the charger reduces the charge current to zero to stabilize the incoming AC voltage; or,
3. FET Temperature.

3.0 Operation

The automatic 4-stage charging process includes:

- **Bulk Charging:** This is the initial stage of charging. While bulk charging, the charger supplies the battery with constant current. The charger remains in Bulk Charge until the absorption charge voltage is achieved (14.6 VDC)* – as determined by the battery type selection**.
- **Absorb Charging:** This is the second charging stage and begins after the bulk voltage has been reached. Absorb charging provides the batteries with a constant voltage and reduces the DC charging current in order to maintain the absorb voltage setting. The absorb charging time is 120 minutes – as determined by the battery amp-hours selection**.
- **Float Charging:** The third charging stage occurs at the end of the absorb charging time. While float charging (also known as a maintenance charge), the batteries are kept fully charged and ready if needed by the inverter. The Float Charging stage reduces battery gassing, minimizes watering requirements (for flooded batteries), and ensures the batteries are maintained at optimum capacity. In this stage, the charge voltage is reduced to the float charge voltage (13.4 VDC)* — as determined by the battery type selection** — which can maintain the batteries indefinitely.
- **Full Charge (Battery Saver™ Mode):** The fourth stage occurs after four hours of float charging. The Full Charge stage maintains the batteries without overcharging, thus preventing excessive loss of water in flooded batteries or drying out of GEL/AGM batteries. In this stage, the charger is turned off and begins monitoring the battery voltage. If the battery voltage drops low (≤ 12.7 VDC), the charger will automatically initiate another four hours in Float Charge.

** These voltage settings are based on the Battery Temperature Sensor (BTS) being disconnected, or at a temperature of 25° C (77° F). If the BTS is installed, these voltage settings will increase if the temperature around the BTS is below 25° C (77° F), and decrease if the temperature around the BTS is higher than 25° C (77° F).*

*** The MMS-E Series uses changeable settings (see Table 6, Inverter Default Settings) that are adequate for most installations. However, if you determine that some of your operating parameters need to be changed, the ME-RC50 remote control can be purchased to allow changes to those settings.*




Figure 3-1, Automatic 4-Stage Charging Graph

Transfer Time - While in Standby mode, the AC input is continually monitored. Whenever AC power falls below the VAC dropout voltage (150 VAC, default setting), the inverter automatically transfers back to Inverter mode with minimum interruption to your appliances – as long as the inverter is turned on. The transfer time from Standby mode to Inverter mode averages approximately 16 milliseconds. While the MMS-E Series is not designed as a computer UPS system, this transfer time is usually fast enough to hold them up. However, the VAC dropout setting has an effect on the ability of the loads to transfer without resetting. The lower this setting, the longer the effective transfer will be and therefore, the higher the probability for the output loads to reset. This occurs because the incoming AC voltage is allowed to fall to a level that is so low that when the transfer does occur, the voltage on the inverter's output has already fallen to a low enough level to reset the loads.

The disadvantage of a higher VAC dropout setting is that smaller generators (or large generators with an unstable output) may nuisance transfer. This commonly happens when powering loads that are larger than the generator can handle – causing the generator's output voltage to constantly fall below the inverter's input VAC dropout threshold.



Info: You must use the ME-RC50 or ME-ARC50 remote to adjust the VAC dropout setting – which in turn determines the VAC dropout threshold.



Info: When switching from Inverter mode to Standby mode, the inverter waits approximately 15 seconds to ensure the AC source is stable before transferring.

3.0 Operation

Battery Temperature Sensor Operation - The plug-in Battery Temperature Sensor (BTS) is used to determine the battery temperature around the batteries. This information allows the multi-stage battery charger to automatically adjust the battery charge voltages for optimum charging performance and longer battery life.

When the BTS is installed, if the temperature around the BTS is below 25° C (77° F) the absorb and float charge voltages increase. If the temperature around the BTS is higher than 25° C (77° F), the absorb and float charge voltages decrease. See Figure 12 to determine how much the charge voltage changes (increases or decreases) as the temperature reading of the BTS changes. For example, the nominal absorb charge voltage for a flooded battery at 25° C (77° F) is 14.6 VDC. If the battery temperature is 35° C (95° F), the absorb charge voltage would decrease to 14.3 VDC (14.6 VDC - 0.3 change).

If the temperature sensor is NOT installed, the charge voltages will not be compensated and the battery will maintain the charge it had at a temperature of 25° C (77° F). The life of the batteries may be reduced if they are subjected to large temperature changes when the BTS is not installed.



Info: When the BTS is connected, the battery charger uses a value of -5mV/°C/Cell from 0-50°C to change the charge voltage based on temperature.




Figure 3-2, BTS Temperature to Charge Voltage Change

3.2 Protection Circuitry Operation

The inverter is protected against fault conditions, and in normal usage it will be rare to see any. However, if a condition occurs that is outside the inverter's normal operating parameters, then it will shut down and attempt to protect itself, the battery bank, and your AC loads. If there is a condition that causes the inverter to shut down, it may be one of the conditions listed below. Refer also to the Troubleshooting section to diagnose and clear the fault.

- **Low Battery** - The inverter will shut off whenever the battery voltage falls to the Low Battery Cut Out (LBCO) level to protect the batteries from being over-discharged. After the inverter has reached the LBCO level and turned off, the inverter will automatically restart after one of the following conditions:
 1. AC power is applied and the inverter begins operating as a battery charger.
 2. Battery voltage rises to the Low Battery Cut In (LBCI) level.

The inverter's status LED turns off when a low battery fault condition occurs. Refer to Table 3-1 to determine the LBCO and LBCI levels for your particular inverter model.

- **High Battery** - In the event the battery voltage approaches the High Battery Cut Out (HBCO) level, the inverter will automatically shut down to prevent the inverter from supplying unregulated AC output voltage. The inverter's status LED turns off when a high battery fault condition occurs. The inverter will automatically restart when the battery falls to the High Battery Cut In (HBCI) level. Refer to Table 3-1 to determine the HBCO and HBCI levels for your particular inverter model.



Info: High battery voltage may be caused by excessive or unregulated voltage from solar panels or other external charging sources.

- **Overload** - During Inverter and Standby modes, the inverter monitors the DC and AC current levels. In the event of a short-circuit or an overload condition for more than a few seconds, the inverter will shut down. To start operating after this fault, the inverter would need to be restarted (turned back on) after the inverter's AC loads are reduced/removed.
- **Over-temperature** - If internal power components begin to exceed their safe operating temperature level, the inverter will shut down to protect itself from damage. The inverter's status LED turns off to indicate the over-temperature fault condition. The inverter will automatically restart after the units cools down.

3.0 Operation

- **Internal Fault** - The inverter continually monitors several internal components and the processor communications. If a condition occurs that doesn't allow proper internal operation, the inverter will shut down to protect itself and the connected loads. The inverter will need to be reset to start operating.

Table 3-1, Inverter Battery Turn On/Off Levels

Inverter Battery Turn On/Off Levels	
HBCO	>15.8 VDC
HBCI	15.5 VDC
LBCI	≥12.5 VDC
LBCO* (one minute delay)	10.0 VDC (9.0-12.2 VDC)
LBCO (immediate)	8.5 VDC

* - adjustable with remote

3.3 Inverter Startup

ON/OFF Switch - The inverter can be turned on and off by lightly pressing and releasing the Power ON/OFF switch on the front of the inverter. When the inverter is first connected to the batteries, or when its automatic protection circuit has turned the inverter off, the ON/OFF switch will need to be pressed to start the unit. Once the inverter has been turned on, pressing the Power ON/OFF switch alternately turns the inverter on and off.



WARNING: The Power ON/OFF control switch does not turn on or off the charger feature. If AC power (utility or generator) is connected and qualified on the AC input, this AC power will also be available on the AC output and is not controlled by the Power ON/OFF switch.

Status LED Indicator - The status indicator is a green LED (Light Emitting Diode) that provides information on the operational mode of the inverter. Watch this indicator for at least 10 seconds to determine the inverter's operational condition from the information below:

Inverter Mode

- **Off** - Indicates the inverter is off; there is no AC power from the inverter, shore power, or generator at the inverter's output terminals.
- **Blinks On** (once every second) - The inverter is on and is using energy from the battery. The inverter is either providing full power to the loads connected to the inverter, or it's in Search Mode and ready to supply AC power to the connected loads.

Protection Mode

There are five fault conditions that will cause the inverter to shut down: Low Battery, High Battery, Over-temperature, AC Overload, and Internal faults. If your inverter has shut down, monitor the status indicator and count the number of blinks that occur every four seconds to determine the particular reason for the shutdown. Refer to the Troubleshooting section to help diagnose/clear the fault condition.

- Blinks on 1 time every four seconds - Low Battery fault
- Blinks on 2 times every four seconds - High Battery fault
- Blinks on 3 times every four seconds - Over-temperature fault
- Blinks on 4 times every four seconds - AC Overload fault
- Blinks on 5 times every four seconds - Internal fault

Charge Mode

The green LED status indicator provides additional information:

- Blinks off every four seconds - The unit is charging the batteries connected to the inverter. The external AC power (shore power or generator) connected to the inverter's input is passing through the inverter and is powering the AC loads connected to the inverter's output.

3.4 Factory Default Settings

The MMS-E Series inverter/charger uses default settings that are adequate for most installations (see Table 3-2). However, you can adjust these parameters using Magnum's optional ME-RC50 remote. Once programmed, the settings are saved in non-volatile memory and are preserved until changed – even if DC power to the inverter is lost (the ME-RC50 must always be connected). The following information can help you determine if you need the ME-RC50 remote*.

01 Search Watts: This setting allows you to turn off the power-saving Search Mode circuitry and to adjust the power level at which the inverter will “wake up” and start inverting.

02 Low Battery Cut Out: This setting determines when the inverter will turn off based on low battery voltage. The inverter turns off automatically after the battery voltage has been below this setting for more than one minute. This protects the batteries from over-discharge and the AC loads from unregulated power (brown-outs).

** Visit www.magnumenergy.com for more information.*

3.0 Operation

03 Battery AmpHrs: This setting allows you to input the battery bank size in amp-hours. This provides information to the charger on how long to charge the batteries in the Absorb Charging stage.

04 Battery Type: This setting identifies the type of batteries being used in the system. This provides information to the charger to determine what voltage level to use to charge the batteries.

05 Charge Rate: This setting can be used to turn off the charger, or limit the amount of current that the charger can use (leaving more current available to power loads); or, to ensure small battery banks are not overheated because of a charge rate that is too high.

06 VAC Dropout: Sets the minimum AC voltage that must be present on the AC input before the unit transfers from Standby Mode to Inverter Mode. This protects the AC loads from utility outages and brown-outs.

The ME-RC50 remote also provides the following features:

- allows you to enable an equalize charge for certain battery types
- displays the inverter/charger's operating status
- provides fault information for troubleshooting

Table 3-2, Inverter/Charger Default Settings

Function	Default Settings
Search Watts	5 Watts
LowBatCutOut	10.0 VDC
Battery AmpHrs	400 AmpHrs (Absorb Time = 90 mins)
Battery Type	Flooded – Liquid Lead Acid Bulk = 14.6 VDC, Float = 13.4 VDC
Charge Rate	100%
VAC Dropout	150 VAC

4.0 Maintenance and Troubleshooting

4.1 Recommended Inverter and Battery Care

The MMS-E Series inverter/charger is designed to provide you with years of trouble-free service. Even though there are no user-serviceable parts, it is recommended that every 6 months you perform the following maintenance steps to ensure optimum performance and extend the life of your batteries.



WARNING: Prior to performing these checks, switch both the AC and DC circuits OFF.

- Visually inspect the batteries for cracks, leaks, or swelling – replace if necessary.
- Use baking soda to clean and remove any electrolyte spills or buildups.
- Check and tighten all battery holddown clamps.
- Clean and tighten (13.6 - 16.3 N-m) all DC terminals (battery and inverter) and connecting cables.
- Check and fill battery water levels (Liquid Lead Acid batteries only).
- Check individual battery voltages (replace those that vary more than 0.3 VDC of each other).
- Check all cable runs for signs of chafing – replace if necessary.
- Check the inverter's cooling vents – clean as necessary.

4.2 Caravan/Marine Off-Season Storage

When placing your caravan or boat into seasonal storage, it is recommended that you perform the following to ensure the system is properly shut down (or properly configured for seasonal storage). This is especially important for maintaining the batteries.

- Perform the recommended maintenance steps noted above.
- Fully charge the batteries.
- Connect shore power (if available) and verify that the breaker to the battery charger is switched ON.
- Verify the inverter is switched OFF.
- Switch OFF all unnecessary AC and DC loads.

4.0 Maintenance and Troubleshooting

4.3 Resetting the Inverter

Under some fault conditions (i.e., an internal fault), the inverter will need to be reset.

To reset the inverter:

1. Press and hold the Power ON/OFF pushbutton for approximately 15 seconds, or until the status LED comes on and flashes rapidly (see Figure 4-1).
2. Release the Power ON/OFF pushbutton once the rapid flashing has begun. The status LED will go off.
3. Press the Power ON/OFF pushbutton again to turn the inverter on.



Info: The Power ON/OFF pushbutton is a small *momentary* type switch which operates by lightly pressing and releasing.




Figure 4-1, Resetting the Inverter

4.0 Maintenance and Troubleshooting

4.4 Troubleshooting

The MMS-E Series inverter/charger is a fairly simple device to troubleshoot. There are only two active circuits (AC and DC), as well as a charging circuit. The following chart is designed to help you quickly pinpoint the most common inverter and charger faults.

Table 4-1, Troubleshooting Guide

Symptom	Possible cause	Recommended Solution
Low Battery Voltage (the status indicator blinks on <u>1 time</u> every 4 secs)	The battery voltage level has dropped below the Low Battery Cut Out (LBCO) set-point for more than one minute (10.0 VDC = LBCO default setting).	Battery voltage is too low. Check fuses/circuit-breakers and cable connections. Check battery voltage at the inverter's terminals. Your batteries may need to be charged, this fault condition will automatically clear when the battery voltage exceeds 12.5 VDC.
High Battery Voltage (the status indicator blinks on <u>2 times</u> every 4 secs)	The battery voltage is above 15.5 VDC. The inverter automatically resets and resumes operation when the battery voltage drops below 15.5 VDC.	This condition usually occurs only when an additional charging source (alternator, solar panels or other external charging sources) is used to charge the battery bank. Reduce or turn off any other charger to the inverter batteries to allow the voltage level to drop.
Over-temperature condition (the status indicator blinks on <u>3 times</u> every 4 secs)	The internal temperature of the inverter has risen above acceptable limits; caused by loads too great for the inverter to operate continuously, or by lack of ventilation to the inverter. When the unit has cooled, it will automatically reset and resume operation.	Reduce the number of electrical loads that you are operating, this will avoid a repeat Overtemp shutdown if the cause was too many loads for the ambient conditions. Check ventilation around the inverter, ensure cool air is available to pass-thru the inverter.
AC Overload (the status indicator blinks on <u>4 times</u> every 4 secs)	The inverter has turned off because the connected loads are larger than the inverter's output capacity or the output wires are shorted.	Reduce the AC loads connected to the inverter or remove all AC output wiring and restart the inverter.
Internal fault (the status indicator blinks on <u>5 times</u> every 4 secs)	This fault occurs when an internal fault is detected.	To clear this fault, an inverter reset is required. Remove DC power to the inverter or press and hold down the power switch on the inverter for 15 seconds (until the green Status LED comes on). If this fault does not clear, the unit will need to be serviced.
Inverter's status light is off.	Inverter is switched OFF or there is no DC voltage (battery) connected to inverter.	Switch the inverter ON. Connect a battery with correct voltage to the inverter.
AC input won't connect (AC IN on remote blinks)	The incoming AC voltage will not be accepted if it is below the VAC Dropout setting (150 VAC = VAC Dropout default setting).	Check the incoming AC voltage to the input of the inverter, ensure it is present and above the VAC dropout level.
Appliances turn off and on; or there is low AC output power.	Loose AC output connections.	Tighten AC output connections.
	Loose / corroded battery cables.	Clean and tighten all cables.
	Low batteries.	Recharge or replace batteries.
Inverter AC output voltage is too low or too high when using an AC voltmeter.	Wrong type of voltmeter used (will display 170 VAC to 250 VAC depending on the battery voltage).	Most meters are made to read Average AC voltage. The AC output of the MM is a "modified" waveform which requires using a "true" RMS voltmeter to correctly read the output voltage.
While charging, the DC charge voltage is higher or lower than expected.	If the Battery Temperature Sensor is installed, it will increase or decrease the DC voltage level depending on temperature around the battery sensor.	This is normal.

5.0 Specifications

5.0 Specifications

Table 5-1, MMS-E Series Specifications

MODEL	MMS912E
Inverter Specifications	
Input battery voltage	9 to 17 VDC
Nominal AC output voltage	230 VAC +/- 5%
Output frequency and accuracy	50 Hz +/- 0.1 Hz
1 msec surge current (amps AC)	30
100 msec surge current (amps AC)	7.5
5 sec surge power (real watts)	1600
30 sec surge power (real watts)	1250
5 min surge power (real watts)	1200
30 min surge power (real watts)	1100
Continuous power output at 25° C	900 VA
Maximum continuous input current	120 ADC
Inverter efficiency (peak)	87%
Transfer time	~ 20 msecs
AC transfer capability	20 AAC
Search mode (typical)	0.4 ADC at 12.6 V
No load (230 VAC output, typical)	19 watts at 12.6 V
Waveform	Pure Sine Wave
Charger Specifications	
Continuous output at 25° C	40 ADC
Charger efficiency	80%
Power factor	> 0.95
Input current at rated output (AAC)	3
Battery temperature compensation	Yes, 4.6m (15') BTS standard
General Features and Capabilities	
Protection circuitry	Low/High Battery, Overtemp & Overload
Corrosion protection	PCB's conformal coated, powder coated chassis
AC Output	Hardwire
AC Input	Hardwire
Output circuit breaker	7 A switchable
Input circuit breaker	8 AAC
Internal cooling	Yes, 0 to 59 cfm variable speed
Optional remotes available	MM-RC, ME-RC, or ME-ARC
Regulatory	NA
Environmental Specifications	
Operating temperature	-20° C to +60° C
Non-operating temperature	-40° C to +70° C
Operating humidity	0 to 95% RH non-condensing
Physical Specifications	
Dimensions (L x W x H)	42 cm x 21 cm x 12 cm
Mounting	Shelf or wall (no downward vents)
Weight	10.4 kg
Shipping weight	11.3 kg

Appendix A - Optional Equipment and Accessories

The following Magnum Energy components are available for use with the MMS-E Series inverter/charger. Some of these items are required depending upon the intended use of the inverter.

Smart Battery Combiner

The Smart Battery Combiner (ME-SBC™) is designed to monitor and charge a second battery using a portion of the current that is charging the main battery. The ME-SBC eliminates a significant voltage drop, and provides automatic turn-on and turn-off based on adjustable voltage set-points. This allows different batteries to be charged from a single charging source, and prevents overcharging/undercharging.

Standard Remote Control

The ME-RC50 Remote Control Panel is simple to use; an LCD screen and "at a glance" LEDs display complete inverter/charger status. Soft keys provide simple access to menus and a rotary encoder knob allows you to scroll through and select a wide range of settings.

Auto Generator Start Controller

The ME-AGS-N Automatic Generator Start controller (Network version) is designed to automatically start your generator based on low battery condition or high temperature. It works with 12, 24, and 48-volt battery banks and includes a 4-position DIP (Dual In-line Package) switch which provides the ability to change the relay timing configurations to allow compatibility with a wider range of generators.

Battery Monitor Kit

The ME-BMK Battery Monitor Kit is a single battery bank amp-hour meter that monitors the condition of the battery and provides information to let you know how much energy you have available and let you plan your electrical usage to ensure the battery is not being over-discharged. The ME-BMK-NS version does not include a DC shunt – order the ME-BMK to receive a 500A/50mv DC shunt.

Fuse Block/Fuses

The Magnum Fuse/Fuse-blocks are used to protect the battery bank, inverter, and cables from damage caused by DC short circuits and overloads. They include a slow-blow fuse with mounting block and protective cover. The 125 and 200 amp models use an ANL type fuse and the 300 and 400 amp models use a Class-T fuse.

DC Load Disconnect

The MM-DCLD (DC Load Disconnect) pigtail adapter is designed to provide a means to DISABLE the inverter function when a 12-volt DC signal is removed.

Ignition Switch Activate

The MM-ISA (Ignition Switch Activate) is a pigtail adapter is designed to automatically ENABLE the inverter function when a 12-volt DC signal is supplied.

Appendix B - Wiring Color Codes

Appendix B - Wiring Color Codes for Europe and U.S./Canada

The following tables contrast AC and DC wiring color codes for Europe and the United States/Canada. In the U.S., the National Electrical Code (NEC) is the mandating authority; in Canada, it's the Canadian Electrical Code (CEC). Most of Europe abides by the International Electrotechnical Commission's (IEC) wiring color codes. The tables also list the labels that Magnum Energy applies to identify AC/DC wiring usage in its inverters.

Table B-1, AC Wiring Color Codes

Use	Magnum Label	Europe	U.S./Canada
Protective earth	AC GROUND	Green w/ yellow stripe	Bare, green
Neutral (out/in)	NEUTRAL OUT/ NEUTRAL IN	Blue	White (marked)
Line, single phase (out/in)	HOT OUT/ HOT IN	Brown	Black

Table B-2, DC Wiring Color Codes*

Use	Magnum Label	Europe	U.S./Canada
Positive circuit	Positive (+) terminal (w/ red cover)	Brown	Red
Negative circuit	Negative (-) terminal (w/ black cover)	Blue	White (sometimes black)

* - The chart is based on a 2-wire negative earthed (grounded) DC power system.

Appendix C - Battery Information

C1 Battery Bank Sizing

The size of the battery bank determines how long the inverter can power the AC loads without recharging. The larger the battery bank, the longer the run time. Size your battery bank to the system's AC load requirements and the length of time required to run the load from the batteries. In general, the battery bank should not be discharged more than 50%.

C2 Battery Types

Batteries are available in different sizes, amp-hour ratings, voltage, and chemistries; they also come in liquid or gel, vented or non-vented, etc. They are also available for starting applications (such as an automobile starting battery) and deep discharge applications. Only the deep cycle types are recommended for inverter applications. Choose the batteries best suited for the inverter installation and cost. Use only the same battery type for all batteries in the bank. For best performance, all batteries should be from the same lot and date. This information is usually printed on a label located on the battery.

C3 Battery Configuration

The battery bank must be wired to match the inverter's DC input voltage specifications. In addition, the batteries can be wired to provide additional run- time. The various wiring configurations are:

C3.1 Series Wiring

Wiring batteries in a series increases the total battery bank output voltage. A series connection combines each battery in a string until the voltage matches the inverter's DC requirement. Even though there are multiple batteries, the capacity remains the same. In the example below (Figure C3-1), two 6 VDC/200 AHr batteries are combined into a single string – resulting in a 12 VDC/200 AHr bank.




Figure C3-1, Series Battery Wiring

Appendix C - Battery Information

C3.2 Parallel Wiring

Wiring the batteries in parallel increases the total run time the batteries can operate the AC loads. A parallel connection combines overall battery capacity by the number of batteries in the string. Even though there are multiple batteries, the voltage remains the same. In the example below (Figure C3-2), four 12 VDC/100 Ahr batteries are combined into a single 12 VDC/400 Ahr battery bank.




Figure C3-2, Parallel Battery Wiring

C3.3 Series-Parallel Wiring

A series-parallel configuration increases both voltage (to match the inverter's DC requirements) and capacity (to increase run time for operating the loads) using smaller, lower-voltage batteries. In the example below (Figure C3-3), four 6 VDC/200 Ahr batteries are combined into two strings resulting in a 12 VDC/400 Ahr battery bank.




Figure C3-3, Series-Parallel Battery Wiring

Appendix C - Battery Information




Figure C3-4, Battery Bank Wiring Examples (12 volt)

Appendix D - Warranty/Service Information

D1 Limited Warranty

Magnum Energy, Inc., warrants this MMS-E Series inverter/charger to be free from defects in material and workmanship that result in product failure during normal usage, according to the following terms and conditions:

1. The limited warranty for the product extends for 24 months beginning from the product's original date of purchase.
2. The limited warranty extends to the original purchaser of the product and is not assignable or transferable to any subsequent purchaser.
3. During the limited warranty period, Magnum Energy will repair or replace (with factory new or remanufactured replacement items) at Magnum Energy's option any defective parts, or any parts that will not properly operate for their intended use – if such repair or replacement is needed because of product malfunction or failure during normal usage. The limited warranty does not cover defects in appearance (cosmetic or decorative), or any structural or non-operative parts. Magnum Energy's limit of liability under the limited warranty shall be the actual cash value of the product at the time the original purchaser returns the product for repair, determined by the price paid by the original purchaser. Magnum Energy shall not be liable for any other losses or damages.
4. Upon request from Magnum Energy, the original purchaser must prove the product's original date of purchase by a dated bill of sale, itemized receipt.
5. The original purchaser shall return the product prepaid to Magnum Energy in Everett, WA. After the completion of service under this limited warranty, Magnum Energy will return the product prepaid to the original purchaser via a Magnum selected non-expedited surface freight within the contiguous United States and Canada; this excludes Alaska and Hawaii.
6. If Magnum repairs or replaces a product, its warranty continues for the remaining portion of the original warranty period or 90 days from the date of the return shipment to the original purchaser, whichever is greater. All replaced products and parts removed from repaired products become the property of Magnum Energy.
7. This limited warranty is voided if:
 - the product has been modified without authorization
 - the serial number has been altered or removed
 - the product has been damaged through abuse, neglect, accident, high voltage, or corrosion
 - the product was not installed and operated according to the owner's manual

BEFORE RETURNING ANY UNIT, CONTACT MAGNUM ENERGY FOR A RETURN MATERIAL AUTHORIZATION (RMA) NUMBER.

D2 How to Receive Repair Service

If your product requires warranty service or repair, contact either:

1. An International Authorized Service Center (ASC), as listed on the Magnum Energy website at:
<http://www.magnumenergy.com/Service/ServiceCenters-Intl.htm>, or
2. Magnum Energy, Inc. at:

Telephone: +011-425-353-8833

Fax: +011-425-353-8390

Email: warranty@magnumenergy.com

If returning your product directly to Magnum Energy for repair, you must:

- return the unit in the original, or equivalent, shipping container
- receive a Return Materials Authorization (RMA) number from the factory prior to the return of the product to Magnum Energy for repair.
- place RMA numbers clearly on the shipping container or on the packing slip.

When sending your product for service, please ensure it is properly packaged. Damage due to inadequate packaging is not covered under warranty. We recommend sending the product by traceable or insured service.



Magnum Energy, Inc.
2211 West Casino Rd.
Everett, WA 98204
Phone: +011-425-353-8833
Fax: +011-425-353-8390
Web: www.magnumenergy.com



This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.