

e-ASK

electronic Access Security Keyless-entry

Cargo Lock / Unlock Version Consumer Manual

(UM06 ~ 18990-02)



500 Bailey Avenue
P.O. Box 350
New Hampton, Iowa 50659 U.S.A.
Tel: 641-394-3188
Fax: 641-394-2392
www.trimarkcorp.com

Table of Contents

Introduction.....	1
e-FOB Operation and Features	2
e-PAD Operation and Features	3
Locking Doors With Keypad.....	3
Unlocking Doors With Keypad and Other Secure Operations ..	3
e-PAD Configurations.....	4
e-PAD / e-FOB Dome/Porch Light Activation	4
e-PAD Protective Deactivating Security Feature	4
e-PAD Backlighting Power Management Feature.....	4
Teaching e-PAD New Access Codes	5
e-ASK I/O Module Features	6
Locking and Unlocking Confirmation	6
Deactivate Lock Confirmation	6
Door Ajar Confirmation	6
Alarm Mode.....	6
Timed Dome/Porch Light	7
Compartment Light Activation	7
Automatic Locking and Unlocking (Optional)	7
Troubleshooting	8

Introduction

This manual provides the necessary information for the proper installation and use of TriMark's **e-ASK** system. Included in this comprehensive access, security, keyless-entry system are the following elements:

- **e-FOB**: keyless entry radio frequency [RF] remote FOB transmitter and receiver
- **e-PAD**: convenient keypad user interface
- **e-ASK** I/O module

The following illustration provide visual details to properly identify the contents of the system.

**e-FOB with RF receiver,
2 remote transmitter FOBs, and wiring harnesses**



e-PAD keypad




e-ASK I/O module



(Note: Horizontal or Vertical e-PADS are available)

e-FOB Operation and Features

The FOB transmitter and receiver are shipped programmed. When the dealer has installed your e-FOB system, it will function as indicated below. Only the unlocking function of the e-FOB remains while the engine is running - other functions are deactivated. Both the Entry Lock and Cargo Lock must be pressed to arm the alarm system. Press the Entry or Cargo Unlock button to disarm the system and deactivate the alarm mode.



Button	Function
Entry Lock	Locks all entry doors and arms security system.
Entry Unlock	Unlocks entry doors and disarms security system. Also activates the porch light.
Cargo Lock	Locks all compartment doors and arms security system.
Cargo Unlock	Unlocks all compartment doors and disarms security system. Also activates the compartment lights.

e-PAD Operation and Features

The **e-PAD** is shipped with default Authority and Access codes. When all necessary wiring connections are made, the **e-PAD** system will function as indicated below. Unless the OEM or dealer has changed the default codes, the Authority and Access codes are as follows:

Access code:

Digit 1	Digit 2	Digit 3	Digit 4	Digit 5
1 / 2	3 / 4	5 / 6	7 / 8	9 / 0

Authority code:

Digit 1	Digit 2	Digit 3	Digit 4	Digit 5
7 / 8	7 / 8	7 / 8	7 / 8	7 / 8

Locking Doors With Keypad

Press and hold down the (1 / 2) button for 1-2 seconds. An access code is not needed to lock the doors.

Unlocking Doors With Keypad and Other Secure Operations

Entering a valid 5-digit access code enables the keypad. After entering an access code, the keypad is enabled for 5 seconds and a sixth button press initiates a secure operation. Entering the correct access code alone will not initiate a secure operation. The authority code does not allow for secure operations. It is only used to assign access codes (see page 4).

The following sequence illustrates how to perform secure operations with **e-PAD**.

- Enter a valid 5-digit access code (see default access code information above and page 5). Confirmation beeps indicate the system is enabled.
- Press the (3 / 4) button within 5 seconds and all doors will unlock.

If an unassigned button or no button is pressed while the system is enabled, the keypad reverts back to disabled state.

e-PAD Configurations

SECURE OPERATIONS ARE DEPENDENT ON SYSTEM CONFIGURATION. The **e-PAD** system can be configured in a variety of ways. Ask your dealer for the 6th digit operation for your vehicle.

The following table can be used to document the 6th digit operation of your vehicle.

6th Digit Pressed	Operation
Button (1 / 2)	
Button (3 / 4)	
Button (5 / 6)	
Button (7 / 8)	
Button (9 / 0)	

e-PAD / e-FOB Dome/Porch Light Activation

The dome/porch light is activated for a timed duration whenever a keypad button is pressed or when system is unlocked from FOB transmitter or vehicle switch. Contact your dealer to adjust duration. The dome/porch light is deactivated with engine start.

e-PAD Protective Deactivating Security Feature

After repeated entry of incorrect codes (20 button presses without enabling), the keypad is deactivated for 1 minute. This helps prevent unauthorized access by entering random codes. No beep will sound with button press while the system is disabled.

e-PAD Backlighting Power Management Feature

In order to provide continuous backlighting, but not drain the vehicle battery, the **e-PAD** deactivates backlighting if battery voltage is low. When continuous backlighting is off, the keypad still “wakes” up when a button is pressed. In this case, the backlighting is activated for only one minute.

Teaching e-PAD New Access Codes

With an active authority code, additional access codes can be programmed with the following instructions.

1. Press the middle (5 / 6) button for 5 seconds. Release after the keypad provides a confirmation beep. The backlighting LED of the keypad will flash indicating the learn mode.
2. Enter in your predefined 5-digit authority code. Keypad will provide two confirmation beeps.
3. Press and release the button that corresponds to the access number. For example, press (1 / 2) button for access #1 and press (3 / 4) button for access #2. The keypad will provide a confirmation beep after this single button press.
4. Enter new 5-digit access code. The keypad will provide confirmation beeps.
5. Re-enter new 5-digit access code. The keypad will provide confirmation beeps.

After performing the above sequence, the keypad will automatically revert back to default operation mode. Repeat process to assign additional access codes.

Up to 5 different access code can be assigned at one time. As additional access codes are defined, pre-existing access codes are over-written. For example, if a new access code is assigned for access #3, the previous #3 access code is no longer valid.

The following table can be used to document the access code assignment.

User #	User Name	Digit 1	Digit 2	Digit 3	Digit 4	Digit 5
1						
2						
3						
4						
5						

e-ASK I/O Module Features

Locking and Unlocking Confirmation

- After locking either the entry door or compartment doors from **e-FOB** transmitter, the headlights flash once and the siren sounds once. When the entry door and compartment doors are both locked within one minute, the headlights flash and siren sounds twice.
- Locking all doors via vehicle switch or keypad provides headlight flash only.
- Locking confirmation is deactivated while engine is running.

Deactivate Lock Confirmation

The system defaults to confirmation ON with power-up. Horn and headlight confirmation can be toggled off and on from the keypad.

1. Enter valid access code. Hold down (9 / 0) button until double beep sounds.
2. Release. Press (1 / 2) button.

Door Ajar Confirmation

A triple siren chirp sounds if any compartment or entry door is open when the entry and compartment doors are locked. If a door is open, the alarm is not armed.

The following table describes audio/visual activations at various conditions.

Outputs	Single Lock confirmation	Unlock confirmation	Alarm
Siren	Not used	Not used	1 minute or when shut off
Horn	1 chirp	2 chirps	Not used
Headlights	1 flash	2 flashes	1 minute or when shut off

Alarm Mode

After locking entry door and compartment doors within one minute of each other, the system is armed. The alarm is activated when entry door or compartment doors are opened or with a signal from external shock sensing or motion detector. When alarm is triggered, the siren is continuously activated and headlights flash for one minute. Unlocking all doors via FOB transmitter, keypad, or starting the engine deactivates alarm mode.

Timed Dome/Porch Light Activation

The dome/porch light is activated by pressing any keypad button or by unlocking entry door via FOB transmitter. The dome/porch light duration can be varied. Contact your dealer to adjust duration. Starting the engine deactivates the light.

Compartment Light Activation

Compartment lights are activated upon unlocking compartment doors. The activation duration is variable. Contact your dealer to adjust duration. Starting the engine deactivates the lights.

Automatic Locking and Unlocking (optional)

The system may include auto-locking. When auto-locking is enabled, doors are locked 5 seconds after the engine is started. Doors unlock when the engine is turned off. The alarm is not enabled/disabled by automatic locking/unlocking.

Troubleshooting

Problem	Possible Solution
e-FOB Hints	
Button press does not provide correct operation	Verify power to the I/O module and RF receiver.
	Re-teach the FOB transmitter to the receiver. Ensure that only Lock button is pressed while in learn mode.
No operation or intermittent operation	Mount RF receiver away from enclosed metal areas and fully extend antennae.
	Check FOB transmitter battery voltage. Batteries need to be changed every 1-2 years depending on usage.
Alarm mode starts when powered	Press Entry Unlock of FOB transmitter
One particular e-FOB function does not work.	Check wire connection of affected function at RF module, wiring harness, and I/O module.
Lost FOB transmitter	Contact your dealer for a replacement FOB transmitter.
e-PAD Hints	
No response with button press	Verify power to the I/O module.
	Verify that keypad cable is connected. (rest of system will function).
Access code is not recognized	Verify that code has not been changed. Reassign keypad with instructions starting on page 5.
	Confirm use of an access code, not the authority code.
Continuous keypad backlighting is off until a button is pressed.	Vehicle battery voltage has dropped below 11 V.
Unexpected, secure operation occurs	Verify DIP switches are set to correct configuration setting

e-ASK I/O Hints	
No response in any system element	Verify power to the I/O module.
Lights and panic mode do not turn off with ignition start.	Verify that connector J11, pins 7, 8 and 9 are wired properly.
Output relay latches on or off.	Verify that power to relay comes from connector J12, pin 1.
	Cycle power to system. If condition continues, replace relay.

This product has been manufactured with methods to ensure high quality and to meet the high expectations of our customers. TriMark warrants this product to be free from workmanship defects and will remedy issues per TriMark's warranty policy.

Remote transmitter FOBs, batteries, and other equipment subject to normal wear and deterioration may need to be replaced periodically by dealer and/or end user and are not covered by this warranty. TriMark will not be liable for indirect, special, incidental or consequential damages.

Contact TriMark for specific mounting details, such as drawings, placement suggestions, mounting hardware, etc.



500 Bailey Avenue
P.O. Box 350
New Hampton, Iowa 50659 U.S.A.
Tel: 641-394-3188
Fax: 641-394-2392
www.trimarkcorp.com

UM06
18990-02
01/08-3



This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.