

Installing Magnetized door hold backs from AP Products.

Surface prep – Surface must be cleaned and free of contaminants. Hold backs mount to most flat surfaces with an aggressive adhesive tape.

Installation- With magnets together, peel the adhesive tape backer, and press on to the surface. Then peel the other adhesive tape backer and open the door. Press firmly to ensure a good adhesion to both surfaces.

Use- The magnetic hold back is installed and ready to use. Open door until magnets come together and touch.



This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.