

Manual Override Procedure

1. Locate the included flexible shaft in your owner's packet



2. For compact assembly motor 225007 or the 225008, attach a #3 square bit on the end of the motor.
 - a. For all other motors, attach flexible shaft to the 1/4" hex fitting on the end of the motor



3. For compact assembly motor 225007 or the 225008, attach 1/4" socket & ratchet, or drill to the other end and turn in the proper direction to move the room.
 - a. For all other motors, attach 1/4" socket & ratchet, or drill to the other end and turn in the proper direction to move the room.
4. If the cables tighten, and the motor is difficult to turn, **REVERSE THE DIRECTION**.
 - a. Over-torquing can happen, resulting in severe damage to the system.

Note: If using compact assembly motor 225007 or the 225008, if the drive shaft or motor has failed, the manual override can plug directly into the gearbox.



This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.