



INSTALLATION MANUAL

13902

Level of Difficulty

Easy (60 minute install time)

⚠ WARNING

Never exceed the vehicle manufacturer's recommended towing capacity.

Parts List

Qty	Description	#
4	Carriage bolt, 1/2" - 13 x 1 3/4"	1
2	Hex head cap screw, M14 - 2 x 40mm	2
8	Carriage bolt, 1/2" - 13 x 1 1/4"	3
12	Hex flange nut, 1/2" - 13	4
2	Serrated conical washer, 1/2"	5
2	Fishwire, 1/2" x 20"	6
4	Square hole spacer, 1/2" x 1" x 3"	7

Tools Required

Torque wrench	Socket, 22mm
Drill	Socket, 3/4"
Safety glasses	Drill bit, 17/32"

Weight Carrying Capacity

Gross trailer weight (GTW)	8,000 lbs.
Tongue weight (TW)	800 lbs.

Weight Distribution Capacity

Weight distribution (WD)	12,000 lbs.
Weight distribution tongue weight (WDTW)	1,200 lbs.

Torque Specifications

7/16" bolt	42 lb.-ft.
1/2" bolt	64 lb.-ft.
M14 bolt	88 lb.-ft.

Use above torque setting unless otherwise noted

Product Photo



Notes

Before you begin installation, read all instructions thoroughly.

Proper tools will improve the quality of installation and reduce the time required.

Hitch weight: 62 pounds. Drilling may be required.

Refer to the table to the left when securing hardware during the installation process to help prevent damage to the product or vehicle.

Do not overload any part of your towing system.

See the vehicle owner's manual to determine the vehicle tow rating.

Product Registration

CURT Group stands behind our products with industry leading warranties. You can help us continue to improve our product line and help us understand your needs by registering your purchase by visiting:

warranty.curtgroup.com/surveys


At CURT Group, customer is king. We value your feedback and we use that information to make improvements on our products. Please, take a minute and let us know how we are doing.

Step 1

Place the supplied fasteners into position on the vehicle where possible without drilling, per application. The fishwire technique may be required for some applications.

FISHWIRE TECHNIQUE

Insert coiled end of fishwire tool through hitch mounting hole in vehicle frame rail and out the access hole. Pass coiled end of fishwire through spacer and thread bolt into coil. Kink wire to keep spacer separate from bolt as shown. Pull fishwire, spacer and bolt through frame and out mounting hole. Use fishwire to guide hitch during mounting and prevent loss of bolt or spacer inside frame rail.



Step 2

Mount the side plates to the frame rails as shown in the assembly below. (Ford, Chevrolet / GMC and Dodge / Ram out).

Raise the center section into position and loosely secure to the side plates.

Drill remaining holes if necessary. (2003 - 2004 Ford trucks)

Step 3

Install the remaining fasteners. Torque all hardware to the following specifications:

7/16" fasteners to 42 lb-ft.

1/2" fasteners to 64 lb-ft.

M14 fasteners to 88 lb-ft.

ASSEMBLY

Parts List

Qty	Description	#
4	Carriage bolt, 1/2" - 13 x 1 3/4"	1
2	Hex head cap screw, M14 - 2 x 40mm	2
8	Carriage bolt, 1/2" - 13 x 1 1/4"	3
12	Hex flange nut, 1/2" - 13	4
2	Serrated conical washer, 1/2"	5
2	Fishwire, 1/2" x 20"	6
4	Square hole spacer, 1/2" x 1" x 3"	7


Driver-side frame rail
(actual vehicle may differ from image)

Passenger-side frame rail
(actual vehicle may differ from image)

Some GM models have a weldnut in this location

Chevrolet / GMC and Dodge / Ram mounting bracket orientation

Ford mounting bracket orientation





This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.