

57300

DODGE TO GM/FORD OEM 7-WAY ADAPTER

WIRING LOCATION GUIDE GUÍA DE UBICACIÓN DEL CABLEADO IDE D'EMPLACEMENT DES FILS



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

¡DEBE LEERSE PRIMERO!

Debe seguirse todos los pasos para asegurar el correcto funcionamiento del Conector-T. Para verificar la correcta instalación, pruebe conectando una luz de prueba o un remolque debidamente cableado.

À LIRE D'ABORD!

Pour assurer le bon fonctionnement du T-Connector, il faut suivre toutes les étapes. Pour vérifier que l'installation a été bien effectuée, branchez un feu de test ou une remorque correctement filée.

1/5/2011

English

1. Remove the existing 7-Way from the vehicle.
2. Disconnect the vehicle's trailer harness from the 7-Way connector by separating the housings. There is a red lock that will need to be released as shown (A). Take care not to damage the housing's lock.
3. Connect the adapter harness to the vehicle's harness (B). Make sure the connectors are fully inserted with the locking tab in place.
4. Connect the adapter harness your new 7-Way connector (C) and install the new 7-Way connector in the mount location (D).
5. Test all functions for proper operation.

INSTALLATION QUESTIONS? CALL TECHNICAL SUPPORT AT 1-877-287-8634







This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.