

Over-Bed Gooseneck Hitches

Make / Model	Style	Years	Footnotes	Folding Ball Hitch#	Fixed Ball Hitch#	Flat Plate Hitch#	Bracket#
Chevrolet							
C1500	8' bed	88 - 99	--	61052	61100	65500	61503
C2500	8' bed	88 - 00	--	61052	61100	65500	61503
C3500	8' bed	88 - 00	--	61052	61100	65500	61503
K1500	8' bed	88 - 99	--	61052	61100	65500	61503
K2500	8' bed	88 - 00	--	61052	61100	65500	61503
K3500	8' bed	88 - 00	--	61052	61100	65500	61503
Silverado 1500	ALL	07 - 18	--	61052	61100	65500	61331
Silverado 1500	ALL	99 - 06	Z	61052	61100	65500	61341
Silverado 1500 Classic	ALL	07 - 07	Z	61052	61100	65500	61341
Silverado 1500 LD	All	19 - 19	--	61052	61100	65500	61331
Silverado 2500	Excluding Cab & Chassis	99 - 04	Z	61052	61100	65500	61341
Silverado 2500 HD	Excluding Cab & Chassis	01 - 10	Z	61052	61100	65500	61341
Silverado 2500 HD	Excluding Cab & Chassis	11 - 19	Z	61052	61100	65500	61301
Silverado 2500 HD Classic	Excluding Cab & Chassis	07 - 07	Z	61052	61100	65500	61341
Silverado 3500	Excluding Cab & Chassis	01 - 06	Z	61052	61100	65500	61341
Silverado 3500 Classic	Excluding Cab & Chassis	07 - 07	Z	61052	61100	65500	61341
Silverado 3500 HD	Excluding Cab & Chassis	07 - 10	Z	61052	61100	65500	61341
Silverado 3500 HD	Excluding Cab & Chassis	11 - 19	Z	61052	61100	65500	61301
Dodge							
Ram 1500	ALL	94 - 01	--	61052	61100	65500	61509
Ram 2500	Excluding Cab & Chassis	94 - 02	--	61052	61100	65500	61509
Ram 3500	Excluding Cab & Chassis	94 - 02	--	61052	61100	65500	61509
Ford							
F-150	ALL	04 - 13	Z	61052	61100	65500	61321
F-150	ALL	80 - 96	--	61052	61100	65500	61505
F-150	ALL	97 - 03	--	61052	61100	65500	61506
F-150 Heritage	ALL	04 - 04	--	61052	61100	65500	61506
F-250	Excluding Cab & Chassis	80 - 99	--	61052	61100	65500	61505
F-250 Super Duty	ALL	99 - 15	Z	61052	61100	65500	61332
F-350	Excluding Cab & Chassis	80 - 97	--	61052	61100	65500	61505
F-350 Super Duty	Excluding Cab & Chassis	99 - 15	Z	61052	61100	65500	61332
F-450 Super Duty	Excluding Cab & Chassis	08 - 11	Z	61052	61100	65500	61332
GMC							
C1500	8' bed	88 - 99	--	61052	61100	65500	61503
C2500	8' bed	88 - 00	--	61052	61100	65500	61503
C3500	8' bed	89 - 00	--	61052	61100	65500	61503
K1500	8' bed	88 - 99	--	61052	61100	65500	61503
K2500	8' bed	88 - 00	--	61052	61100	65500	61503
K3500	8' bed	88 - 00	--	61052	61100	65500	61503
Sierra 1500	ALL	07 - 18	--	61052	61100	65500	61331
Sierra 1500	ALL	99 - 06	Z	61052	61100	65500	61341
Sierra 1500 Classic	ALL	07 - 07	Z	61052	61100	65500	61341
Sierra 1500 Limited	ALL	19 - 19	--	61052	61100	65500	61331
Sierra 2500	Excluding Cab & Chassis	99 - 04	Z	61052	61100	65500	61341
Sierra 2500 HD	Excluding Cab & Chassis	01 - 10	Z	61052	61100	65500	61341
Sierra 2500 HD	Excluding Cab & Chassis	11 - 19	Z	61052	61100	65500	61301
Sierra 2500 HD Classic	Excluding Cab & Chassis	07 - 07	Z	61052	61100	65500	61341
Sierra 3500	Excluding Cab & Chassis	01 - 06	Z	61052	61100	65500	61341
Sierra 3500 Classic	Excluding Cab & Chassis	07 - 07	Z	61052	61100	65500	61341
Sierra 3500 HD	Excluding Cab & Chassis	07 - 10	Z	61052	61100	65500	61341
Sierra 3500 HD	Excluding Cab & Chassis	11 - 19	Z	61052	61100	65500	61301

Footnotes

Z - No frame drilling required



This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.