

RV TOW Harness Wiring Kit

INSTALLATION INSTRUCTIONS

Fits: Ford Edge

Kit Includes:

- (1) Wiring Harness with 4-Flat Connector
- (1) 48" 4-Flat Extension
- (20) 15" Cable Tie
- (1) 4-Flat Bracket
- (3) #8 Self-Tapping Ground Screw

RV TOW HARNESS INSTALLATION INSTRUCTIONS

1. Read instructions thoroughly before beginning.

2. Open the rear tailgate. Remove floor mats, spare tire cover and side cargo trays on both sides of spare tire. Remove threshold plate and set to the side. Remove cargo tie downs on both sides of vehicle shown in **Figure 1**. Gently pull away side panels taking care not to damage any alignment tabs or damage the panel.



Figure 1

3. Using a 8mm socket remove bolts holding taillights on driver and passenger side. Remove taillights and inspect connectors for dirt & debris and clean if necessary. Set taillights to the side and unseat grommet from body on both sides shown in **Figure 2**. Using an utility knife make a small slit in grommet from center to outside, away from factory wire harness, taking care not to damage any wires.



Figure 2

4. Starting on driver's side route RV harness with connectors containing Yellow wires behind interior side panel and through opening behind taillight where the grommet was removed in Step 3. Position connectors between separated vehicle harness connectors. Press connectors firmly into vehicle connectors until they lock into place. Pull on connectors to ensure locks are engaged.

5. There are two ways to mount ground ring on White wire:

5a. Locate a clean and accessible mounting location on the vehicle near the RV harness ends within reach of white wire and ring terminal. Remove any debris or undercoating to expose a clean metal surface and drill a 3/32" hole.

Caution: Take care not to drill through the body or any exposed surface.

Attach ring terminal on the White wire using the ground screw provided.

5b. Using a 8mm socket remove the bolt holding the ground ring shown in **Figure 3**. Place the ring terminal on RV Harness with vehicle's ground ring and re-attach bolt.



Figure 3

6. Route portion of RV Harness with connectors containing Green wires down to bottom of side wall panel along the rear of vehicle and up behind passenger side panel. Repeat Step 4 for connector plugging.

7. Cut the cable ties on 4-Flat portion of harness. Route the 4-Flat portion of the RV harness to the center of the floor to grommet shown in **Figure 3**. Unseat grommet, make a slit in it and fit around 4-Flat wire. Reseat grommet and it may be necessary to apply silicone to seal grommet where cut was made.



Figure 3

8. Underneath vehicle route 4-Flat wire over exhaust heat shield and around plastic guards to brake lines near front of vehicle. Secure with cable ties along the way.

An alternate routing method is to remove plastic guards and route above them and then replace guards.

Caution: Make sure to avoid areas that contain moving parts or could cut, pinch or burn the wires when routing the 4-flat harness towards the front of the vehicle. Also avoid routing harness near the fuel lines as it may cause the fuel to ignite.

Failure to follow these warnings may cause property damage, personal injury or loss of life.

9. Follow brake lines up into the driver's side of engine compartment, shown in **Figure 4**, until you reach the area behind the driver's side headlight.



Figure 4

10. Locate the front frame rail that goes across the front of the vehicle. Locate a suitable position to mount the 4-Flat bracket shown in **Figure 5**. Using the bracket as a template mark the two holes and drill two 3/32" holes and attach the bracket using the two remaining screws.

Caution: Take care not to drill through the body or any exposed surface.



Figure 5

11. With the 4-flat extension plugged into the RV harness on one end and the motorhome on the other, test that the functions work on the Ford Edge.

These functions will only work on the brake/tail combination lamp.

4-Flat Harness Color Code:

White - Ground

Brown - Tail Lights

Green - Right Turn and Brake Signal

Yellow - Left Turn and Brake Signal

When not in use store the 4-flat extension in the vehicles glove box.

12. At the rear of the vehicle secure any loose wires to the vehicle's crossmember using cable ties provided. Re-install taillights to vehicle.

NOTE: THIS RV HARNESS ALSO INCLUDES A CONNECTION POINT LABELED "FOR TRAILER TOW USE ONLY: TAILLIGHT REQUIRED." IF YOU DECIDE TO LEAVE YOUR RV HARNESS ON THE VEHICLE AT ALL TIMES AND WANT TO TOW A TRAILER SIMPLY PLUG IN 4-FLAT HARNESS.



This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.