

Dodge Factory Harness Adapter #57300

Make / Model	Style	Years
Chrysler		
Aspen	with Factory Tow Package	07 - 08
Dodge		
Dakota	with Factory Tow Package	00 - 09
Durango	with Factory Tow Package	01 - 08
Ram 1500	with Factory Tow Package	00 - 08
Ram 1500 Van	with Factory Tow Package	01 - 03
Ram 2500	with Factory Tow Package	00 - 09
Ram 2500 Van	with Factory Tow Package	01 - 03
Ram 3500	with Factory Tow Package	00 - 09
Ram 3500 Van	with Factory Tow Package	01 - 03
Sprinter 2500	with Factory Tow Package	03 - 09
Sprinter 3500	with Factory Tow Package	03 - 09
Freightliner		
Sprinter 2500	with Factory Tow Package	03 - 09
Sprinter 3500	with Factory Tow Package	03 - 09
Jeep		
Commander	with Factory Tow Package	06 - 10
Grand Cherokee	with Factory Tow Package	00 - 10
Liberty	with Factory Tow Package	05 - 08
Mitsubishi		
Raider	with Factory Tow Package	06 - 09



This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.