



T.I.P. Troubleshooting Information on Power Gear

INSTALLATION OF MILWAUKEE CYLINDER ADDITIONAL GROUND WIRE ON THE 8-PIN CONNECTOR

To insure a adequate ground for Milwaukee Cylinder semi automatic leveling system for the Pace Arrow Gas, the following steps should be adhered to upon installation.

Locate the two foot black spliced wire connected to #1 wire on the 8-pin connector. This wire will have an eyelet to put a bolt or screw through for mounting. The short black wire should be connected to an adequate place for ground. Make sure the point of connection is clean and if possible out of the elements. Check the wire to insure the connection is tight. If the connection cannot be made to a clean surface or mounted tight to the surface use a star washer to obtain a proper connection.



This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.