

SLIDE-OUTS

Tools Required (Fig. 1)
Drill
1/4" Drill Bit
7/16" Wrench
9/16" Wrench

Fig. 1



1. Rotate the cross shaft 90 degrees and drill a new 1/4" hole (Fig. 2).

Fig. 2



2. Reattach motor and cross shaft using:
 - Bolt - 1/4" - 20 x 2 Cap Screw GR8 Yellow Zinc
 - Nut - 1/4" - 20 Top Lock GR2 Zinc

Fig. 3





This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.