

The patented Boat Vent II

***installs quickly and easily,
with no screws or fasteners.***

For use with 3/4" and 7/8" Support Poles

(not included)

#11982

Easy Step-by-Step Installation:

1. Cut or punch a 2 1/4" hole-use this card as a template.
2. Unscrew nut, slide off lower washer.
3. Put lower washer flange up thru hole.
4. Push cap down thru hole, thru lower washer.
5. Screw nut on tightly.
6. Push pole into coupler and adjust height.



Use this template to
make hole in cover

Taylor Made Products

www.taylormadeproducts.com

A Member of The Taylor Made Group

Gloversville, NY 12078



This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.