



DOCKPRO™ *Corner Dock Cushion* *Installation Instructions*

#45984

Hybrid construction means soft compressible foam where you want it and tough high density foam where you need it. The inner core of the new foam bumper is a lower density EVA foam (2.8 pounds per cubic foot) and the outer (front and back) pieces are tougher, higher density PE foam (8.7 pcf).

Instructions:

- 1) Position the corner dock bumper into its mounting location and mark the 6 mounting hole locations with a pencil.*
- 2) Drill the mounting holes with a 5/16" drill bit.*
- 3) Using six 1/4" diameter bolts secure the bumper (for mounting to 2" thick lumber a 2.75" long bolt is recommended).*
- 4) Secure the bolts with washers and lock nuts on the back side.*



Foam plugs are supplied to give the bumper a clean, finished look.

Taylor Made Products

65 Harrison St., Gloversville, NY 12078

www.taylormadeproducts.com

Made in China

A Member of The Taylor Made Group

© 2017 Taylor Made Group, LLC



This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.