

Correctly wired in pairs**Incorrectly wired together**

Crossing one or more wires from the jack motors to the control box pigtail can cause many issues, including but not limited to:

- Excessive amp draw.
- Blown fuses on the control box.
- One side not fully retracting.
- One side not fully extending.
- Motors failing due to over-heating.





This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.