



## MIRAGE ILLUSTRATED PARTS LIST

*For Mirage Service Procedures and Parts Availability, Contact Carefree*




### Electrical (12V Controls)



### Automatic Wind Retraction Components

**This System DISCONTINUED - Limited Parts Availability**



*Electronic components shown are not used for the Direct Response system.  
For Direct Response Electronics, Refer to "ELECTRONIC SYSTEMS AND COMPONENTS"*

| <b>Item</b>            | <b>Part Number</b> | <b>Description</b>                    | <b>Notes</b>                              |
|------------------------|--------------------|---------------------------------------|-------------------------------------------|
| <b>1</b>               | R001077SAT-xxx     | Mounting Plate                        |                                           |
| <b>2</b>               | R036333-001        | Backing Plate                         |                                           |
| <b>3</b>               | R040548-001        | Cover, Backing Plate                  |                                           |
| <b>4</b>               | R001054            | End Plug, Roller Tube, Left           |                                           |
| <b>5</b>               | R062755-001        | Glide Bushing, LH                     |                                           |
| <b>6</b>               | R001055            | Motor Assy                            |                                           |
| <b>7</b>               | R030886-001        | Drive Gear, Motor                     |                                           |
| <b>8</b>               | R030885-001        | Crown, Motor                          |                                           |
| <b>9</b>               | R062779-001        | Gear Assy, Hand Crank                 |                                           |
| <b>10</b>              | R040551-001        | Spacer                                |                                           |
| <b>10a</b>             | R001546-RP         | Crank Handle Assy                     |                                           |
| <b>11</b>              | R001052            | End Plate, Housing                    |                                           |
| <b>12</b>              | R001051XXX         | End Cap, Standard, LH                 |                                           |
| <b>13</b>              | R001056XXX         | End Cap, Standard, RH                 |                                           |
| <b>14</b>              | R012531-XXL096     | Spring Arm Assy, LH                   |                                           |
|                        | R001616XXX         | Spring Arm Assy, LH                   |                                           |
| <b>15</b>              | R062764-001        | Knuckle, LH, Spring Arm, Mirage       |                                           |
| <b>16</b>              | R019261-23L        | Connector, LH, Lead Rail, Mirage      |                                           |
| <b>17</b>              | R012531-XXR096     | Spring Arm Assy, RH                   |                                           |
|                        | R001617XXX         | Spring Arm Assy, RH                   |                                           |
| <b>18</b>              | R062765-001        | Knuckle, RH, Spring Arm, Mirage       |                                           |
| <b>19</b>              | R019261-23R        | Connector, RH, Lead Rail, Mirage      |                                           |
| <b>20</b>              | R001173XXX-xxx     | Lead Rail                             |                                           |
| <b>21</b>              | R001053            | End Plate, Lead Rail                  |                                           |
| <b>24</b>              | R019468-006        | Switch Kit                            |                                           |
| <b>25</b>              | R060487-001        | Relay Box                             |                                           |
| <b>26</b>              | R060443-004        | Switch, SPST, Momentary ON            | Ext/Ret<br>ON/OFF                         |
| <b>27</b>              | R060443-005        | Switch, DPST                          |                                           |
| <b>28</b>              | R019633-006        | Switch Plate                          |                                           |
| <b>29</b>              | R060452-001        | Control Box                           |                                           |
| <b>30</b>              | NLA                | Anemometer                            |                                           |
| <b>33</b>              | SR0017             | Remote Control                        | Wind Sensor<br>Wind Sensor<br>Wind Sensor |
| <b>ITEMS NOT SHOWN</b> |                    |                                       |                                           |
| <b>34</b>              | R012458-001        | Hardware Pack, Motorized, Aftermarket |                                           |
| <b>35</b>              | R012458-002        | Hardware Pack, Manual, Aftermarket    |                                           |
| <b>36</b>              | R012459-001        | Hardware Pack, OEM                    |                                           |
| <b>37</b>              | R001179            | Arm Shim Kit                          |                                           |

- Notes:
1. XXX = Color; xxx = Length in inches.
  2. End Caps w/ Lights and Speakers have been discontinued and are no longer available.
  3. Item 14 (LH Spring Arm Assy) contains items 15 and 16 (LH Knuckle and Lead Rail Connector).
  4. Item 17 (RH Spring Arm Assy) contains items 18 and 19 (RH Knuckle and Lead Rail Connector).
  5. The anemometer is no longer available. The part is discontinued and no longer manufactured.
  6. Motor (item 6) is furnished with drive gear (item 7) and crown (item 8).
  7. If ordering lead rail (item 20) specify if awning is manual or motorized and if the gear or motor is LH or RH.
  8. Switch Kit (item 24) contains switches and bezel. Kit replaces all previous 12V switches.

---



---

# This manual is provided courtesy of **RV Tech Cheat Sheet**



**Professional resources for the whole RV industry — free.**

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.

---



---

**[rvtechcheatsheet.com/manuals](https://rvtechcheatsheet.com/manuals)**

**Find thousands more RV manuals, wiring diagrams and parts lists**

**RV techs:** share fixes, ask questions and learn from each other.

**Join our free Facebook group →**

---



---

Follow proper safety practices. If in doubt, consult a professional RV technician.