


--- OPTIONAL COMPONENTS
AND WIRING



DANGER!
SHOCK HAZARD!

DISCONNECT POWER
SUPPLY BEFORE
SERVICING ANY
ELECTRICAL
COMPONENT.

AVIS!

DEBRANCHES LES FILS ELECTRIQUES AVANT
L'ENTRETIEN ET LE DE TOUT COMPARTIMENT
OU ORANGE ELECTRIQUES.

PLUG CONNECTS TO CEILING ASSEMBLY. SEE DIAGRAM
SUPPLIED WITH CEILING ASSEMBLY FOR ADDITIONAL WIRING.

1976-603 *



This manual is provided courtesy of RV Tech Cheat Sheet



Professional resources for the whole RV industry — *free.*

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

[Join our free Facebook group →](#)



Follow proper safety practices. If in doubt, consult a professional RV technician.