


PLUG CONNECTS TO CEILING  
ASSEMBLY. SEE DIAGRAM  
SUPPLIED WITH CEILING ASSEMBLY  
FOR ADDITIONAL WIRING.



## **ANGER! SHOCK HAZARD!**

DISCONNECT POWER SUPPLY BEFORE SERVICING  
ANY ELECTRICAL COMPONENT.

## **AVIS!**

DEBRANCHES LES FILS ELECTRIQUES AVANT  
L'ENTRETIEN ET LE DE TOUT COMPARTIMENT  
OU ORANGE ELECTRIQUES.

---



---

# This manual is provided courtesy of **RV Tech Cheat Sheet**



**Professional resources for the whole RV industry — free.**

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.

---



---

**[rvtechcheatsheet.com/manuals](https://rvtechcheatsheet.com/manuals)**

**Find thousands more RV manuals, wiring diagrams and parts lists**

**RV techs:** share fixes, ask questions and learn from each other.

**Join our free Facebook group →**

---



---

Follow proper safety practices. If in doubt, consult a professional RV technician.