



REPAIR PARTS LIST

FOR

6536C881 AND 6536C891 SERIES

TWO TON PACKAGED HEAT PUMP

RV Products
A Division of Airxcel, Inc.
P.O. Box 4020
Wichita, KS 67204

6536C881
6536C891
SERIES




CODE	USED ON MODEL	PART NUMBER	DESCRIPTION	NO. REQ.
1.	881	6536B611	Basepan With Insulation	1
	891	6536C601	Basepan With Insulation	1
2.	881	6795A602	Top With Insulation	1
	891	6536A602	Top With Insulation	1
3.	881	6795A603	Back Panel With Insulation	1
	891	6536A607	Back Panel With Insulation	1
4.	All	6795-605	Main Bulkhead With Insulation	1
ns	881	6795A607	Return Air Door	1
5.	All	6795A606	Secondary Bulkhead With Insulation	1
6.	All	6795B109	Corner Panel	1
7.	All	6536-603	O.D. Access Panel	1
8.	All	6536-603	I.D. Access Panel With Insulation	1
9.	All	6795B110	Right Corner Panel	1
10.	All	6536C512	Electric Panel Assembly	1
11.	All	6795A104	Divider Shelf	1
12.	All	6795-111	Filler Plate	1
13.	All	6795B112	Electric Box Door	1
14.	All	1452-1481	Outdoor Coil	1
15.	All	1452-1471	Indoor Coil	1
16.	All	6795A125	Drain Pan	1
17.	All	6531-504	Drain Valve	1
18.	All	1450A2009	Compressor	2
19.	All	6759-3791	Overload (MRA #2753-117)	2
20.	All	6759-3081	Compressor Foot Pkg. (3/Pkg.)	2
21.	All	1218-302	Large Hose Clamp	2
22.	All	6536-113	Reversing Valve Bracket	2
23.	All	6536-5301	Reversing Valve Assembly	2
24.	All	1460-1081	Solenoid Coil	2
25.	All	1454-2501	Restrictor	2
26.	All	6536A515	O.D. Blower Housing	1
27.	All	1472-1161	O.D. Blower Wheel	1
28.	All	6795A150	O.D. Blower Venturi	2
29.	All	6795B313	Safety Screen	1
30.	All	6795-3011	O.D. Blower Motor Mount	1
31.	All	6795A3031	Sleeve/Grommet Pkg. (4/Pkg.)	2
32.	All	1468A3029	O.D. Blower Motor	1
33.	All	6536-514	O.D. Bearing Bracket Assembly	1
34.	All	6536-3011	O.D. Pillow Block Bearing	1
35.	All	1499-5631	O.D. Blower Capacitor (12.5 Mfd/370V)	1
36.	All	1499-950	Rubber Capacitor Boot	1
37.	881	6795A518	I.D. Blower Housing	1
	891	6536-518	I.D. Blower Housing	1
38.	All	1472-1001	I.D. Blower Wheel	1
39.	All	6795-151	I.D. Blower Venturi	2
40.	All	6795-302	I.D. Blower Motor Mount	1
41.	All	1468A3129	I.D. Blower Motor (Reversible)	1
42.	All	1499-5461	I.D. Blower Capacitor (7.5 Mfd/370V)	1
43.	All	6795-3151	High Voltage Terminal Board	1




6536C881
6536C891
SERIES

CODE	USED ON MODEL	PART NUMBER	DESCRIPTION	NO. REQ.
44.	All	6795-117	High Voltage Isolator	1
45.	All	1216-229	Grounding Lug	1
46.	All	1497-9041	Start Device	2
47.	All	1499-5661	Compressor Run Capacitor (25 Mfd/370V)	2
48.	All	1460-1131	Compressor Relay	2
49.	All	6536C3209	P.C. Board Kit	1
50.	All	7330A3231	Freeze Switch	2

6536C881
6536C891
SERIES







This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.