



REPAIR PARTS LIST

FOR


6538-751

SERIES HIGH EFFICIENCY

TWO TON PACKAGED HEAT PUMPS (LONG)

RV Products
A Division of Airxcel, Inc.
P.O. Box 4020
Wichita, KS 67204

6538 -751 SERIES



CODE	USED ON MODEL	PART NUMBER	DESCRIPTION	NO. REQ.
1.	All	6538-616	Basepan Assembly With Insulation	1
2.	All	6538A502	Top With Insulation	1
3.	All	6538A503	Bulkhead With Insulation	1
4.	All	6538-505	Blower Door Assembly	1
5.	All	6538-507	Filler Panel	1
6.	All	6538-121	Tube Bracket	1
7.	All	6538-118	Compressor Door Assembly	1
8.	All	6538-119	Electric Panel Assembly	1
9.	All	6537-107	Divider Shelf	1
10.	All	6795-117	High Voltage Isolator	1
11.	All	6538-108	Electric Box Door	1
12.	All	1452-173	Condenser Coil	1
13.	All	1452-172	Evaporator Coil	1
14.	All	6538-114	Drain Pan	1
15.	All	6795-200	Drain Valve	1
16.	All	1450-2339	Compressor	2
17.	All	1450-0181	Overload	2
18.	All	6759-3081	Compressor Foot Pkg. (3/Pkg.)	2
19.	All	6538-532	Reversing Valve Assembly	2
20.	All	1460-1081	Solenoid Coil	2
21.	All	6538-552	Liquid Line Assembly (Includes Expansion Valve) Circuit 1	1
21a.	All	6538-553	Liquid Line Assembly (Includes Expansion Valve) Circuit 2	1
22.	All	6538-302	Fan Block	1
23.	All	1472-5031	O.D. Fan Blade	1
24.	All	6538-110	Fan Bulkhead	1
25.	All	6538-122	Support Bracket	1
26.	All	1212-0361	O.D. Sleeve/Grommet Pkg. (4/Pkg.)	1
27.	All	1468-3339	O.D. Fan Motor	1
28.	All	1499-5461	O.D. Fan Capacitor (7.5 Mfd/370V)	1
29.	All	1499-951	Rubber Capacitor Boot	1
30.	All	6536-3011	Pillow Block Bearing (I.D.)	1
31.	All	1472-1151	I.D. Blower Wheel	1
32.	All	6535A287	I.D. Blower Venturi	1
33.	All	6795-302	I.D. Blower Motor Mount	1
34.	All	1468A3219	I.D. Blower Motor (Reversible)	1
35.	All	6537A590	I.D. Blower Housing Assembly	1
ns	All	7330A3231	Coil Sensor	2
36.	All	1460-1131	Compressor Relay	2
37.	All	1499-5731	Compressor Run Capacitor (45 Mfd/370V)	2
38.	All	6795-3151	High Voltage Terminal Board	1

6538-751 SERIES



CODE	USED ON MODEL	PART NUMBER	DESCRIPTION	NO. REQ.
39.	All	1216-228	Grounding Lug	1
40.	All	1497-0891	Start Capacitor (108-130 Mfd/165V)	2
41.	All	6535C3201	P.C. Board	1
42.	All	1499-5461	I.D. Blower Capacitor (7.5 Mfd/370V)	1
43.	All	1497-4131	Start Relay	2

ns = not shown

Note: All parts with three digit suffix numbers are “Special Order” Parts. These parts are subject to factory availability and require extra time for delivery.



This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.