



RV Products Division

**REPAIR PARTS LIST
FOR
6538 “B”
SERIES HIGH EFFICIENCY
TWO TON PACKAGED HEAT PUMPS (TALL)**

WARRANTY INFORMATION

PARTS RETURN


“Air Conditioning” in-warranty parts subject to return to Airxcel, Inc. must be sent prepaid to the following address. Always include your company’s claim or work order along with the Airxcel, Inc. invoice generated from the shipment of the replacement part.

Airxcel, Inc.
RV Products Division
Attn: Warranty Return
3050 N. St. Francis
Wichita, KS 67219

WRITTEN CORRESPONDENCE

All written correspondence (no parts) should be sent to the following address:

Airxcel, Inc.
RV Products Division
Dept. 546
P.O. Box 4020
Wichita, KS 67204



6538"B" SERIES



RV Products Division

CODE	USED ON MODELS	PART NUMBER	DESCRIPTION	NO. REQ.
1.	All	6538A601	Basepan Assembly With Insulation	1
2.	All	6538-502	Top With Insulation	1
3.	All	6538-503	Bulkhead With Insulation	1
4.	All	6538-505	Blower Door Assembly	1
5.	All	6538-507	Filler Panel	1
6.	All	6537-106	Tube Bracket	1
7.	All	6538-109	Compressor Door Assembly	1
8.	All	6537-550	Electric Panel Assembly	1
9.	All	6537-111	Divider Shelf	1
10.	All	6795-117	High Voltage Isolator	1
11.	All	6538-108	Electric Box Door	1
12.	All	1452-173	Condenser Coil	1
13.	All	1452-172	Evaporator Col	1
14.	All	6538-314	Drain Pan	1
15.	All	6795-200	Drain Valve	1
16.	All	1450-2149	Compressor	2
17.	All	1450-0081	Overload	2
18.	All	6759-3081	Compressor Foot Pkg. (3/Pkg.)	2
19.	All	6538-520	Reversing Valve Assembly (System 1)	1
	All	6537A533	Reversing Valve Assembly (System 2)	1
20.	All	1460-1081	Solenoid Coil	2
21.	All	1454-259	By-Flow Restrictor	2
22.	All	6536A515	O.D. Blower Housing	1
23.	All	1472-1161	O.D. Blower Wheel	1
24.	All	6795A150	O.D. Blower Venturi	2
25.	All	6795B313	Safety Screen	1
26.	All	6795A3011	O.D. Blower Motor Mount	1
27.	All	6795A3031	Sleeve/Grommet Pkg. (4/Pkg.)	2
28.	All	1468A3029	O.D. Blower Motor	1
29.	All	1499-5631	O.D. Blower Capacitor (12.5 Mfd/370V)	1
30.	All	1499-951	Rubber Capacitor Boot	2
31.	All	6536-514	Bearing Bracket (Blower)	2
32.	All	6536-3011	Pillow Block Bearing (I.D. or O.D.)	2
33.	All	1472-1151	I.D. Blower Wheel	1
34.	All	6537A287	I.D. Blower Venturi	1
35.	All	6795-302	I.D. Blower Motor Mount	1
36.	All	1468A3219	I.D. Blower Motor (Reversible)	1
37.	All	6537A590	I.D. Blower Housing Assembly	1
ns	All	7330A3231	Coil Sensor	2
38.	All	1460-1131	Compressor Relay	2
39.	All	1499-5671	Compressor Run Capacitor (30 Mfd/370V)	2
40.	All	6795-3151	High Voltage Terminal Board	1
ns.	All	1216-228	Grounding Lug	1
41.	All	8333A9021	Start Device Pkg.	2
42.	All	6535C3209	P.C. Board	1
43.	All	1499-5461	I.D. Blower Capacitor (7.5 Mfd/370V)	1

ns = not shown

SPECIAL ORDER PARTS:

NOTE: All parts with three digit suffix numbers are "Special Order" Parts. These parts are subject to factory availability and require extra time for delivery.



This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.