



REPAIR PARTS LIST

FOR

6636 “D” SERIES HIGH EFFICIENCY

PACKAGED AIR CONDITIONERS

RV Products
A Division of Airxcel, Inc.
P.O. Box 4020
Wichita, KS 67204

6636 “D” SERIES




CODE	USED ON MODEL	PART NUMBER	DESCRIPTION	NO. REQ.
1.	All	6535B511	Basepan Assembly With Insulation	1
2.	All	6535A502	Top With Insulation	1
3.	All	6636-144	Side Panel Right	1
4.	All	6535A519	Bulkhead With Insulation	1
5.	All	6636-140	Lower Filler Panel	1
6.	All	6535A545	Blower Door Assembly	1
7.	All	6636A341	Filler Panel	1
8.	All	6636-115	Tube Bracket	1
9.	All	6535A548	Access Door	1
10.	All	6636B530	Electric Panel Assembly	1
11.	All	6636-111	Divider Shelf	1
12.	All	6795-117	High Voltage Isolator	1
13.	All	6535B346	Electric Box Door	1
14.	All	1452A1541	Condenser Coil	1
15.	All	1452B1531	Evaporator Coil	1
16.	All	6636A104	Drain Pan	1
17.	All	6595-200	Drain Valve	1
18.	All	1450A2119	Compressor	2
19.	All	1450-0071	Overload (MRA #2753-117)	2
20.	All	6759-3081	Compressor Foot Pkg. (3/Pkg.)	2
21.	All	6636B131	CKT #1 Suction Line Assembly Coil	1
22.	All	6636B129	CKT #2 Suction Line Assembly Coil	1
23.	All	6636-126	CKT #1 Discharge Line Assembly	1
24.	All	6636-125	CKT #2 Discharge Line Assembly	1
25.	All	6636-130	CKT #1 Suction Line Assy. Compressor	1
26.	All	6636-520	Liquid Line Assembly - Complete	2
27.	All	6536A515	O.D. Blower Housing	1
28.	All	1472-1161	O.D. Blower Wheel	1
29.	All	6795A150	O.D. Blower Venturi	2
30.	All	6795B313	Safety Screen	1
31.	All	6795A3011	O.D. Blower Motor Mount	1
32.	All	6795A3031	Sleeve/Grommet Pkg. (4/Pkg.)	2
33.	All	1468A3029	O.D. Blower Motor	1
34.	All	1499-5631	O.D. Blower Capacitor (12.5 Mfd/370V)	1
35.	All	1499-951	Rubber Capacitor Boot	1
36.	All	6536-514	O.D. Bearing Bracket (Blower)	1
37.	All	6536-3011	Pillow Block Bearing (I.D. or O.D.)	1
38.	All	1472-1151	I.D. Blower Wheel	1
39.	All	6535A287	I.D. Blower Venturi	1
40.	All	6795A3021	I.D. Blower Motor Mount	1

CODE	USED ON MODEL	PART NUMBER	DESCRIPTION	NO. REQ.
41.	All	1468A3219	I.D. Blower Motor	1
42.	All	6535C589	I.D. Blower Housing	1
43.	All	7330A3231	Freeze Switch	1
44.	All	1460-1131	Compressor Relay	2
45.	All	1499-5671	Compressor Run Capacitor (30 Mfd/370V)	1
46.	All	6795-3151	High Voltage Terminal Board	1
47.	All	1216-228	Grounding Lug	2
48.	All	8333A9021	Start Device	1
49.	All	See #50	Start Device	1
50.	All	6535C3201	P.C. Board Kit	1
51.	All	1499-5461	I.D. Blower Capacitor (7.5 Mfd/370V)	1

Note: All parts with three digit suffix numbers are “Special Order” Parts. These parts are subject to factory availability and require extra time for delivery.

Note: “A” Model units have new higher capacity indoor blower assembly.

6636 "D" SERIES





This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.