


FREEDOM WM ILLUSTRATED PARTS LIST



WM501

Item	Part Number	Description	Notes
1	R001618WHT	Endcap, LH, Top, White	
	R001618BLK	Endcap, LH, Top, Black	
	R001618GRY	Endcap, LH, Top, Satin	
2	R001619WHT	Gear Assy, Manual Crank, White	1
	R001619BLK	Gear Assy, Manual Crank, Black	1
	R001619SAT	Gear Assy, Manual Crank, Satin	1
3	R001637WHT	Motor Assy, LH, White	2,4
	R001637BLK	Motor Assy, LH, Black	2,4
	R001637GRY	Motor Assy, LH, Satin	2,4
4	R001620WHT	Endcap, RH, White	
	R001620BLK	Endcap, RH, Black	
	R001620GRY	Endcap, RH, Satin	
4a	R040792	Plug	
5	R001621	Ramp Kit, Leadrail	
6	R001622	Roller Tube Endplug, LH	
7	R001623	Roller Tube Endplug, RH	
8	R001624WHT	End Plate, Lead Rail, LH, White	
	R001624BLK	End Plate, Lead Rail, LH, Black	
	R001624GRY	End Plate, Lead Rail, LH, Satin	
9	R001625WHT	End Plate, Lead Rail, RH, White	
	R001625BLK	End Plate, Lead Rail, RH, Black	
	R001625GRY	End Plate, Lead Rail, RH, Satin	
10	R001626	Knuckle Assy, Case, LH	3
11	R001627	Knuckle Assy, Case, RH	3
12	R001628	Assy, Pivot, LH	3
13	R001629	Assy, Pivot, RH	3
14	R001630	Hardware Pack, Arm Attach, 1 Arm	
15	R012530-TB68L	Spring Arm Assy, LH	Used with 2.44 Meter 3
	R012530-TB76L	Spring Arm Assy, LH	Used with 2.57 Meter 3
	R012530-TB94L	Spring Arm Assy, LH	Used with 3 Meter & Up 3
16	R012530-TB68R	Spring Arm Assy, RH	Used with 2.44 Meter 3
	R012530-TB76R	Spring Arm Assy, RH	Used with 2.57 Meter 3
	R012530-TB94R	Spring Arm Assy, RH	Used with 3 Meter & Up 3
17	R001654-001	Vertical Support Leg, LH	Used with 2.44 & 2.57 Meter 5
	R001654-002	Vertical Support Leg, LH	Used with 3 Meter & Up 5
18	R001654-101	Vertical Support Leg, RH	Used with 2.44 & 2.57 Meter 5
	R001654-102	Vertical Support Leg, RH	Used with 3 Meter & Up 5
19	R00394	Carport Foot	
20	R019283-001	Kit, Bottom Bracket, Satin	qty: 2
	R019283-005	Kit, Bottom Bracket, White	qty: 2
	R019283-006	Kit, Bottom Bracket, Black	qty: 2
21	R001546-RP	Crank, Telescoping	
22	R001605	Switch Kit	4
23	R019311-001	Hardware Pack, FreedomWM, 2.43-4m	
24	R019311-003	Hardware Pack, FreedomWM, 4.5-5m	

- NOTES
1. Gear Assy (item 2) includes gear and inner endcap assembled. Parts not available separately.
 2. Motor Assy (item 3) includes motor, inner endcap, bearing and one-way drive. Parts not available separately.
 3. Attaching hardware not included with spring arm assemblies. Order item 14.
 4. A motor upgrade kit (SR0097XXX) is available for manual crank awnings and includes motor assembly (item 3), switch kit (item 22) and attaching hardware.
 5. Original vertical support legs uses a gray flipper latch. Replacement latch kit is R00144. Kit not available if leg has orange flipper latch.



This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.