



FURRION

Furrion Ltd. (Furrion) is a wholly owned subsidiary of Lippert Components, Inc. (Lippert) Furrion Ltd. Furrion Innovation Center & Institute of Technology

- 22244 Innovation Drive, Elkhart, IN 46514-5514, USA
- Toll free/Numéro gratuit/Línea telefónica gratuita: 1-800-789-3341
- Email/Courriel/Correo electrónico: support@furrion.com

©2007-2023 Furrion Ltd. Furrion® and the Furrion logo are trademarks licensed for use by Furrion Ltd. and registered in the U.S. and other countries.

FURRION.COM
For Patent Info: www.Lippert.com/patents




The contents of this manual are proprietary and copyright protected by Lippert. Lippert prohibits the copying or dissemination of portions of this manual unless prior written consent from an authorized Lippert representative has been provided. Any unauthorized use shall void any applicable warranty. The information contained in this manual is subject to change without notice and at the sole discretion of Lippert. Revised editions are available for free download from lippert.com.

Please recycle all obsolete materials.


For all concerns or questions, please contact Lippert.

Ph: 432-LIPPERT (432-547-7378) | Web: lippert.com | Email: customerservice@lci1.com


2. Mount on wall



CONNECT POWER




INSTALL REMOTE CONTROL BATTERY



BASIC OPERATION

Soundbar Buttons



Remote control Button	Function
	Power on/off.
	Short press to switch the source mode to Bluetooth; Press and hold it for 3s to unpair and launch pairing again. (BT Name: Furrion SB 2.1)
Source	Select the audio source (AUX, RCA, COAX, BT).
	Mute or un-mute the audio output.
	Skip to the previous track in BT mode.
	Start or pause playback in BT mode.
	Skip to the next track in BT mode.
	Adjust volume.
Music	Select the different EQ mode.
TV	
Movie	
Sport	

Tip: See the complete user manual online for detailed functional explanation.

FURRION

Aurora™ Bluetooth Soundbar




Quick Start Guide

Model: FSBNN30MSS-BL
Lippert No.: 2021123835

This quick start guide will help you install and use the device properly.
For further support and to download the complete user manual please visit www.furriion.com/support.

WHAT'S IN THE BOX





NOTE: Product design and packaging may change without notice.

CONNECT





- Open the protective cover on the back by removing the screws then connect the cables.

Note: All external devices and cables shown in the diagram are for reference only and not included in the package.


1. Connect Soundbar with TV



2. Connect Soundbar with other devices





- After the connections are completed, close the protective cover and tighten the screws for the best weatherproof effect.



INSTALL

IMPORTANT: Before final installation, check by powering the Soundbar on to make sure the unit operates properly.

1. Install Soundbar to the compatible Furriion Aurora™ TV





This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.