

LEWMAR®


68000967 3 BUTTON WIRELESS CONTROL

68000968 5 BUTTON WIRELESS CONTROL

RECOMMENDED WIRING DIAGRAMS FOR LEWMAR PRODUCTS:

- V700, Pro-Series, Pro-Fish, Pro-Sport with Sealed Contactor
- V700, Pro-Series, Pro-Fish, Pro-Sport with Pre-wired Contactor in box
- V1, V2, V3 & V5 with Sealed Contactor
- V1, V2, V3 & V5 with Contactor in Box
- V4 with Sealed Contactor
- V4 with Contactor in Box
- H2 & H3
- 140TT2.0kW Electric Thruster (5 Button Only)
- 140TT2.2kW, All 185TT, 250TT & 300TT Electric Thrusters (5 Button Only)

CIRCUIT BREAKER




Permanent Magnet Dual Direction Contactor - 68000939 (0052531 - Old)

Wiring Diagram 12VDC

Used on: Pro-Sport, Pro-Series/Fish 700 & 1000, V700, Concept 0, Sprint 600 & 1000, Horizon 600F & 900F

L E W M A R


CIRCUIT BREAKER



ELECTRIC SWITCHES




ROCKER
SWITCH
(68000593)



FUSE 3A


CONTROL
BOX
(12V-0052509)
(24V-0052510)





BATTERY
12/24VDC

Permanent Magnet Dual Direction Control Box - 0052509/10
Wiring Diagram 12/24VDC
Used on: Pro-Sport, Pro-Series/Fish 700 & 1000, V700, Concept 0, Sprint 600 & 1000, Horizon 600F & 900F


LEWMAR




Split Field Dual Direction Control Box - 68000129/130
Wiring Diagram 12/24VDC only
Used on: Concept 1, V1, V2, V3, V5




Split Field Dual Direction Contactor
Wiring Diagram 12/24VDC
Used on: Concept 1, V1, V2, V3, V5




Series Wound Dual Direction Contactor
Wiring Diagram 12/24VDC
Used on: Concept 3, V4







Wiring Diagram 12/24VDC
Used on: H2 & H3




For Terminals 1 to 5
Refer to windlass wiring
Diagrams






To Thruster
Solenoid loom

Thruster Positive Switching system
Wiring Diagram 12VDC
Used on: 140TT2.0KW only.

LEWMAR



* For Terminals 1 to 5
 Refer to wireless wiring
 Diagrams



To Thruster Black box
 Via Automatic Battery switch if fitted
 and/or P/S Battery switch if fitted

Thruster Negative Switching system
 Wiring Diagram 12/24VDC
 Used on: 140TT, 2.2KW; All 185TT, 250TT, 300TT

LEWMAR



This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.