

ELECTRICAL DECK SWITCH TYPES FOR IDENTIFICATION ONLY

Detail

Lewmar Windlass Switch (80mm Diameter) Phased Out 2010



68000597 FOOT SWITCH WHITE SET
68000598 FOOT SWITCH BLACK SET

Lewmar Switch (80mm Diameter) Phased Out 2006



69000015 ELEC SWITCH CLOSED (LEWMAR®)
69000016 ELEC SWITCH CLOSED (UP)
69000017 ELEC SWITCH CLOSED (DOWN)
69000018 ELEC SWITCH OPEN LEWMAR®



This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.