


2 X 2 HYDRAULIC THROUGH FRAME SLIDE-OUT COMPONENTS

SLIDE-OUTS


NOTE: Part numbers are shown for identification purposes only. Not all parts are available for individual sale. All parts with a link to the Lippert Store can be purchased.



Callout	Part #	Description
Kit - A	281331	2.5 X 2.5 Gear Pack
B	700612	15 Tooth Gear (10DP/20PA)
C	271138	Rod, 2 X 2 Drive Shaft
D	271137	2 X 2 Gear Pack Roller - .625 X 2.365
E	372865	Bearing Side Plate, Graphite - 4.000 X 1.641

2 X 2 HYDRAULIC THROUGH FRAME SLIDE-OUT COMPONENTS

SLIDE-OUTS




Callout	Part #	Description
F*	122739	18 Tooth Gear (12 DP/ 14.50 PA)
G*	328044	15 Tooth Gear (10DP/20PA), Heavy Duty
H	105892	Rear Roller Shaft
I	104474	Rear Roller
J	103480	Wear Tab (Original)
		Wear Tab (Current)
K	277882	Wear Tab (for 317322 Outboard Inner Arm)
L	113535	Front Cylinder Bracket
M	106040	Rear Cylinder Bracket
N	106030	Trim Plate

NOTE: *18 Tooth Gear may be used as a substitute for the 15 Tooth Gear in kits A where needed.

NOTE: *Heavy duty gear is 15 tooth, and may be used as a substitute for the 15 Tooth Gear in kit A where needed.

2 X 2 HYDRAULIC THROUGH FRAME SLIDE-OUT COMPONENTS

SLIDE-OUTS




NOTE: See Room Bar Measurement Chart ([TI-052](#))

Callout	Part #	Description
O	102357	Stiffener
P	106059	Hat Channel
Q	104851	Slide-Out Mounting Bracket
R	141792	1 3/8" Adjustable Head Assembly
S	159624	Standard Weld-On Head Assembly
T	163049	Flush Adjustable Head Assembly
U	173593	Standard Flush Fixed Head Assembly
V	173594	Standard Flush Adjustable Head Assembly
W	183949	Room Bar (Use for up to 80")
	183950	Room Bar (Use for up to 154")
NOTE: Brackets can be shipped loose.		

2 X 2 HYDRAULIC THROUGH FRAME SLIDE-OUT COMPONENTS


SLIDE-OUTS



Callout	Part #	Description
X	145734	Outboard Outer Arm (Idler and Drive)
Y	145736	Outboard Inner Arm (15 Tooth)
Z	173204	Inboard Outer Arm 76" (Idler and Drive)
AA	163778	Inboard Inner Arm (15 Tooth)
AB	161014	Inboard Outer Arm 69" (Idler and Drive)
AC	159389	Inboard Outer Arm 70" (Idler and Drive)
AD	301393	Inboard Inner Arm (15 Tooth)
AE	296090	Outboard Inner Arm (15 Tooth)
AF	296121	Inboard Inner Arm (15 Tooth, No Rear Roller)
AG	317322	Outboard Inner Arm (No Rear Roller) OBSOLETE
NOTE: Standard slide-out arms have 15 teeth.		

2 X 2 HYDRAULIC THROUGH FRAME SLIDE-OUT COMPONENTS


SLIDE-OUTS



Callout	Part #	Description
AH	334649	2 x 2 Outboard Inner Tube (18 Tooth)
AI	334650	2 x 2 Inboard Inner Tube (18 Tooth)
AJ	354184	Hydraulic Cylinder 43"
	342328	Hydraulic Cylinder 38"
	354179	Hydraulic Cylinder 30"
	339031	Hydraulic Cylinder 24"
AK	141109	O-Ring Face Seal Straight Fitting
AL	173738	O-Ring Face Seal Elbow Fitting
AM	120639	Hydraulic Interior Slide-Out Switch
AN	140530	6Prong Interior Switch with Wall Plate

2 X 2 HYDRAULIC THROUGH FRAME SLIDE-OUT COMPONENTS

SLIDE-OUTS




Callout	Part #	Description
Kit - AO	157523	Slide-Out Cross Shaft Assembly
AP	117630	Outer Cross Shaft
AQ	117606	Inner Cross Shaft
AR	123365	Cross Shaft Insert
AS	118092	Nut, 1/4" - 20
AT	119066	Bolt, 1/4" - 20 x 2"

2 X 2 HYDRAULIC THROUGH FRAME SLIDE-OUT COMPONENTS

SLIDE-OUTS


AU



AV



AW



AX



Callout	Part #	Description
AU*	141111	Hydraulic Power Unit
AV	157505	Yellow Fill Cap
AW	118246	Dual Polarity Solenoid
AX	167576	Power Unit Motor

NOTE: *Hydraulic Power unit may appear as either example displayed above. Function and reservoir capacity are identical for each variation.



This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.