

# 3,500 LB TORSION AXLE COMPONENTS

## AXLES AND SUSPENSION

### Electric Brake Assembly




| Part #                 | Description                                             |
|------------------------|---------------------------------------------------------|
| <a href="#">297956</a> | Electric Brake; 10" x 2.25" (Left Hand)                 |
| <a href="#">296649</a> | Electric Brake; 10" x 2.25" Self-Adjusting (Left Hand)  |
| <a href="#">139380</a> | Electric Brake; 10" x 2.25" with Park (Left Hand)       |
| <a href="#">298274</a> | Electric Brake; 10" x 2.25" (Right Hand)                |
| <a href="#">296650</a> | Electric Brake; 10" x 2.25" Self-Adjusting (Right Hand) |
| <a href="#">139381</a> | Electric Brake; 10" x 2.25" with Park (Right Hand)      |

### Hydraulic Brake Assembly



| Part #                 | Description                                            |
|------------------------|--------------------------------------------------------|
| <a href="#">132047</a> | Hydraulic Brake; 10" x 2.25" (Right Hand)              |
| <a href="#">132048</a> | Hydraulic Brake; 10" x 2.25" (Left Hand)               |
| 179868                 | Hydraulic Brake; 10" x 2.25" Free Backing (Right Hand) |
| 179869                 | Hydraulic Brake; 10" x 2.25" Free Backing (Left Hand)  |


### Disc Brake Assembly



| Part # | Description                  |
|--------|------------------------------|
| 130033 | Disc Brake; 545 - 1/2" Studs |

# 3,500 LB TORSION AXLE COMPONENTS

## AXLES AND SUSPENSION



| Callout                                                                                                      | Part #                 | Description                                   |
|--------------------------------------------------------------------------------------------------------------|------------------------|-----------------------------------------------|
| A                                                                                                            | <a href="#">122065</a> | Rubber plug for lubed grease caps             |
| B                                                                                                            | <a href="#">122067</a> | Dust cap, for 2" bore, super lube             |
|                                                                                                              | <a href="#">122099</a> | Dust cap, for 2" bore, non-lube               |
| C                                                                                                            | <a href="#">122075</a> | Cotter pin; 1.75"                             |
| D                                                                                                            | <a href="#">122081</a> | Spindle nut; 1"                               |
| E                                                                                                            | <a href="#">119214</a> | Spindle washer, round ID                      |
| F                                                                                                            | <a href="#">119215</a> | Spindle washer, for spindle with D-flat       |
| G                                                                                                            | <a href="#">119216</a> | Spindle locking tang washer                   |
| H                                                                                                            | <a href="#">122089</a> | Outer bearing cone, L44649                    |
| I                                                                                                            | <a href="#">125102</a> | Outer bearing cup, L44610                     |
| J                                                                                                            | <a href="#">122092</a> | Inner bearing cone, L68149                    |
| K                                                                                                            | <a href="#">124296</a> | Inner bearing cup, L68111                     |
| L                                                                                                            | 122087                 | Grease seal, double lip, 1.72" ID x 2.565" OD |
| <b>NOTE:</b> Grease Seals can be purchased on packs of 2 or 10. They can be purchased <a href="#">here</a> . |                        |                                               |
| M                                                                                                            | <a href="#">122460</a> | Brake hub; 5 - 4 1/2"; 1/2" Stud Size         |

---



---

# This manual is provided courtesy of **RV Tech Cheat Sheet**



**Professional resources for the whole RV industry — free.**

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.

---



---

**[rvtechcheatsheet.com/manuals](https://rvtechcheatsheet.com/manuals)**

**Find thousands more RV manuals, wiring diagrams and parts lists**

**RV techs:** share fixes, ask questions and learn from each other.

**Join our free Facebook group →**

---



---

Follow proper safety practices. If in doubt, consult a professional RV technician.