


ABOVE FLOOR SLIDE-OUT DOUBLE RAIL COMPONENTS

SLIDE-OUTS


NOTE: Part numbers are shown for identification purposes only. Not all parts are available for individual sale. All parts with a link to the Lippert Store can be purchased.



Callout	Part #	Description
A	124366	Key for Crown Gear
B	101232	Cross Shaft Adapter
C	116656	Drive Shaft
D	124188	Stop Block with Set Screw
E	126158	Stop Block
F	118353	Cam Follower
G	116658	Crown Gear (26 Teeth)
H	116551	Bronze Bushing
I	116597	Manual Override Nut
J	125554	Crown Gear Set Screw (2x)
K	*113457	30 3/4" Hat Assembly with Gear Rack
NOTE: (*) For alternate lengths, contact the LCI Parts department.		


ABOVE FLOOR SLIDE-OUT DOUBLE RAIL COMPONENTS

SLIDE-OUTS



Callout	Part #	Description
L	141425	Klauber M-500 Motor
M	133612	Venture 18:1 Dual Motor/Drive Shaft (OBSOLETE)
	117292	Venture 18:1 Dual Motor/Drive Shaft (Current)
	117293	Venture 28:1 Dual Motor/Drive Shaft
N	119226	Crank Handle
O	173628	White Slide-Out Switch Kit (OBSOLETE)
	117461	White Slide-Out Switch Kit (Current)
P	117460	Black Slide-Out Switch Kit
Q	117426	Black Switch
	129003	White Switch
R	117419	Black Switch Plate
	117420	White Switch Plate
S	178436	Switch Wire Harness

SLIDE-OUTS



Callout	Part #	Description
T	276401	Slide-Out Controller; 30 Percent Lower



This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.