



DOUBLE BIN UNDER
CHASSIS STORAGE
OEM INSTALLATION MANUAL

TABLE OF CONTENTS

Introduction	2
Safety	2
Resources Required	3
Installation	3
Post Installation	4
Notes	5

Introduction

Double Bin Under Chassis Storage products from Lippert help save space and fit everything needed for a home away home. The detachable storage boxes bolt on to the RV chassis (hardware not included) and are perfect for cables, cleaning supplies and other miscellaneous camping items.

Note: Images used in this document are for reference only when assembling, installing and/or operating this product. Actual appearance of provided and/or purchased parts and assemblies may differ.

Additional information about this product can be obtained from lci1.com/support or by downloading the free LippertNOW app. The app is available on Apple App Store® for iPhone® and iPad® and also on Google Play™ for Android™ users. Apple App Store®, iPhone®, and iPad® are registered trademarks of Apple Inc. Google Play™ and Android™ are trademarks of Google Inc.

Safety

Read and understand all instructions before installing or operating this product. Adhere to all safety labels.

This manual provides general instructions. Many variables can change the circumstances of the instructions, i.e., the degree of difficulty, operation and ability of the individual performing the instructions. This manual cannot begin to plot out instructions for every possibility, but provides the general instructions, as necessary, for effectively interfacing with the device, product or system. Failure to correctly follow the provided instructions may result in death, serious personal injury, severe product and/or property damage, including voiding of the Lippert limited warranty.

WARNING

The "WARNING" symbol above is a sign that a procedure has a safety risk involved and may cause death or serious personal injury if not performed safely and within the parameters set forth in this manual.

WARNING

Failure to follow instructions provided in this manual may result in death, serious personal injury and/or severe product and property damage, including voiding of the component warranty.

CAUTION

The "CAUTION" symbol above is a sign that a safety risk is involved and may cause personal injury and/or product or property damage if not safely adhered to and within the parameters set forth in this manual.

CAUTION

Always wear eye protection when performing service, maintenance or installation procedures. Other safety equipment to consider would be hearing protection, gloves and possibly a full face shield, depending on the nature of the task.

Resources Required


- 1-2 people, depending on task
- Cordless or electric drill or screw gun
- 4 - 1/4" x 1 1/2" Self Tapping Screws
- 8 - 5/16" - 20 x 1" Hex Head Bolts
- 16 - 5/16" Flat Washers
- 8 - 5/16" - 20 Hex Lock Nuts
- 11/32" drill bit
- 1/2" combination wrench
- 1/2" socket and ratchet

Installation

Note: For safety and convenience, use two people for installation.

1. Determine location for under chassis storage bin. The carrier can be located behind the rear jacks of the trailer but must remain within the departure angle of the trailer. (Fig.1).

Fig. 1




Note: If installing under chassis storage bin with spare tire carrier (Fig 2B), determine orientation for spare tire carrier to permit curbside access to the winch extension (Fig. 2C).


2. Clamp the under chassis storage unit to the frame at the four mounting plate locations (Fig. 2A).

Note: A 1/4" x 1 1/2" self-tapping screw can be used with a 3/8" hex head socket or nut driver for under chassis positioning in lieu of clamping. Self-tapping screw should not be used as a replacement for the bolt, washer, and nut attachment hardware.

Fig. 2




3. Install two 5/16" - 20 - 1" bolts with 5/16 flat washers (Fig. 3A), through the frame and through the mounting plate.



4. Install one 5/16" flat washer and one 5/16 - 20 hex lock nut (Fig. 3B) on each bolt.
5. Tighten hex lock nuts and remove the clamps if used.

Post Installation

1. Disengage the lock pin (Fig. 4) by pulling it out, and begin extending the storage bin by pulling on the bin handle.
2. Continue to extend the storage bin out until the locking pin re-engages. The bin is now completely extended.
3. Disengage the lock pin again by pulling it out, and begin retracting the storage bin by pushing on the bin handle.
4. Release the lock pin and continue pushing in on the bin until the lock pin re-engages.



Notes

[illegible]



The contents of this manual are proprietary and copyright protected by Lippert. Lippert prohibits the copying or dissemination of portions of this manual unless prior written consent from an authorized Lippert representative has been provided. Any unauthorized use shall void any applicable warranty. The information contained in this manual is subject to change without notice and at the sole discretion of Lippert. Revised editions are available for free download from lippert.com.

Please recycle all obsolete materials.

For all concerns or questions, please contact Lippert
Ph: 432-LIPPert (432-547-7378) | Web: lippert.com | Email: customerservice@lci1.com



This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.