

Note: Part numbers are shown for identification purposes only. Not all parts are available for individual sale. All parts with a link to the Lippert Store can be purchased.



Callout	Part #	Description
A	805310	Edge Awning Drive Head Assembly w/ Gear Pack and Override (Black)
	805312	Edge Awning Drive Head Assembly w/ Gear Pack and Override (White)
B	771407	Drive Head Front Cover (Black)
	771409	Drive Head Front Cover (White)
C	771408	Drive Head Back Cover (Black)
	771410	Drive Head Back Cover (White)
D	771384	Motor Side Mount (Black)
E	275071	Rubber Grommet (for Manual Override Opening)




Callout	Part #	Description
F	805311	Edge Awning Idler Head Assembly (Black)
	805313	Edge Awning Idler Head Assembly (White)
G	771412	Idler Head Front Cover (Black)
	771414	Idler Head Front Cover (White)
H	771413	Idler Head Back Cover (Black)
	771415	Idler Head Back Cover (White)
I	771385	Idler Side Mount (Black)


AWNINGS



Callout	Part #	Description
J	373566	Awning Motor, Standard
	723566	Awning Motor, High Torque
K	418203	Gear Pack
L	773638	Hex Screw, 1/4" - 14 x 2"
M	771389	Rod
N	266156	Screw, #6 x 1/2"
O	327445	Spring Pin, 1/8" x 3/4"
P	266143	Bushing
Q	266137	E-Clip Retainer, 1/2"
R	201478	Rubber Bumper



Callout	Part #	Description
S	806622	Edge Awning Slide Pitch Arm Assembly without Serenity Light (White)
	806623	Edge Awning Slide Pitch Arm Assembly without Serenity Light (Black)
	806625	Edge Awning Slide Pitch Drive Arm Assembly with Serenity Light (White)
	806626	Edge Awning Slide Pitch Drive Arm Assembly with Serenity Light (Black)
	806628	Edge Awning Slide Pitch Idler Arm Assembly with Serenity Light (White)
	806629	Edge Awning Slide Pitch Idler Arm Assembly with Serenity Light (Black)
T	773929	Edge Pitch Assembly
U	773641	Edge Awning Wall Mount, 58"
V	346882	Gas Strut, 18" Extend (158 lbs.)
W	346888	Bracket, 1.50" x 1.39" x .85"
X	237315	Klamp-Tite Rivet, 3/16" x 1.300



Callout	Part #	Description
Y	773642	Edge Awning Inner Drive Arm, 46 $\frac{3}{16}$ "
Z	793009	Edge Awning Outer Lever Arm (Drive) - 7"
	793010	Edge Awning Outer Lever Arm (Idler) - 7"
AA	431583	Washer, $\frac{1}{2}$ "
AB	800827	Retaining Ring
AC	800272	Washer, $\frac{1}{4}$ "
AD	800273	Washer, $\frac{3}{8}$ "
AE	701388	Hex Screw, #14 - 10 x 1 $\frac{1}{4}$ "
AF	805935	Vinyl Tube



Callout	Part #	Description
AG	760287	LED Serenity Light, 7"
AH	730559	Bezel Serenity Light, 7"
AI	801135	Spacer .386" x .600" x .375"
AJ	801136	Spacer .386" x .600" x .813"
AK	801137	Spacer .266" x .386" x .375"
AL	801138	Spacer .266" x .500" x .813"
AM	800824	Pin, .250" x 2.47"
AN	800825	Pin, .370" x 2.15"
AO	800826	Pin, .370" x 2.97"
AP	807864	Pin, .370" x .875"
AQ	805597	Edge Awning Center Support



This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.