



Purpose

This document provides the overall dimensions of the Equa-Flex® rubberized equalizer variations. The dimensions shown represent an unloaded and not installed component. Due to the rubber compressing when installed on a unit, the dimensions will vary from unit to unit and with unit overall weight loads.

NOTE: Short or long designations for triple axles are determined by the spacing between the axles due to how they will look or how the load will be spread. This measurement is either 33" or 35". Standard Equa-flex products have a smaller weight range and allow for both configurations.


Axle Products			
Figure	Description	Lippert Part Number	Aftermarket Part Number
Tandem			
1	Equa-Flex, Tandem axle, non-greasable, up to 3.5K	145539	NA
	Equa-Flex, Tandem axle, non-greasable, 3K-6K	159401	279687
	Equa-Flex, Tandem axle, greasable, 3K-6K	159348	NA
2	Equa-Flex, Tandem axle, non-greasable, 5K-8K	145545	279688
	Equa-Flex, Tandem axle, greasable, 5K-8K	145546	NA
3	Equa-Flex, Spread tandem axle, non-greasable, 3.5K-5.2K	207186	314336
Triple			
4	Equa-Flex, Triple axle, short, non-greasable, 5K-8K	145547	NA
	Equa-Flex, Triple axle, short, greasable, 5K-8K	145548	NA
5	Equa-Flex, Triple axle, standard, non-greasable, 3K-6K	167407	281314
	Equa-Flex, Triple axle, standard, greasable, 3K-6K	168493	NA
6	Equa-Flex, Triple axle, long, non-greasable, 5K-8K	145549	NA
	Equa-Flex, Triple axle, long, greasable, 5K-8K	145550	279689



LIPPERT
COMPONENTS®

Equa-Flex Dimensions-Tandem Axles


Tandem Axle, Up to 3.5K and 3K-6K (Hanger Spacing: Up to 29.5")






LIPPERT
COMPONENTS®

Tandem Axle, 5K-8K (Hanger Spacing: 29.5" and 30.5")



Spread Tandem Axle, 3.5K-5.2K (Hanger Spacing: 34")






LIPPERT
COMPONENTS®

Equa-Flex Dimensions-Triple Axles

Triple Axle, Short, 5K-8K (Hanger Spacing: 29.5" / 33" / 29.5")


Fig. 4






LIPPERT
COMPONENTS®

Triple Axle, Standard, 3K-6K (Hanger Spacing: 29.5" / 33" / 29.5")



Triple Axle, Long, 5K-8K (Hanger Spacing: 30.5" / 35" / 30.5")





This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.