


GROUND CONTROL® 2.0 COMPONENTS


LEVELING AND STABILIZATION



Callout	Part #	Description
A	241846	Standard Landing Gear
B	241845	Extended Landing Gear
C	241844	Leveling Jack
D	297788	Footpad
E	280296	Pan Head Screw; #10 x 7/8"
F	228031	Manual Override Nut
G	241795	Tuson Motor
H	179015	Gear Box
I	275403	Mounting Bracket
J	119113	Bolt-On Pull Pin
K	225598	Snapper Pin; 3" x 3/8"
L	245794	Rear Leveling Jack Harness
	277984	Middle Leveling Jack Harness (OBSOLETE)
	245795	Landing Gear Harness

GROUND CONTROL® 2.0 COMPONENTS

LEVELING AND STABILIZATION



Callout	Part #	Description
M	234802 421484	LCD Touch Pad (original) LCD Touch Pad (current)
N	232201	Rear Sensor
O	232937	LCD Touch Pad Harness
P	243688	Rear Sensor Harness
Q	245796	Power and Ground Harness
R	242623	Ground Control 2.0 4 Point Controller
S	276452	Ground Control 2.0 6 Point Controller



This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.
