




GROUND CONTROL® TT LEVELING OCTP COMMON COMPONENTS


LEVELING AND STABILIZATION



Callout	Part #	Description
A	421366	Power Tongue Jack
B	116112	Scissor Jack Crank Handle
C	429140	Ground Control TT Leveling Label
D	643324	Level Up Label
E	428191	TT Leveling Ground Control Label

GROUND CONTROL® TT LEVELING OCTP COMMON COMPONENTS








LEVELING AND STABILIZATION



Callout	Part #	Description
F	425585	4-Pin Pigtail Harness
G	305115	Hall Effect Right Rear Sensor Harness
	306298	Hall Effect Left Rear Sensor Harness
	307489	Hall Effect Right Front Sensor Harness
	307490	Hall Effect Left Front Sensor Harness
H	426526	Power and Ground Supply Harness
I	421372	Tongue Jack Harness
J	331116	Canbus Data Harness
K	243688	Leveling Sensor Harness 35'
L	434431	Leveling Sensor Harness 15'
M	329080	Canbus Power Connector Harness

GROUND CONTROL® TT LEVELING OCTP COMMON COMPONENTS

LEVELING AND STABILIZATION



Callout	Part #	Description
N	423094	Leveling Sensor
O	425306	Auto Leveling Control Touch Pad
P	406345	OneControl Touch Panel
Q	329164	Linc® Remote (Optional)
R	675725	Leveling Sensor Mounting Plate
S	333041	Canbus Terminating Resistor
T	434376	Flange Nut 3/8" x 16
U	663511	Flange Bolt 3/8" x 16



This manual is provided courtesy of RV Tech Cheat Sheet



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.