


SLIDE-OUTS

Power Unit - 12V DC Motor with Pump and Reservoir



EXTEND ports for the extension of the Full Wall Slide-out System are positioned on the block with the flow divider. The RETRACT ports are positioned on the small square block on the retract side of the pump unit. Page 6 of the "Hydraulic Full Wall Slide-out System" represents the first version of the stand alone pump unit. This configuration showed the EXTEND and RETRACT ports in the opposite orientation of the pump unit shown above. The configuration above shows the current version of the "Hydraulic Full Wall Slide-out System" pump unit.

As a supplier of components to the RV industry, safety, education and customer satisfaction are our primary concerns. Should you have any questions, please do not hesitate to contact us at (574) 537-8900 or by email at customerservice@lci1.com. Self-help tips, technical documents, product videos and a training class schedule are available at www.lci1.com or by downloading the MyLCI app.



This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.