

ELECTRONICS

Purpose

This document provides the steps to install and remove an In-Wall® Harness Clip from an In-Wall motor harness.

⚠ CAUTION

Moving Parts can pinch, crush or cut. Keep clear and use caution.

Resources Required

- In-Wall Harness Clip

Installation

1. Install the top end of the In-Wall Harness Clip (Fig. 1A) onto the top edge of the motor harness.
2. Press the bottom of the In-Wall Harness Clip (Fig. 1B) onto the bottom edge of the motor harness until it snaps in place.

Removal

1. Press on the inside bottom edge of the In-Wall Harness Clip (Fig. 2A) to release the clip from the bottom of the motor.
2. Lift the top end of the In-Wall Harness Clip up and off from the top edge of the motor harness to fully remove the clip.

Fig. 1





Fig. 2





This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.