



JACK-IT® BICYCLE RACK ASSEMBLIES

STORAGE AND CONVENIENCE

Jack-IT Bicycle Rack




Jack-IT PowerTower



JACK-IT® BICYCLE RACK ASSEMBLIES


STORAGE AND CONVENIENCE

Jack-IT BikeWing




BikeWing can be installed on:


PowerTower of Jack-IT
(Stinger only)



Shank of Bump-IT
(Y-shaped base only)




Receiver tube of BikeBase
(Stinger or Y-shaped base)



JACK-IT® BICYCLE RACK ASSEMBLIES

STORAGE AND CONVENIENCE

BikeBase






JACK-IT® BICYCLE RACK ASSEMBLIES

STORAGE AND CONVENIENCE

Hitch-IT: BikeBase/BikeWing Combo Unit






JACK-IT® BICYCLE RACK ASSEMBLIES

STORAGE AND CONVENIENCE

Bump-IT





This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.