


LEVEL-UP® TOWABLE LCD 5TH WHEEL

LEVELING & STABILIZATION


4-Point Assembly



Power Unit Assembly



14K Landing Gear




Controller



LCD Control Touchpad



8K Leveling Jacks




Rear Leveling Sensor


LEVEL-UP® TOWABLE LCD 5TH WHEEL

LEVELING & STABILIZATION

6-Point Assembly



Controller





Power Unit Assembly




LCD Control Touchpad




8K Rear Leveling Jacks



14K Landing Gear



8K Mid Leveling Jacks



Rear Leveling Sensor



This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.