


LEVEL-UP® MOTORIZED LEVELING ASSEMBLY


LEVELING AND STABILIZATION

Hydraulic Power Unit




NOTE: Hydraulic Power Unit may be found in various locations, normally in a compartment.

Touch Pad & Harness



NOTE: Touch pad may be found near the driver.


Rear Sensor & Harness



NOTE: Rear Sensor may be found near the rear axle.

NOTE: Component locations shown are an approximation and will vary per manufacturer's specifications.

Controller




NOTE: Controller may be found close to the center (front-to-rear and side-to-side) of the coach, normally in a protected enclosure.

Front Leveling Jacks x 2



Rear Leveling Jacks x 2





This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.