

## LEVELING AND STABILIZATION

### To Connect to Truck

1. Turn touch panel "on." Display will read "level...jacks down."
2. Push "left" and "right" button at the same time and release. (Camper will return to position where sequence for auto level started, not necessarily where it was dropped off truck).
3. Hitch unit to truck (check to see if hitch is latched).
4. Push "up" arrow until display reads auto retract. Push "enter."
5. Push "enter" (all jacks should fully retract).
6. Turn touch panel "off."

**NOTE:** When operating in temperatures below 30° F, inconsistent performance may occur in the auto retract mode. The combination of low battery and low temps may cause the system to turn off before the jacks are fully retracted. If this should happen, operate the system in the manual mode to get the jacks to fully retract.

### CAUTION

**When operating in any mode and under all conditions, ALWAYS check to see if the jacks are fully retracted before starting to travel. Failure to retract jacks prior to travel may cause damage to the unit or tow vehicle.**

---



---

# This manual is provided courtesy of **RV Tech Cheat Sheet**



**Professional resources for the whole RV industry — free.**

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.

---



---

**[rvtechcheatsheet.com/manuals](https://rvtechcheatsheet.com/manuals)**

**Find thousands more RV manuals, wiring diagrams and parts lists**

**RV techs:** share fixes, ask questions and learn from each other.

**Join our free Facebook group →**

---



---

Follow proper safety practices. If in doubt, consult a professional RV technician.