



Picnic Double Gazebo 16' x 8'

Installation and Owner's Manual

(For Aftermarket Applications)

Table of Contents

Introduction	1
Quick facts:	1
Safety	2
Set-up	2
Privacy Screen	3
Latern/Light Hooks	4
Take Down	4
Maintenance	4

Introduction

Take shelter from bugs and take in the breeze while entertaining your guests in a spacious Picnic Popup Gazebo 16' x 8' from Lippert.

Additional information about this product can be obtained from lci1.com/support or by using the LippertNOW app. Replacement kits can be ordered from <https://store.lci1.com/> or by using the LippertNOW app.

The LippertNOW app is available for free on Apple App Store® for iPhone® and iPad® and also on Google Play™ for Android™ users.

App Store® and iPad® are registered trademarks of Apple Inc.
Google Play™ and Android™ are trademarks of Google Inc.

Quick facts:

- Breathable mesh screen walls to enjoy fresh, bug-free air.
- Comfortably accommodates eight to twelve people in 128 sq. ft. of space.
- Designed with a hub system that allows for easy set up and tear down within seconds.
- Includes 5 tie downs and 11 heavy-duty stakes for secure fastening. One carry bag also included (Fig.1).
- Water-resistant material keeps moisture out.
- Provides protection against harsh sun exposure.
- Made from flame-retardant material.
- Item dimensions: 16' x 8'.
- Item weight: 39 lbs.
- Breezy, bug-free entertaining.

Kit PN #2022114836



Fig.1



Picnic Popup Gazebo 16' x 8'

Installation and Owner's Manual (For Aftermarket Applications)

Safety

Read and fully understand all instructions before installing or using this product.

Adhere to all safety labels.

⚠ WARNING

THE "WARNING" SYMBOL ABOVE IS A SIGN THAT A PROCEDURE HAS A SAFETY RISK INVOLVED AND MAY CAUSE DEATH OR SERIOUS PERSONAL INJURY IF NOT PERFORMED SAFELY AND WITHIN THE PARAMETERS SET FORTH IN THIS MANUAL.

⚠ WARNING

INJURY OR DEATH MAY RESULT FROM FIRE IF SHELTER IS EXPOSED TO OPEN FLAME. SHELTER IS NOT FIREPROOF. DO NOT USE OPEN FLAME PRODUCTS INSIDE SHELTER. SHELTER FABRIC IS TREATED WITH FIRE RETARDANT. APPLICATION OF ANY FOREIGN SUBSTANCE MAY RENDER THE FLAME RETARDANT PROPERTIES INEFFECTIVE.

⚠ CAUTION

THE "CAUTION" SYMBOL ABOVE IS A SIGN THAT A SAFETY RISK IS INVOLVED AND MAY CAUSE PERSONAL INJURY AND/OR PRODUCT OR PROPERTY DAMAGE IF NOT SAFELY ADHERED TO AND WITHIN THE PARAMETERS SET FORTH IN THIS MANUAL.

Set-up

⚠ WARNING

USE ALL PROVIDED METHODS OF SECURING THE FABRIC TO ITS FRAMING: NYLON FASTENER STRAPS, TIES AND GUY LINES/ ROPES WHERE LOCATED.

THIS PRODUCT IS NOT ENGINEERED FOR EXTREME WEATHER, CLIMATES OR ENVIRONMENTS.

TO PREPARE FOR "SURPRISE" ADVERSE CONDITIONS, HOWEVER, MAKE SURE GUY LINES/ ROPES ON THE STRUCTURE ARE SUFFICIENTLY TAUT BETWEEN THE STRUCTURE AND STAKE, ADJUST AS NEEDED.

1. Find a clear and level site for your shelter. Remove from case and undo ties (Fig.2). Stand the shelter up on the center hub.



Fig.2

2. Open the shelter with the roof facing up, with the poles (Fig.3A) on the inside. Pull out the hub at the center of the side panels (Fig.3B) while holding the roof line with the opposite hand and stepping on the shelter skirt base to help pull the side panel out (Fig.3C). Repeat this step for each side panel.



Fig.3



Picnic Popup Gazebo 16' x 8'

Installation and Owner's Manual (For Aftermarket Applications)

3. Enter through the door and push up on the roof center hubs (Fig.4A) for the two cabins up until erect.




Fig.4

4. Assemble and install the door poles inside the gazebo on each side of the door (Fig. 4B). Insert one end of the pole into the webbing loop at the top. Secure the pole to the gazebo with hook and loop fasteners at the middle and bottom.

5. Fasten the center support strapbuckle on the ground inside the gazebo. Stake out the gazebo properly using the guy lines and stakes (Fig. 5).



Fig.5



Completed Picnic Double Gazebo with
Front Opening Panels Closed

⚠ WARNING

AFTER SET-UP CHECK THE CORNERS OF THE ROOF FABRIC AND MAKE SURE ROOF LINE IS PROPERLY POSITIONED ON FRAMING OTHERWISE WATER MAY COLLECT ON THE ROOF LINE. WATER ADDS WEIGHT, WHICH WEAKENS THE OVERALL STRUCTURE. AVOID POSSIBLE COLLAPSE BY CHECKING AND REMOVING ANY WATER ACCUMULATION THAT MAY OCCUR.

Privacy Screen

1. A privacy screen (Fig.6A) is available to install in the middle of the two cabins.
2. Attach the toggle to the ring (Fig.6B) on the gazebo side panels for installing.



Fig.6

3. Open the zipper in the privacy screen center for access.



Picnic Popup Gazebo 16' x 8'

Installation and Owner's Manual (For Aftermarket Applications)

Latern/Light Hooks

The Picnic Double Gazebo comes equipped with two lantern/light hooks (Fig.7A) that have adjustable straps. The straps are attached to the roof hub in each cabin.




Fig.7

Take Down

1. Remove the privacy screen
2. Disconnect the floor buckle strap.
3. Remove and disassemble door poles.

CAUTION

**BE CAUTIOUS TO NOT USE EXCESSIVE FORCE
WHEN REMOVING THE POLE STRUCTURES.**

4. Remove all stakes.
5. Push in on the side panel hub (Fig.3B) from the outside to collapse side panel. Repeat this step for all side panels. Push down on the roof until collapsed.
6. Grab one corner of the Picnic Double Gazebo base and fold over in half. Fold remaining corners over until the Gazebo is the same shape as it was at the start of installation.
7. Carefully lift and insert disassembled Picnic Double Gazebo into the carry bag, as well as the stakes, guy lines, door poles and privacy screen.

Maintenance

- Picnic Double Gazebo is NOT machine washable. Picnic Double Gazebo is NOT machine dryable.
- To clean the product, hand wash using mild dish soap and soft bristle brush. Allow the fabric to completely air dry.
- Wipe down all parts - steel, plastic, and fiberglass before putting away for the next season's use. Salt from ocean air can cause damage.
- DO NOT store Picnic Double Gazebo while wet. Storing wet can cause mildew.
- Salt, mildew and other causes and subsequent effects are NOT covered under the limited warranty.



Manual information may be distributed as a complete document only, unless Lippert provides explicit consent to distribute individual parts.

All manual information is subject to change without notice. Revised editions will be available for free download at lippert.com. Manual information is considered factual until made obsolete by a revised version.

Please recycle all obsolete materials and contact Lippert with concerns or questions.



This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.