



T.I.P. Troubleshooting Information on Power Gear

TOUCH PAD REPLACEMENT FOR P/N 500535, 500675 AND 500629

CAUTION NOTES:

1. Do not plug or unplug any connector to the electronic touch pad while "power" is on. Turn key to "off" position.
2. Do not allow the electronic touch pad to touch any metal or screws during insertion into dashboard mounting zone. Circuit board contact with metal may result in failure of the electronic touch pad.
3. Disconnect the pump harness from the chassis harness prior to installation of the touch pad.

REMOVAL:

- 1) Remove the two screws on the touch pad.
- 2) Gently maneuver the touch pad out of the dash, being careful not to pull excessively on the wiring.
- 3) Remove the interface connector from the back of the touch pad.

INSTALLATION:

- 1) Install the interface harness to the back of the new touch-pad
- 2) Carefully install the new touch pad in position, make sure the interface harness stays properly connected to the touch pad.
- 3) Reinstall the two screws holding the touch pad in place.



This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.