



NOTE: Part numbers are shown for identification purposes only. Not all parts are available for individual sale. All parts with a link to the Lippert Store can be purchased.



	ITEM spare part	Description
1	2022012758	Upper rail end cap Vanscreen color black
2	2022012759	Adjusting bottom plate Vanscreen color black
3	2022012760	Adjusting upper plate Vanscreen color black
4	2022012761	Pillar upper corner Vanscreen color black
5	2022012762	Upper handle cap Vanscreen color black
6	2022012763	Chute handle corver Vanscreen color black
7	2022012764	Bottom rail end cap Vanscreen color black
8	2022012765	Pillar bottom corner Vanscreen color black
9	2022012766	Bottom handle cap Vanscreen color black
10	2022012767	Bottom handle chute Vanscreen color black
11	2022012768	Roll 5 x 8 G 02 ZB
12	2022012769	Chipboard screw 3 x 20 countersunk head black
13	2022012771	Screw 3 x 30 rounded head black
14	2022012772	Headless screw 4 x 5 black
15	2022012770	Screw 3,9 x 13 self tapping rounded head black
16	2022013117	Screw 3 x 20 self tapping countersunk head zinc.

PROMASTER SLIDING DOOR COMPONENTS

DOORS





This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.