



HAPPIJAC[®]

A Division of Lippert Components Inc.

Release Lever Mechanism INSTALLATION

1. Drop in camming mechanism as shown in (Fig. 1).
2. Snap lever into right side of cam and plastic plug into left side. (Fig. 2).
3. Install drive coupler and spring as shown in (Fig. 3).



Fig. 1

4. With cam lever up, drop motor head in place and secure with washer and plastite screw provided. **Note:** It may be necessary to insert the crank handle into the drive socket and turn slowly until parts mesh and motor head drops into place.




Fig. 2




Fig. 3



This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.