




**Fig. 1 - Wireless Remote Module Part #165257**



**Fig. 2 - Wireless Remote Key Fob Part #179839**




**Fig. 3**



1. Push and hold blue reset button (Fig. 3A) on wireless remote module for approximately 5 seconds until red light (Fig. 3B) illuminates.

**Fig. 4**



2. Push and hold either arrow button (Fig. 4C) on the key fob for approximately 3 seconds until the red light on the module goes out.
3. Key fob is now reset.

As a supplier of components to the RV industry, safety, education and customer satisfaction are our primary concerns. Should you have any questions, please do not hesitate to contact us at (574) 537-8900 or by email at [customerservice@lci1.com](mailto:customerservice@lci1.com). Self-help tips, technical documents, product videos and a training class schedule are available at [www.lci1.com](http://www.lci1.com) or by downloading the MyLCI app.

---



---

# This manual is provided courtesy of **RV Tech Cheat Sheet**



**Professional resources for the whole RV industry — free.**

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.

---



---

**[rvtechcheatsheet.com/manuals](https://rvtechcheatsheet.com/manuals)**

**Find thousands more RV manuals, wiring diagrams and parts lists**

**RV techs:** share fixes, ask questions and learn from each other.

**Join our free Facebook group →**

---



---

Follow proper safety practices. If in doubt, consult a professional RV technician.