

AXLES AND SUSPENSION

Toe	The back (wire side) equal to or no more than $\frac{3}{16}$ " larger compared to the front.
Toe Cross Check	The two cross measurements MUST be within $\frac{3}{16}$ " to each other.
Camber	The difference between two measurements MUST be $\frac{3}{8}$ " to $\frac{5}{8}$ "
Hub Face Dimension	+/- $\frac{1}{4}$ " of the HF on order.
Spring Center Dimension	+/- $\frac{1}{8}$ " of the SC on order.
Brake Torque	35-55 ft.-lb.
U-Bolt Torque	5.2K = 65 ft.-lb. 6-8K = 90 ft.-lb. 2K = 25 ft.-lb. 3.5K with $\frac{1}{2}$ " = 50 ft.-lb.

As a supplier of components to the RV industry, safety, education and customer satisfaction are our primary concerns. Should you have any questions, please do not hesitate to contact us at (574) 537-8900 or by email at customerservice@lci1.com. Self-help tips, technical documents, product videos and a training class schedule are available at lci1.com or by downloading the MyLCI app.



This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.