











Callout	Part #	Description
A	252208	TV Lift Kit 30" (763 mm)
B	252207	Rack 30" (763 mm)
C	238462	Torque Shaft
D	236575	Motor; In-Wall; IG 42, 10 mm
E	327493	Bearing Block

SCHWINTEK TV LIFT COMPONENTS

POWER AND MOTION



Callout	Part #	Description
F	238461	Coupler; Torque Shaft/Motor
G	238893	Spur Gear
H	292801	V-Roller
I	242503	V-Roller Screw
J	253396	Controller
K	199082	Switch
L	260992	Cabinet Top Transition Angle
M	193925	TV Plate



This manual is provided courtesy of **RV Tech Cheat Sheet**



Professional resources for the whole RV industry — free.

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.



rvtechcheatsheet.com/manuals

Find thousands more RV manuals, wiring diagrams and parts lists

RV techs: share fixes, ask questions and learn from each other.

Join our free Facebook group →



Follow proper safety practices. If in doubt, consult a professional RV technician.