




# HAPPIJAC®

A Division of Lippert Components Inc.

## WIRING DIAGRAM

Wires to all switches need be no larger than 18 gauge. Wires to +12VDC and Ground can be no smaller than 10 gauge.

NOTE: A FULL COLOR VERSION OF THIS DIAGRAM IS AVAILABLE ON OUR WEBSITE: [WWW.HAPPIJAC.COM](http://WWW.HAPPIJAC.COM)



## MICRO-SWITCH WIRING

One of the wires from each micro-switch shares a terminal with the corresponding wire from the UP-DOWN switch. There is **no polarity** to the micro-switches.

## WIRING HINTS

Keep wire runs as short as possible & minimize number of connections for maximum current flow and best performance.



# This manual is provided courtesy of RV Tech Cheat Sheet



## Professional resources for the whole RV industry — **free.**

We put manuals, wiring diagrams and hard-won tech knowledge in every technician's hands, so repairs get done right the first time, techs work faster, and RV owners everywhere get better service.

**[rvtechcheatsheet.com/manuals](http://rvtechcheatsheet.com/manuals)**

**Find thousands more RV manuals, wiring diagrams and parts lists**

**RV techs:** share fixes, ask questions and learn from each other.

**Join our free Facebook group →**



Follow proper safety practices. If in doubt, consult a professional RV technician.